

**Geneve 9640 Advanced Basic  
User's Manual**

For the  
Geneve 9640  
Family Computer

version update 4.09C

Copyright @2023. All rights reserved. No part of this publication may be reproduced without the written permission of the content creator.

#### **DISCLAIMER OF WARRANTY**

no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of sale-ability or fitness for any particular purpose. This software is sold or licensed "as is." The risk as to its quality and performance is with the buyer and not content creator. All right to revise this publication and to make changes in the content hereof without obligations of the content creator to notify any person of such revisions or changes. The content creator also reserves the right to make design revisions or changes without obligations to notify any person of such revisions or changes.

### Beginning notes on Geneve 9640 Advanced BASIC usage

- ⑩ The Geneve 9640 Advanced BASIC Manual is arranged in an alphabetical order to aid in the search of all the commands, statements and functions with detailed explanations of each.
- ⑩ The Appendix Sections provide an excellent reference on details for effective programming and Advanced BASIC usage.
- ⑩ The Geneve 9640 Advanced BASIC is upwardly compatible with TI Extended BASIC. Plus it implements many new and exciting commands, statements, and functions over TI Extended BASIC for graphics, file access and device handling. Note: There are also several commands and statements that are different or have been revised from TI Extended BASIC. Be sure to read over a command before implementing it in your program.
- ⑩ In the Geneve 9640 Advanced BASIC the following keys combinations are specific to this BASIC:
  1. The function "Break" (FCTN-4 / CLEAR) is invoked by pressing CTRL-C or CTRL-BREAK.. Accordingly, wherever in this manual reference is made to "CLEAR", press CTRL-C or CTRL-BREAK.
  2. ALT-CTRL-DEL initiates a system reset/warm reboot, and will immediately exit Geneve 9640 Advanced BASIC *without saving any work or closing files*.
  3. SHIFT-PRTSC or CTRL-PRTSC or PRTSC makes the keyboard routine invoke the Print Screen interrupt. The screen is dumped to the optional parallel port (PIO). CTRL-PRTSC enables/disables ABASIC (and MDOS) console logging to the optional parallel port. This parallel port output cannot be re-routed to the ABASIC PPT device.
- ⑩ Files can be accessed in Geneve 9640 Advance BASIC with MDOS style drive letters such as "H:\LOAD1" and also device-specific filenames "HDS1.LOAD".
- ⑩ For more on I/O communication with external devices, Advanced BASIC memory usage and a set of default I/O commands read over the sections "I/O Default Commands" and "Advanced BASIC Loading Options" on pages 227 and 228.

**WE RECOMMEND A CAREFUL REVIEW OF THE MANUAL BEFORE PROCEEDING WITH YOUR PROGRAMMING PROJECTS.**

# James Franklin Uzzell

Founder of DDI Software and prolific programmer in Geneve 9640 Advanced BASIC



It is with great honor we recognize the continued development of Advanced Basic and the updates he made to the code and our understanding of the software until his passing in 2005. Without Jim, many MDOS bugs would not have been found. And without Jim, the numerous updates to Advanced Basic that were made would have never happened. Rest in Peace Jim. Your efforts were, and are, greatly appreciated.

Information from the TI-99'ers Hall of Fame at [TI-99ers.ORG](http://TI-99ers.ORG) includes more detail than a snapshot of what is presented below.

Doing business as DDI Software, Jim Uzzell provided some of the best and probably the most Geneve 9640 Advanced BASIC software available for the Myarc "Geneve" 9640 computer. Jim's efforts were good enough to earn him two Jim Peterson Memorial Achievement Award nominations. The first nomination came in 1998 for his MYBASIC 4.0 and then again in 2000 for his release of ABASIC 4.0. Jim also identified and reported specific bugs he found within MDOS. Jim was widely considered to be the world authority in Geneve 9640 Advanced BASIC.

We honor Jim Uzzell, for his knowledge and comradeship and for his dedicated involvement in the circle of support that surrounds the TI-99/4A / Geneve Community.

*Biography prepared by Glenn Bernasek  
with contributions from Jim Uzzell's daughter, Sonya,  
TI-99/4A and Myarc "Geneve" 9640 historian Bill Gaskill,  
and DDI Software review by Charles Good*

**Inducted to the TI99ers Hall of Fame on November 24, 2005**

## TABLE OF CONTENTS

## COMMANDS, STATEMENTS and FUNCTIONS

ABS .....	09
ACCEPT .....	10
ASC .....	13
ATN .....	14
BCOLOR .....	14
BEEP .....	15
BREAK .....	16
BTIME .....	18
BYE .....	18
CALL .....	19
CHAR .....	21
CHARPAT .....	25
CHARSET .....	26
CHDIR .....	26
CHR\$ .....	27
CINT .....	28
CIRCLE .....	29
CLEAR .....	30
CLOSE .....	31
CLS .....	32
COINC .....	33
COLOR .....	35
CONTINUE .....	37
COS .....	38
CREAL .....	39
DATA .....	40
DATA/DATE\$ .....	42
DCOLOR .....	43
DEF .....	44
DEFvartype .....	46
DELETE .....	48
DELSprite .....	49
DIM .....	50
DISPLAY .....	52
DISPLAY USING .....	55
DISTANCE .....	56
DRAW .....	58
DRAWTO .....	60
ECOLOR .....	61
END .....	62
EOF .....	63

ERR .....	64
EXP .....	66
FILES .....	67
FILL .....	68
FOR TO .....	70
FREESPACE .....	73
GCHAR & GPOINT .....	74
GOSUB .....	76
GOTO .....	78
GRAPHICS .....	79
HCHAR .....	82
HEX\$ .....	83
IF THEN ELSE .....	84
IMAGE .....	86
INIT .....	89
INP .....	89
INPUT .....	90
INT .....	94
JOYST .....	95
CALL KEY .....	96
KEY .....	98
KILL .....	100
LEFT\$ .....	101
LEN .....	102
LET .....	103
LINK .....	105
LINPUT .....	106
LIST .....	108
LLIST .....	110
LOAD .....	112
LOCATE .....	114
LOG .....	115
LPR .....	116
LPT .....	116
LTRACE .....	117
MAGNIFY .....	118
MARGINS .....	121
MAX .....	123
MEMSET .....	124
MERGE .....	125
MIN .....	127
MOD .....	128
MOTION .....	129
MOUSE .....	130
MYART .....	132

NEW.....	132
NEXT.....	133
NUMBER.....	134
OLD.....	137
ON BREAK.....	138
ON ERROR.....	140
ON GOSUB.....	142
ON GOTO.....	144
ON WARNING.....	146
OPEN.....	148
OPTION BASE.....	151
OUTP.....	152
PALETTE.....	152
PATTERN.....	153
PEEK.....	154
PEEKV.....	156
PI.....	157
POINT.....	158
POKEV.....	159
POS.....	161
POSITION.....	163
PPT.....	164
PRINT.....	164
PRINT USING.....	169
PSET.....	160
RANDOMIZE.....	170
READ.....	171
REC.....	172
RECTANGLE.....	174
REM.....	176
RESETPLT.....	176
RESEQUENCE.....	177
RESTORE.....	178
RETURN.....	180
RIGHT\$.....	182
RND.....	183
RPT\$.....	184
RUN.....	185
SAVE.....	187
SAY.....	189
SCHAR.....	190
SCREEN.....	190
SEG\$.....	192
SGN.....	193
SIN.....	194
SOUND.....	195
SPGET.....	198

SPRITE .....	199
SPRITE2 .....	204
SPRITESET .....	204
SQR .....	205
STOP .....	206
STR\$ .....	207
SUB .....	208
SUBEND .....	211
SUBEXIT .....	212
SWAP .....	213
TAB .....	214
TAN .....	215
TCOLOR .....	216
TERMCHAR .....	217
TIME/TIME\$ .....	218
TRACE .....	219
UNBREAK .....	220
VAL .....	221
VLHEX .....	222
VCHAR .....	223
VERSION .....	225
WEND .....	225
WHILE .....	226
I/O DEFAULT COMMANDS .....	227
ADVANCED BASIC LOADING OPTIONS .....	228
APPENDICES .....	229
Appendix A: List of Commands, Statements, and Functions .....	230
Appendix B: ASCII Code .....	232
Appendix C: Musical Tone Frequencies .....	234
Appendix D: Character Sets .....	235
Appendix E: Pattern-Identifier Conversion Table .....	235
Appendix F: Color Codes .....	236
Appendix G: Mathematical Functions .....	236
Appendix H: List of Speech Words .....	237
Appendix I: Adding suffixes to Speech Words .....	240
Appendix J: Error Messages .....	246
Appendix K: Summary of Graphics Modes .....	251
Appendix L: Program Illustrating MOUSE Commands .....	252
Appendix M: Call Key ASCII Characters Chart .....	253
Appendix N: ABASIC Assembly Support and other Information .....	256
Appendix O: Color Palette and Hexdecimal Charts .....	259
Appendix P: RS232 Info and OUTP example .....	260
Appendix Q: Some differences between XB and Advanced BASIC .....	262
Appendix R: Commands by category .....	263

---

**ABS****ABS**

## Format

ABS(numeric-expression)

## Type

Numeric (REAL or DEFINT)

## Description

The ABS function gives the absolute value of the numeric-expression.

If the value of the numeric-expression is positive or zero, ABS returns its value.

If the value of the numeric-expression is negative, ABS returns it as a positive number.

ABS always returns a non-negative number.

## Examples

```
100 PRINT ABS(45.2)
```

Output 45.2

```
100 A=ABS(-7.345)
```

```
200 PRINT A
```

Output 7.345

**ACCEPT****ACCEPT**

## Format

```
ACCEPT [[AT(row,column)] [BEEP] [ERASE ALL] [SIZE(numeric-expression)]
[INVERT/BLINK] [CLIP] [VALIDATE(type[,...])]:]variable
```

## Cross Reference

GRAPHICS, INPUT, LINPUT, MARGINS, TERMCHAR, BCOLOR, BTIME

## Description

The ACCEPT instruction suspends program execution to enable you to enter data from the keyboard.

The options available with ACCEPT make it more versatile for keyboard input than the input statement. You can accept up to one line of input from any position within the screen window, sound a tone when the computer is ready to accept input, clear the screen window before accepting input, limit input to a specified number of characters, and define the types of valid input.

ACCEPT can be used as either a program statement or a command.

The data value entered from the keyboard is assigned to the variable you specify. If you specify a numeric variable, the data value entered from the keyboard must be a valid representation of a number. If you specify a string variable, the data value entered from the keyboard can be either a string or a number. Trailing spaces are removed.

A string value entered from the keyboard can optionally be enclosed in quotation marks. However, a string containing a comma, a quotation mark, or leading or trailing spaces must be enclosed in quotation marks. A quotation mark within a string is represented by two adjacent quotation marks.

You normally press ENTER to complete keyboard input; however, you can also use Alt 7 (AID), Alt 9 (BACK), Alt 5 (BEGIN), CLEAR, Alt 6 (PROC'D), DOWN ARROW, or UP ARROW. You can use the TERMCHAR function to determine which of those keys was pressed to exit from the previous ACCEPT, INPUT, or LINPUT instruction.

Note that pressing CLEAR during keyboard input normally causes a break in the program. However, if your program includes an ON BREAK NEXT statement, you can use CLEAR to exit from an input field.

## Options

You can enter the following options, separated by a space in any order.

AT--Enables you to specify the location of the beginning of the input field. Row and column are relative to the upper-left corner of the screen window defined by the margins. The upper-left corner of the window defined by the margins is considered to be the intersection of row 1 and column 1 by an ACCEPT instruction that uses the AT option. If you do not use the AT option, the input field begins in the far left column of the bottom row of the window.

**BEEP**--Sounds a short tone to signal that the computer is ready to accept input.

**.ERASE ALL**--Places a space character (ASCII code 32) in every character position in the screen window before accepting input.

**SIZE**--Enables you to specify a limit to the number of characters that can be entered as input. The limit is the absolute value of the numeric-expression. If the algebraic sign of the numeric-expression is positive, or if you do not use the SIZE option, the input field is cleared before input is accepted. If the numeric-expression is negative, the input field is not cleared, enabling you to place a value in the input field that may be accepted by pressing ENTER. If you do not use the SIZE option, or if the absolute value of the numeric-expression is greater than the number of characters remaining in the row (from the beginning of the input field to the right margin), the input field extends to the right margin.

**VALIDATE**--Enables you to specify the characters or the types of characters that are valid input. If you specify more than one type, a character from any of the specified types is valid. The types are as follows:

TYPE	VALID INPUT
ALPHA	All alphabetic characters.
UALPHA characters.	All upper-case alphabetic
LALPHA characters.	All lower-case alphabetic
DIGIT	All digits (0-9).
NUMERIC	All digits (0-9), the decimal point (.), the plus sign (+), the minus sign (-), and the upper-case letter E.

You can also use one or more string-expressions as types. The characters contained in the strings specified by the string-expressions are valid input.

The VALIDATE option only verifies data entered from the keyboard. If there is a default value in the input field (entered with DISPLAY), for example, the validate option has no effect on that value.

#### New Options

**CLIP**--Using the CLIP option, the string represented in the "DISPLAY AT" statement will be clipped at the end of a line rather than wrapping around to the next line, as it does in the default mode. The CLIP option is particularly useful when using "DISPLAY AT" within a window.

**BLINK/INVERT**--BLINK will cause the line displayed to BLINK on and off. This is only available in GRAPHICS(3,1) mode.



INVERT--will cause the pixels in each character to invert their colors so the foreground- and background-colors will be inverted. This is only available in GRAPHICS(2,2), (2,3), (3,2), and (3,3) modes.

### Examples

```
100 ACCEPT AT(3,5):Y
```

Accepts data at the third row, fifth column of the screen window into the variable Y.

```
100 ACCEPT VALIDATE("YN"):R$
```

Accepts data containing Y and/or N into the variable R\$. (YYNN would be a valid entry.)

```
100 ACCEPT ERASE ALL:B
```

Accepts data into the variable B after putting the blank character into all positions in the screen window.

```
100 ACCEPT AT(R,C)SIZE(FIELDLEN)BEEP VALIDATE(DIGIT,"AYN"):X$
```

Accepts a digit or the letters A, Y, or N into the variable X\$. The length of the input may be up to FIELDLEN characters. A field the length of FIELDLEN is filled with blank characters, and then the data value is accepted at row R, column C. A beep is sounded before acceptance of data.

### Program

```
100 DIM AUTH$(20)BOOK$(20)
```

```
110 DISPLAY AT (5,1)ERASE ALL:"AUTHOR:"
```

```
120 DISPLAY AT(7,1):"BOOK:"
```

```
130 DISPLAY AT(23,1):"TYPE A ? TO END ENTRY."
```

```
140 FOR S=1 TO 20
```

```
150 ACCEPT AT(5,7)VALIDATE(ALPHA,"?")BEEP SIZE(13):AUTH$(S)
```

```
160 IF NAME$(S)."? " THEN 200
```

```
170 ACCEPT AT(7,10)SIZE(12):BOOK$(S)
```

```
180 DISPLAY AT(7,10):" , ."
```

```
190 NEXT S
```

```
200 CALL CLEAR
```

```
210 DISPLAY AT(1,1):"AUTHOR","BOOK"
```

```
220 FOR T=1 TO S-1
```

```
230 DISPLAY AT(T+2,1):AUTH$(T),BOOK$(T)
```

```
240 NEXT T
```

```
250 GOTO 250
```

(Press CLEAR to stop the program.)

**ASC****ASC**

## Format

ASC(string-expression)

## Cross Reference

CHR\$

## Description

The ASC function returns the ASCII character code corresponding to the first character of the string-expression.

ASC is the inverse of the CHR\$ function.

The string-expression cannot be a null string.

## Examples

```
100 PRINT ASC("A")
```

Prints 65 (the ASCII character code for the letter A).

```
100 B=ASC("1")
```

Sets B equal to 49 (the ASCII character code for the character 1).

```
100 DISPLAY ASC("HARRISON")
```

Displays 72 (the ASCII character code for the letter H).

```
100 A$="DOYLE"
```

```
110 PRINT ASC(A$)
```

Prints 68 in line 110 (the ASCII character code for the letter D) .

**ATN****ATN**

## Format

ATN(numeric-expression)

## Cross Reference

COS, SIN, TAN

## Description

The ATN function returns the angle (in radians) whose tangent is the value of the numeric-expression.

The value returned by ATN is always greater than  $-\pi/2$  and less than  $\pi/2$ .

## Examples

```
100 PRINT 4*ATN(-1)
Prints -3.141592654.
```

```
100 Q=PI/ATN(1.732)
Sets Q equal to 3.0000363894830.
```

**BCOLOR****BCOLOR**

## Format

CALL BCOLOR(foreground,background)

## Cross Reference

BTIME, DISPLAY, ACCEPT

## Description

This command is used to set the foreground- and background-colors of the BLINK parameter used in conjunction with DISPLAY AT, ACCEPT AT and BTIME.

It is applicable only to GRAPHICS(3,1) and must be used in conjunction with BTIME.

## Example

```
100 CALL GRAPHICS(3,1)
110 CALL SCREEN(2)
150 CALL BTIME(5,5)::! used to set blink rate
120 CALL BCOLOR(16,7)
130 DISPLAY AT(5,1)ERASE ALL BLINK:"THIS IS BLINKING"
140 ACCEPT AT(5,1)BLINK SIZE(-28):A$
This program displays normal text in white with a red background. The
display area on line 5 will blink and alternately be white text on a
red blocked text to white text on the black background at intervals
set in BTIME.
```

**BEEP****BEEP**

## Cross Reference

DISPLAY [AT], ACCEPT [AT]

## Description

The BEEP command sounds a short tone when encountered as an option in DISPLAY AT and ACCEPT AT commands.

You cannot use BEEP by itself as a program statement or as a command.

## Example

```

100 CALL GRAPHICS(3,3)
110 DEFINT I,R,E
120 FOR I=1 TO 25
130 E=(437+I)-(RND*50)
140 R=(167+I)-(RND*50)
150 CALL PSET(RND*184,RND*480)
160 CALL DRAWTO(1,R,E)
170 DISPLAY AT(24,1)BEEP:R;E
180 FOR X=1 TO 1000::NEXT X
190 NEXT I
200 END

```

This program randomly selects the ROW COLUMN coordinates of 25 points and draws lines connecting them. Each time a line is drawn the values of ROW COLUMN are displayed in the left corner of screen and the BEEP sound is produced.

## BREAK

## BREAK

### Format

BREAK(line-number-list)

### Cross Reference

CONTINUE, ON BREAK, UNBREAK

### Description

The BREAK instruction sets a break-point at each program statement you specify. When the computer encounters a line at which you have set a break-point, your program stops running before that statement is executed.

BREAK is a valuable debugging aid. You can use BREAK to stop your program at a specific program line, so that you can check the values of variables at that point.

You can use BREAK line-number-list as either a program statement or a command.

The line-number-list consists of one or more line numbers, separated by commas. When a BREAK instruction is executed, break-points are set at the specified program lines. If you use BREAK as a program statement, line-number-list is optional. When a BREAK statement with no line-number-list is encountered, the computer stops running the program at that point.

If you use BREAK as a command, you must include a line-number-list.

### break-points

When your program stops at a break-point, the message break-point in line number is displayed. While your program is stopped at a break-point, you can enter any valid command.

To resume program execution starting with the line at which the break occurred, enter the CONTINUE command. However, if you edit your program (add, delete or change a program statement) you cannot use CONTINUE. This prevents errors that could result from resuming execution in the middle of a revised program. You also cannot use CONTINUE if you enter a MERGE or SAVE command or a LIST command with the file-specification option. Note that pressing CLEAR also causes a break-point to occur before the execution of the of the next program statement.

When your program stops at a break-point, the computer performs the following operations:

It restores the default character definitions of all ASCII characters from 33 thru 126.

It restores the default foreground-color and background-color to all characters.

It restores the default screen color..

It deletes all sprites.

It resets the sprite magnification level to 1.

The graphics colors (see DCOLOR) and current position (see DRAWTO) are not affected. If the computer is in GRAPHICS(1,1),(2,1) OR (3,1), the graphics mode and margin settings remain unchanged.

#### Removing break-points

You can remove a break-point by using the UNBREAK instruction or by editing or deleting the line at which the break-point is set. When your program stops at a break-point, that break-point is automatically removed.

All break-points are removed when you use the NEW or SAVE command.

#### BREAK Errors

If the line-number-list includes an invalid line number (0 or a value greater than 32767), the message Bad line number is displayed. If the line-number-list includes a fractional or negative line number, the message Syntax error is displayed. In both cases, the BREAK instruction is ignored; that is, break-points are not set even at valid line numbers in the line-number-list. If you were entering BREAK as a program statement, it is not entered into your program.

If the line-number-list includes a line number that is valid (1-32767) but is not the number of a line in your program, or a fractional number greater than 1, the message

```
WARNING
LINE NOT FOUND
```

is displayed. If you were entering BREAK as a program statement, the line number is included in the warning message. A break-point is, however, set at any valid line in the line-number-list preceding the line number which caused the warning.

#### Examples

150 BREAK

BREAK as a statement causes a break-point before execution of the next line in the program.

100 BREAK 120,130

Causes break-points before execution of lines 120 and 130.

BREAK 10,400,130

As a command, causes break-points before execution of lines 10, 400, and 130.

## BTIME

## BTIME

### Format

CALL BTIME(blinkrate-ON, blinkrate-OFF)

### Cross Reference

BCOLOR, ACCEPT, DISPLAY

### Description

This command is used to set the rate at which characters are set to BLINK in the DISPLAY AT and ACCEPT AT statements. This command can only be used with GRAPHICS(3,1) and must be used in conjunction with BCOLOR. Blinkrate can be an integer from 0 to 15, representing actual blink rates between 0 and 2503.5 milliseconds in multiples of 166.9 milliseconds.

### Example

```
100 CALL GRAPHICS(3,1)
110 CALL DCOLOR(15,5)
120 CALL BCOLOR(15,7)::! Sets blink color
130 FOR I=0 TO 15
140 CALL BTIME(I,I)
150 DISPLAY AT(5,1)ERASE ALL BLINK:"RATE OF BLINK= ";I
160 FOR DELAY=1 TO 1000::NEXT DELAY
170 NEXT I
180 END
```

The above program illustrates some of the possible blink rates.

## BYE

## BYE

### Format

BYE

### Description

The BYE command resets the computer. Always use BYE to exit from Geneve 9640 Advanced BASIC. The BYE command causes the computer to do the following:

- Close all open files.

- Erase the program and all variable values in memory.

- Exit from Geneve 9640 Advanced BASIC.

- Display the DOS command line.

**CALL****CALL****Format**

CALL subprogram-name[(parameter-list)]

**Cross Reference**

SUB

**Description**

The CALL instruction transfers program control to the specified command.

You can use CALL as either a program statement or a command.

The CALL command transfers program control to the subprogram specified by the subprogram-name.

The optional parameter-list consists of one or more parameters separated by commas. Use of a parameter-list is determined by the subprogram you are calling. Some subprograms require a parameter-list, some do not use a parameter-list, and with some a parameter is optional.

You can use CALL as a program statement to call either a built-in Geneve 9640 Advanced BASIC subprogram (command) or to call a subprogram that you write. After the subprogram is executed, program control returns to the statement immediately following the CALL statement.

You can use CALL as a command only to call a built-in Geneve 9640 Advanced BASIC subprogram commands.

Each of the following built-in subprograms commands is discussed separately in this manual:

BCOLOR	ECOLOR	LOAD	PEEK	SPRITE2
BTIME	ERR	LOCATE	PEEKV	SPRITESET
CHAR	FILL	LPR	POINT	TCOLOR
CHARPAT	FILES	MAGNIFY	POKEV	TIME
CHARSET	GCHAR	MARGINS	POSITION	VCHAR
CIRCLE	GPOINT	MEMSET	PSET	VERSION
CLEAR	GRAPHICS	MKEY	RECTANGLE	
COINC	HCHAR	MLOC	RESETPLT	
COLOR	HIDEMOUSE	MOTION	SAY	
DATE	INIT	MOUSEDRAW	SCREEN	
DCOLOR	INP	MREL	SEEMOUSE	
DELSprite	JOYST	MYART	SCHAR	
DISTANCE	KEY	OUTP	SOUND	
DRAW	LINK	PALETTE	SPGET	
DRAWTO	LOAD	PATTERN	SPRITE	

**Examples**

```
100 CALL GRAPHICS(3,1)
200 CALL LINK("filename" [,parameters])
300 CALL RESETPLT
400 CALL USER-SUBPROGRAM
```

## Program

The following program illustrates the use of CALL with a built-in subprogram command (CLEAR) in line 100 and the use of a user-written subprogram (ZPI) in line 120.

```
100 CALL CLEAR
110 X=4
120 CALL ZPI(X)
130 PRINT X
140 STOP
```

```
200 SUB ZPI(Z)
210 Z=Z*PI
220 SUBEND
```

```
RUN
(SCREEN CLEARS)
12.56637061
```

**CHAR****CHAR**

## Format

CALL CHAR(character-code,pattern-string[,...])

## Cross Reference

CHARPAT, CHARSET, COLOR, DCOLOR, GRAPHICS, HCHAR, SCREEN, SPRITE, VCHAR

## Description

The CHAR command enables you to define your own characters so that you can create graphics on the screen.

CHAR is the inverse of the CHARPAT command.

Character-code is a numeric-expression with a value from 0 to 255, specifying the number of the character (codes 0-255). You can define any of the 256 characters and display them as characters and/or sprites.

The pattern-string specifies the definition of the character. The pattern-string, which may be up to 64 digits long, is a coded representation of the pixels that define up to four characters on the screen, as explained below. Any letters entered as part of a pattern-string must be upper case.

You can use the CHARSET command to restore default character definitions of characters 32-95 inclusive. Also, when your program ends (either normally or because of an error), stops at a break-point, or changes graphics mode, all default character definitions (0-255) are restored.

The instructions that you can use to display characters on the screen vary according to the graphics mode. In all modes except GRAPHICS(2,1),(3,1) , you can use the SPRITE command to display sprites on the screen.

If you use HCHAR or VCHAR to display a character on the screen and then later use CHAR to change the definition of that character, the result depends on the graphics mode.

In GRAPHICS(1,1),(2,1) OR (3,1), the displayed character changes to the newly defined pattern.

In GRAPHICS(1,2),(1,3),(2,2),(2,3),(3,2),(3,3), the displayed character remains unchanged.

You can use the DISPLAY, DISPLAY USING, PRINT, and PRINT USING instructions and the HCHAR and VCHAR commands to display characters on the screen.

## Other Graphics Modes

In Graphics(2,X) and (3,X), each character is composed of 48 pixels in a grid eight pixels high and six pixels wide. The eight by eight grid described below is used to define characters; however, the last two pixels in each pixel-row are ignored.

In these modes, you can use the DISPLAY, DISPLAY USING, PRINT, and PRINT USING instructions and the HCHAR and VCHAR commands to display characters on the screen. You cannot display sprites in GRAPHICS (2,1),(3,1).

### Character Definition--The Pattern String

Characters are defined by turning some pixels on and leaving others off. The space character (ASCII code 32) is a character with all the pixels turned off. Turning all the pixels on produces a solid block, eight pixels high and eight pixels wide.

The foreground-color is the color of the pixels that are on. The background-color is the color of the pixels that are off. (For more information see COLOR, DCOLOR, and SCREEN.)


When you enter Geneve 9640 Advanced BASIC, the characters are predefined with the appropriate pixels turned on. To redefine a character, you specify which pixels to turn on and which pixels to turn off.

For the purpose of defining characters, each pixel-row (eight pixels) is divided into two blocks (four pixels each). Each digit in the pattern-string is a code specifying the pattern of the four pixels in one block.

You define a character by describing the blocks from left to right and from top to bottom. The first two digits in the pattern-string describe the pattern for the first two blocks (pixel-row 1) of the grid, the next two digits define the next two blocks (pixel-row 2), and so on.

The computer uses a binary (base 2) code to represent the status of each pixel; you use hexadecimal (base 16) notation of the binary code to specify which pixels in a box are turned on and which pixels are turned off.

The following table shows all the possible on/off combinations of the four pixels in a block and the binary code and hexadecimal notation representing each combination.

BLOCK	BINARY CODE	HEXADECIMAL (0=OFF; 1=ON) NOTATION
	0000	0
	0001	1
	0010	2
	0011	3
	0100	4
	0101	5
	0110	6
	0111	7
	1000	8
	1001	9
	1010	A
	1011	B
	1100	C
	1101	D
	1110	E
	1111	F

A character definition consists of 16 hexadecimal digits; each digit represents one of the 16 blocks that comprise a character. As the pattern-string may be up to 64 digits long, you can define as many as four consecutive characters with one pattern-string.

If the length of the pattern-string is not a multiple of 16, the computer fills the pattern-string with zeros until its length is a multiple of 16.

#### Programs

For the dot pattern pictured below, you use "1898FF3D3C3CE404" as the pattern string for CALL CHAR. The following program uses this and one other string to make a figure "dance".

```

100 CALL CLEAR
105 CALL GRAPHICS(1,1)
110 A$="1898FF3D3C3CE404"
120 B$="1819FFBC3C3C2720"
130 CALL COLOR(27,7,12)
140 CALL VCHAR(12,16,244)
150 CALL CHAR(244,A$)
160 GOSUB 200170 CALL CHAR(244,B$)
180 GOSUB 200
190 GOTO 150
200 FOR DELAY=1 TO 150
210 NEXT DELAY
220 RETURN
RUN
(screen clears)
(character moves)
(Press CLEAR to stop the program.)

```

For other graphics modes make the following changes.

```
105 CALL GRAPHICS(2,2)::! Or other non-text
130 CALL DCOLOR(7,12)
140 CALL CHAR(144,A$,145,B$)
150 CALL VCHAR(12,16,144)
170 CALL VCHAR(12,16,145)
```

If a program stops for a break-point, all characters are reset to their standard patterns. When the program ends normally or because of an error, all characters are reset.

The following example works in all graphics modes.

```
100 CALL CLEAR
110 CALL GRAPHICS(X,Y)
120 CALL CHAR(144,"FFFFFFFFFFFFFFFF")
130 CALL CHAR(42,"0F0F0F0F0F0F0F0F")
140 CALL HCHAR(12,17,42)
150 CALL VCHAR(14,17,144)
160 FOR DELAY=1 TO 500
170 NEXT DELAY
RUN
```

The X and Y in line 110 must be replaced with the number of the graphics mode to be designated.



**CHARPAT****CHARPAT**

## Format

```
CALL CHARPAT(character-code,string-variable[,....])
```

## Cross Reference

CHAR

## Description

The CHARPAT command enables you to ascertain the current character definition of specified characters.

Character-code is a numeric-expression with a value from 0 to 255, specifying the number of the character of which you want the current definition.

The pattern describing the character definition is returned in the specified string-variable. The pattern is in the form of a 16-digit hexadecimal code. See CHAR for an explanation of the pattern used for character definition.

See Appendix B for a list of available characters.

## Example

```
100 CALL CHARPAT(33,C$)
```

Sets C\$ equal to "0010101010001000", the pattern identifier for character 33, the exclamation point.

## CHARSET

## CHARSET

Format  
CALL CHARSET

Cross Reference  
CHAR, COLOR

Description  
The CHARSET command restores default character definitions and colors.

CHARSET, restores the default character definitions to characters 32-126, inclusive.

In Graphics (1) or (1,1), CHARSET restores the default colors to all 256 characters.

## CHDIR

## CHDIR

Format  
CHDIR path.filename

Cross Reference  
FILES, PWD, KEY LIST

Description  
This COMMAND allows you to change the default working directory.

Examples

From the prompt  
CHDIR DSKX.SUBDIR  
CHDIR HDSX.SUBDIR.SUBDIR

Typing PWD or KEY LIST from the prompt will display the working directory.

**CHR\$****CHR\$**

Format

CHR\$(character-code)

Type

String

Cross Reference

ASC

Description

The CHR\$ function returns the character corresponding to the ASCII character code specified by the value of the character-code.

CHR\$ is the inverse of the ASC function.

Character-code is a numeric-expression with a value from 0 to 32767 inclusive, specifying the number of the character you wish to use. If the value of character-code is greater than 255, it is repeatedly reduced by 256 until it is less than 256. If the value of the character-code is not an integer, it is rounded to the nearest integer.

Examples

```
100 PRINT CHR$(72)
```

Prints H.

```
100 X$=CHR$(33)
```

Sets X\$ equal to !.

Program for a complete listing of all ASCII characters and their corresponding ASCII values, run the following program.

```
100 CALL CLEAR
110 IMAGE ### ## ### ##
120 FOR A=32 TO 127
130 PRINT USING 110:A,CHR$(A);
140 NEXT A
```

## CINT

## CINT

Format  
(numeric-expression=CINT(numeric-expression))

Cross Reference  
DEFvaratype,CREAL

Description  
Converts a number to integer precision.

Arithmetic modes:  
REAL: real numbers and integers.

**CIRCLE****CIRCLE**

## Format

```
CALL CIRCLE(line-type,pixelrow,pixelcol,radius)
```

## Cross Reference

```
DRAW,DRAWTO,DCOLOR,GRAPHICS
```

## Description

Draws a circle on the screen with center at pixelrow, pixelcol with a defined radius. Can not be used with GRAPHICS(2,1),(3,1).

## Example

```
100 CALL GRAPHICS(3,2)
200 CALL DCOLOR(16,2)
300 CALL CIRCLE(1,98,128,160)
400 INPUT A$
```

**CLEAR****CLEAR**

Format  
CALL CLEAR

Cross Reference  
DCOLOR, DELSPRITE

Description  
The CLEAR command erases the screen.

CLEAR places a space character (ASCII code 32) in every screen position.

The CLEAR command has no effect on sprites. Use the DELSPRITE command to remove sprites.

**Programs**

When the following program is run, the screen is cleared before the PRINT statements are performed.

```
100 CALL CLEAR
110 PRINT "LARRY NIVEN"
120 PRINT "RINGWORLD"
RUN
--screen clears
LARRY NIVEN
RINGWORLD
```

If the space character (ASCII code 32) has been redefined by the CALL CHAR command, the screen is filled with the new character when CALL CLEAR is performed.

```
100 CALL CHAR(32,"0103070F1F3F7FFF")
110 CALL CLEAR
120 GOTO 120
RUN
--Screen is filled with *
(Press CLEAR to stop the program.)
```

The following program first fills and then clears the entire screen.

```
100 CALL GRAPHICS(1,2)
110 CALL HCHAR(1,2,72,768)
120 FOR DELAY=1 TO 500::NEXT DELAY
130 CALL CLEAR
140 GOTO 140
RUN
(Press CLEAR to stop the Program.)
```

**CLOSE****CLOSE****Format**

`CLOSE #file-number[:KILL], CLOSE ALL`

**Cross Reference**

KILL, OPEN, DELETE

**Description**

The CLOSE instruction closes the specified file. When you close a file, you discontinue the association (between your program and the file) that you established in the OPEN instruction.

The KILL option is not allow without a specific #file-number. Use CLOSE ALL to close all open files.

You can use CLOSE as either a program statement or a command.

The file-number is a numeric-expression whose value specifies the number of the file as assigned in its OPEN instruction.

The KILL option, which can be used only with certain devices, deletes the file after closing it. For more information about using the KILL option with a particular device, refer to the owner's manual that comes with that device.

After the CLOSE instruction is performed, the closed file cannot be accessed by an instruction because the computer no longer associates that file with a file -number. You can reassign the file-number to another file.

**Closing Files Without the CLOSE Instruction**

To protect the data in your files, the computer closes all open files when it reaches the end of your program or when it encounters an error (either in Command or Run mode).

Open files are also closed when you do one of the following:

    Edit your program (add, delete, or change a program statement).

    Enter the BYE, MERGE, NEW, OLD, RUN or SAVE command.

Open files are not closed when you stop program execution by pressing CLEAR(F4) or when your stops at a break-point set by a BREAK instruction.

**Example****Diskette file**

```
100 OPEN #24:"DSK1.MYDATA",INTERNAL,UPDATE,FIXED
```

```
200 CLOSE #24
```

```
RUN
```

The CLOSE statement for a diskette requires no further action on your part.

## CLS

## CLS

Format  
CLS

### Description

You may use CLS either as a program statement or a command. CLS clears the window created with the CALL MARGINS statement and returns the cursor to the home position. It does not remove the window though. To remove a window use CALL GRAPHICS or CALL MARGIN. Can also be used to clear the general screen without a MARGIN command being issued. Can be used in all GRAPHICS modes.

### Example

```
100 CALL GRAPHICS(2,1)
110 CALL MARGINS(1,14,1,16)
120 PRINT "THE SKYLARK OF SPACE":"E.E. SMITH"
130 CALL KEY(0,K,S)::IF S<1 THEN 130
140 CLS:!! Clears contents in window
```

**COINC****COINC**

## Format

## Two sprites

```
CALL COINC(#sprite-number1,#sprite-number2,tolerance,numeric-
variable)
```

## A Sprite and a screen pixel

```
CALL COINC(#sprite-number,pixelrow,pixelcol,tolerance,numeric-
variable)
```

## All Sprites

```
CALL COINC(ALL,numeric-variable)
```

```
CALL COINC(ALL,numeric-variable,pixelrow,pixelcol)
```

## Cross Reference

## SPRITE

## Description

The COINC command enables you to ascertain if sprites are coincident (in conjunction) with each other or with a specified screen pixel.

The exact conditions that constitute a coincidence vary depending on whether you are testing for the coincidence of two sprites, a sprite and a screen pixel, or all sprites.

If the sprites are moving very quickly, coinc may occasionally fail to detect a coincidence.

## Two Sprites

Two sprites are considered to be coincident if the upper-left of the sprites are within a specified number of pixels (tolerance) of each other.

The values of the numeric-expression sprite-number1 and sprite-number2 specify the numbers of the two sprites as assigned in the SPRITE command.

A coincidence exists if the distance between the pixels in the upper-left corners of the two sprites is less than equal to the value of the numeric-expression tolerance.

The distance between two pixels is said to be within tolerance if the difference between pixelrows and the difference between pixelcols are both less than or equal to the specified tolerance. Note that this is not the same as the distance indicated by the DISTANCE command.

COINC returns a value in the numeric-variable indicating whether or not the specified coincidence exists. The value is -1 if there is a coincidence or 0 if there is no coincidence.

## A Sprite and a Screen Pixel

A sprite is considered to be coincident with a screen pixel if the upper-left corner of the sprite is within a specified number of pixels (tolerance) of the screen pixel or if any pixel in the sprite occupies the screen pixel location.

The sprite-number is a numeric-expression whose value specifies the number of the sprite assigned in the SPRITE command.

The pixelrow and the pixelcol are numeric-expressions whose values specify the position of the screen pixel.

A coincidence exists if the distance between the pixel in the upper-left corner of the sprite and the screen pixel is less than or equal to the value of the numeric-expression tolerance. (Note that a coincidence also exists if any pixel in the sprite occupies the screen pixel location).

The distance between two pixels is said to be within tolerance if the difference between pixelrows and the difference between pixelcols are both less than or equal to the specified tolerance. Note that this is not the same as the distance indicated by the DISTANCE command.

COINC returns a value in the numeric-variable indicating whether or not the specified coincidence exists. The value is -1 if there is a coincidence or 0 if there is no coincidence.

#### All sprites

The ALL option tests for the coincidence of any of the sprites.

For the ALL option, sprites are considered to be coincident if any pixel of any sprite occupies the same screen pixel location as any pixel of any other sprite.

Also the ALL with a pixelrow,pixelcol option considers there to be a coincidence if any sprite occupies the defined screen location of pixelrow,pixelcol.

COINC returns a value in the numeric-variable indicating whether or not a coincidence exists. The value is -1 if there is a coincidence or 0 if there is no coincidence.

#### Program

```
100 CALL CLEAR::S$="0103070F1F3F7FFF"
120 CALL CHAR(244,S$)::CALL CHAR(250,S$)
130 CALL SPRITE(#1,244,7,50,50)
140 CALL SPRITE(#2,250,5,44,42)
150 CALL COINC(#1,#2,10,C)
160 PRINT C
170 CALL COINC(ALL,C)
180 PRINT C
RUN
-1
0
```

Line 150 shows a coincidence because the upper-left corners of the sprites are within 10 pixels of each other.

Line 170 shows no coincidence because the shaded areas of the sprites do not occupy the same screen pixel location. (Shaded areas are compared only if you specify the ALL option.) Do not use when MOUSE interrupts are on (MOUSE ON).

**COLOR****COLOR**

## Format

Pattern Mode-GRAPHICS(1,1)

CALL COLOR(character-set,foreground-color,background-color[,....])

## Sprites

CALL COLOR(#sprite-number,foreground-color[,....])

## Cross Reference

CHAR, DCOLOR, GRAPHICS, PALETTE, SCREEN, SPRITE, SPRITE2, TCOLOR

## Description

The COLOR command enables you to specify the colors of characters or sprites.

The types of parameters you specify in a call to the COLOR command depend on whether you are assigning colors to characters or to sprites.

In general, each character has two colors. The color of the pixels that make up the character itself is the foreground-color; the color of the pixels that occupy the rest of the character position on the screen is the background color.

When you enter Geneve 9640 Advanced BASIC, the foreground-color of all the characters is white; the background-color of all characters is blue. These default colors are restored when your program ends (either normally or because of an error, stops at a break-point, or changes graphics mode.

If a color is transparent, the color actually displayed is the color specified by the SCREEN command.

See Appendix F for a listing of available colors and their respective codes.

TI99 character mode-GRAPHICS(1,1)

In this mode the 256 available characters are divided into 32 sets of 8 characters each. When you assign a color combination to a particular set, you specify the colors of all 8 characters in that set.

The character-set is a numeric-expression whose value specifies the number (0-31) of the 8 character set.

Fore-ground-color and background-color are numeric-expressions whose values specify colors that can be assigned from among the 16 available colors.

CALL COLOR(#0,foreground-color) sets the MOUSE color.

In the 256 color mode(2,2), the colors are 1-256. In the 4 color mode(3,2) the colors are 1-4.

See Appendix D for available characters and character sets in Pattern Mode GRAPHICS(1,1).

Text Modes- GRAPHICS(2,1),(3,1)

Use the SCREEN command to assign character colors in Text Mode. Sprites are not displayed in text mode.

Graphics(1,2),(1,3),(2,2),(2,3),(3,2),(3,3)

In these modes, you can use COLOR only to assign colors to sprites; any other use of the COLOR command causes an error. Use the DCOLOR command to specify character and graphics colors in High-Resolution Mode.

### Sprites

A sprite is assigned a foreground-color when it is created with the SPRITE command. The back-ground-color of a sprite is always transparent.

To re-assign colors to sprites you must use the sprite parameters, no matter what graphics mode the computer is in.

The sprite-number is a numeric-expression whose value specifies the number of a sprite as assigned by the SPRITE command.

Fore-ground-color is a numeric-expression whose value specifies a color that can be assigned from among the 16 available colors.

When using with the SPRITE2, which enables multi-color SPRITES, 16 foreground colors must be specified for each of the 16 lines of the SPRITE in the form of;

CALL COLOR(#5,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16)

Note: SPRITE2 for more details.

### Examples

```
100 CALL COLOR(#5,16)
```

Sets sprite number 5 to have a foreground-color of 16 (white). The background is always 1 (transparent).

This example is valid in all graphics modes. (Remember that sprites have no effect in (2,1) or (3,1)).

```
100 CALL COLOR(#7,INT(RND*16+1))
```

Sets sprite number 7 to have a foreground-color chosen randomly from the 16 colors available. The background-color is 1 (transparent).

This example is valid in all graphics modes.

### Program

This program sets foreground-color of characters 48-55 to 5(dark blue) and the background-color to 12(light yellow).

```
100 CALL CLEAR
```

```
110 CALL GRAPHICS(1,1)
```

```
120 CALL COLOR(3,5,12)
```

```
130 DISPLAY AT(12,16):CHR$(48)
```

```
140 GOTO 140
```

(Press CLEAR to stop the program.)

**CONTINUE****CONTINUE**

Format  
CONTINUE  
CON

Cross Reference  
BREAK

**Description**

The CONTINUE command restarts a program which has been stopped by a break-point. It may be entered whenever a program has stopped running because of a break-point caused by the BREAK command or statement or pressing Control + Break keys (CLEAR.) However, you cannot use the CONTINUE command if you have edited a program line. CONTINUE may be abbreviated as CON.

When a break-point occurs, the standard character set and standard colors are restored. Sprites cease to exist. CONTINUE does not restore user-defined characters that have been reset or any colors. Otherwise, the program continues as if no break-point had occurred.

## COS

## COS

### Format

COS(numeric-expression)

### Type

REAL

### Cross Reference

ATN, SIN, TAN

### Description

The COS function returns the cosine of the angle whose measurement in radians is the value of the numeric-expression.

The value of the numeric-expression cannot be less than -1.5707963269514E10 or greater than 1.5707963266374E10.

To convert the measure of an angle from degrees to radians, multiply by  $\pi/180$ .

### Program

The following program gives the cosine for each of several angles.

```
100 A=1.047197551196
110 B=60
120 C=45*PI/180
130 PRINT COS(A);COS(B)
140 PRINT COS(B*PI/180)
150 PRINT COS(C)
RUN
.5 -.9524129804
.5
.7071067812
```

**CREAL****CREAL**

## Format

(numeric-expression)=CREAL(numeric-expression)

## Cross Reference

DEFvartype, CINT

## Description

Converts a number to single-precision float.

## Arithmetic modes:

REAL: real numbers and integers.

## Example

X=CREAL(Y)

**DATA****DATA**

## Format

DATA data-list

## Cross Reference

READ, RESTORE

## Description

The DATA statement enables you to store constants within your program. You can assign the constants to variables by using a READ statement.

The data-list consists of one or more constants separated by commas. The constants can be assigned to the variables specified in the variable-list of a READ statement. The assignment is made when the READ statement is executed.

If a numeric variable is specified in the variable-list of a READ statement, a numeric constant must be in the corresponding position in the data-list of the DATA statement. If a string variable is specified in a READ statement, either a string or a numeric constant may be in the corresponding position in the DATA statement. A string constant in a data-list may optionally be enclosed in quotation marks. However, if the string constant contains a comma, a quotation mark, or leading or trailing spaces, it must be enclosed in quotation marks.

A quotation mark within a string constant is represented by two adjacent quotation marks. A null string is represented in a data-list by two adjacent commas, or two commas separated by two adjacent quotation marks.

The order in which the data values appear within the data-list and the order of the DATA statements within a program normally determine the order in which the values are read. Values from each data-list are read sequentially, beginning with the first item in the first DATA statement. If your program includes more than one DATA statement, the DATA statements are read in ascending line-number order (unless you use a RESTORE statement to specify otherwise).

A DATA statement encountered during program execution is ignored.

A DATA statement cannot be part of a multiple-statement line, nor can it include a trailing remark.

## Program

The following program reads and prints several numeric and string constants.

```

100 FOR A=1 TO 5
110 READ B,C
120 PRINT B;C
130 NEXT A
140 DATA 2,4,6,7,8
150 DATA 1,2,3,4,5
160 DATA """"THIS HAS QUOTES-CS LEWIS""""
170 DATA NO QUOTES HERE-OUT OF THE SILENT PLANET
180 DATA " NO QUOTES HERE, EITHER-PERELANDRA"
190 FOR A=1 TO 6
200 READ B$
210 PRINT B$
220 NEXT A
230 DATA 1,NUMBER,GENEVE
RUN
2 4
6 7
8 1
2 3
4 5
"THIS HAS QUOTES-CS LEWIS"
NO QUOTES HERE-OUT OF THE SILENT PLANET
NO QUOTES HERE, EITHER-PERELANDRA
1
NUMBER
GENEVE

```

Line 100 through 130 reads five sets of data and prints their values, two to a line.

## DATE/DATE\$

## DATE/DATE\$

### Format

```
CALL DATE("mm/dd/yy")
DATE$
```

### Description

DATE\$ can be a function.

CALL DATE can be a statement or a command.

It can be used to set the date or retrieve the current date.

To set the date use the format:

```
CALL DATE("mm/dd/yy")
```

mm is the two-digit equivalent of the current month 01-12

dd is the two digit date 01-31

yy is the last two digits. Two-digit range= range 01-99

To retrieve the current date, use the function DATE\$.

### Example

```
CALL DATE("01/01/87")
```

This example sets the date to January 1, 1987

### Example

```
PRINT DATE$
01/01/87
```

### Example

```
100 PRINT "TODAY'S DATE IS ";DATE$
110 INPUT "DO YOU WISH TO CHANGE THE DATE ?":CHANGE$
120 IF LEFT$(CHANGE$,1)="Y" OR LEFT$(CHANGE$,1)="y" THEN 130 ELSE END
130 INPUT "ENTER NEW DATE:":NEWDATE$
140 CALL DATE(NEWDATE$)
150 GOTO 100
```

Note: Date/Time comes off the clock chip mapped in upper memory of the card.

**DCOLOR****DCOLOR**

## Format

CALL DCOLOR(foreground-color,background-color)

## Cross Reference

CIRCLE, COLOR, DRAW, DRAWTO, FILL, GRAPHICS, POINT, RECTANGLE

## Description

The DCOLOR command enables you to set the graphics colors for GRAPHICS(1,2),(1,3),2,2),(2,3),(3,2) and (3,3).

The graphics colors are used by the CIRCLE, DRAW, DRAWTO, FILL, POINT, and RECTANGLE commands.

DCOLOR has no effect in GRAPHICS(1,1),(2,1) or (3,1).

## Example

```
110 CALL GRAPHICS(2,2)
120 CALL DCOLOR(9,0)
130 CALL DRAW(1,1,1,22,3)
```

This program draws a short red line.

## DEF

## DEF

### Format

DEF function-name[(parameter1 [, . . . parameter7])]=expression

### Description

The DEF statement enables you to define your own functions. These user-defined functions can then be used in the same way as built-in functions.

The function-name can be any valid variable name that does not appear as a variable name elsewhere in your program.

If the function-name is a numeric variable, the value of the expression must be a number. If the function-name is a string variable, the value of the expression must be a string.

If the function-name is a numeric variable, you can optionally specify its data-type (DEFINT, DEFREAL, DEFSNG, or DEFDBL) by using variable tags.

You can use up to seven parameters to pass values to a function. Parameters must be valid variable names. A variable name used as a parameter cannot be the name of an array. You can use an array element in the expression if the array does not have the same name as a parameter in that statement. The variable names used as parameters in a DEF statement are local to that statement; that is, even if a parameter has the same name as a variable in your program, the value of that variable is not affected.

If a parameter is a numeric variable, you can optionally specify its data-type (DEFINT, DEFREAL) by using variable tags.

A DEF statement must have a lower line number than that of any use of the function-name it defines. A DEF statement is not executed.

A DEF statement can appear anywhere in your program, except that it cannot be part of an IF THEN statement.

### DEF without Parameters

When your program encounters a statement containing a previously defined function-name with no parameters, the expression is evaluated, and the function is assigned the value of the expression at that time.

If you define a function-name without parameters, it must appear without parameters when you use it in your program.

## DEF With Parameters

When your program encounters a statement containing a previously defined function-name with parameters, the parameters values are passed to the function in the same order in which they are listed. The expression is evaluated using those values, and the function is assigned the value of the expression at that time. String values can be passed only to string parameters. Numeric values can be passed only to numeric parameters.

If you define a function with parameters, it must appear with the same number of parameters when you use it in your program.

## Recursive Definitions

A DEF statement may reference other defined functions (the expression may include previously defined function-names). However, a DEF statement may not be directly or indirectly recursive (self-referencing).

Direct recursion occurs when you use the function-name in the expression of the same DEF statement. (This would be similar to writing a dictionary definition that included the word you were trying to define.)

Indirect recursion occurs when the expression contains a function-name, and in turn the expression in the DEF statement of that function (or other function subsequently referenced) includes the original function-name. (This would be similar to looking up the dictionary definition of a word, finding that the definition included other words that you needed to look up, and then discovering that the definitions led you directly back to your original word.)

## Examples

```
100 DEF PAY(OT)=40*RATE+1.5*RATE*OT
110 RATE=4.00
120 PRINT PAY(3)
RUN
178
```

Defines PAY so that each time it is encountered in a program the pay is figured using the RATE of pay times 40 plus 1.5 times the rate of pay times the overtime hours.

```
100 DEF RND20=INT(RND*20+1)
```

Defines RND20 so that each time it is encountered in a program an integer from 1 to 20 is given.

```
100 DEF FIRSTWORD$(NAME$)=SEG$(NAME$,1,POS(NAME$," ",1)-1)
```

Defines FIRSTWORD\$ to be the part of NAMES\$ that precedes a space.

**DEFvartype****DEFvartype****DEFINT, DEFREAL and DEFSTR**

Vartypes: DEFINT, DEFREAL, DEFSTR

DEFINT - define as integers  
 DEFREAL- define as floating point (64 bit)  
 DEFSTR - define as string

Format:     DEFINT I,J,COUNT,LOOPNUM,DIM A(100)  
               DEFREAL SQRROOT,VALUE,N,DIM D(40)  
               DEFSTR NAM,FILENAME,N,F,DIM E(75)

NOTE: DEFREAL ALL is the default mode in Geneve 9640 Advanced BASIC.  
 (ALL- defines all variables as a specified type unless overrode by the  
 symbol types.)

Cross Reference  
 DIM, OPTION BASE, SUB

Description  
 The DEFvartype instruction enables you to declare the data-type of  
 specified variables.

Usually the name given to a variable will identify the type of  
 variable.

Example: If a variable name ends in a dollar sign (i.e. A\$) then the  
 variable is a string variable. Numeric variables can be identified in  
 Geneve 9640 Advanced BASIC in terms of precision by the use of the  
 following symbol as terminator attached to the end of the variable  
 name. %, is termed type declaration tag.

SYMBOL	TYPE OF VARIABLE
\$	STRING VARIABLE
%	INTEGER CONSTANT
(no symbol)	REAL FLOATING POINT

Variables can also be declared by use of the DEFvartype statement. The  
 declaration must be present and executable at a lower line number than  
 that of any use of the variable-names that it represents.

A DEFvartype statement must appear at the beginning of a line. Also,  
 any variable defined by that statement must appear later in the  
 program.

The variable-list consists of one or more variables separated by commas. The DEFINT and DEFREAL statements allow an ALL option, if this is used then all numeric variables in the program will be defined as the type specified except if they are specifically declared otherwise.

#### Integer:

A numeric variable of the integer data-type is a whole number greater than or equal to -32768 and less than 32767. Integer variables are processed faster and use less memory than do real (or floating) point variables.

#### REAL:

Real numbers are floating point numbers which is the default number type in ABASIC.

DEFvartype statements also can be used to declare the types of arrays.

TYPE-DECLARATION-TAGS override DEFvartype statements.

#### Programs

In the following example, DEFSTR NAM overrides DEFINT ALL such that NAM(5) will be treated as a string.

```
100 DEFINT ALL
110 DEFSTR NAM(5)
120 NAM(5)="Geneve":X%=37.123545:I=1.2345
130 PRINT NAM(5);X;I
RUN
Geneve 37.123545 1
```

**DELETE****DELETE**

## Format

DELETE [startline#-endline#]

## Description

100-200 deletes lines 100-through 200.

COMMAND	LINES DELETED
DELETE	All lines.
DELETE X	Line number X only.
DELETE X-	Lines from number X to the highest line number, inclusive.
DELETE -X	Lines from the lowest line number to line number X, inclusive.
DELETE X-Y	All lines from line number X to line number Y, inclusive.
DELETE X,Y	All lines from line number X to line number Y, inclusive.

If any line-number-range does not include a line number in your program, the following conventions apply:

If line-number-range is higher than any line number in your program, the highest-numbered program line is deleted.

If line-number-range is lower than any line number in your program, the lowest-numbered program line is deleted.

If line-number-range is between lines in the program, only those lines that fall within the range specified will be deleted.

NOTE: For TI 99/4A BASIC(s) converted Programs:

Delete will no longer be used to delete files from DISK STORAGE DEVICE. See KILL, CLOSE, FILES. However, programs that contain a "DELETE" file statement will execute exactly as they did under TI BASIC or TI EXTENDED BASIC. The token used internally will now be occupied by the KILL command. As long as the program is stored in tokenized form(program file, or DV163 merge format), then execution will not be affected. On listing the program, the word "KILL" will be listed instead of "DELETE".

DELETE--no longer applies to files. DELETE applies to line numbers only. To delete files, see KILL.

**DELSPRITE****DELSPRITE**

## Format

Delete Specified Sprite

CALL DELSPRITE(#sprite-number[,... •])

Delete All Sprites

CALL DELSPRITE(ALL)

## Cross Reference

CLEAR, SPRITE

## Description

The DELSPRITE command enables you to delete one or more sprites. All sprites are deleted when your program ends (either normally or because of an error), stops at a break-point, or changes graphics mode.

## Delete Specific Sprites

Sprite-number is a numeric-expression whose value specifies the number of the sprite as assigned in the SPRITE command. The sprite can reappear if it is redefined by the SPRITE command, or if the LOCATE command is called.

## Delete All Sprites

If you enter the ALL option, all sprites are deleted, and can reappear only if redefined by the SPRITE command.

## Examples

100 CALL DELSPRITE(#3)

Deletes sprite number 3.

100 CALL DELSPRITE(#4,#3\*C)

Deletes sprite number 4 and the sprite whose number is found by multiplying 3 by C.

100 CALL DELSPRITE(ALL)

Deletes all sprites.

**DIM****DIM**

## Format

```
DIM array-name(integer1[,... integer7])[,array-name... ]
```

## Cross Reference

OPTION BASE

## Description

The DIM instruction enables you to dimension (reserve space for) arrays with one to seven dimensions.

You can use DIM as either a program statement or a command.

The array-name must be a valid variable name. It cannot be used as the name of a variable or as the name of another array. An array is either numeric or string, depending on the array-name.

The integer is the upper limit of element numbers in a dimension.

If a program includes an OPTION BASE 1 statement, the first element is element 1, so the number of elements is equal to the integer plus 1.

A string array cannot have more than 16383 elements. For numeric arrays, a DEFINT array cannot have more than 32767 elements, and a floating point array cannot have more than 16383 elements. The number of integers in parentheses following the array-name determines the number of dimensions (1-7) in the array.

You can optionally specify the data-type (DEFvartype) of a numeric array by replacing DIM with the data-type.

An error occurs if you try to dimension a particular array more than once.

Note that you cannot use both instruction formats (DIM and data-type) to dimension the same array.

You cannot use OPTION BASE as a command.

You can dimension as many arrays with one DIM instruction as you can fit in one input line.

If you reference an array without first using a DIM instruction to dimension it, each dimension is assumed to have 11 elements (elements 0-10), or 10 elements (elements 1-10) if your program includes an OPTION BASE 1 statement.

If you use a DIM statement to dimension an array, the DIM statement must have a line number lower than that of any reference to that array. DIM statements are interpreted during pre-scan and are not executed.

A DIM statement can appear anywhere in your program, except as part of an IF THEN statement.

## Referencing an Array

To reference a specific element of an array, you must use subscripts. Subscripts are numeric-expressions enclosed in parentheses immediately following the reference to the array-name. An array must include one subscript for each dimension in the array. If necessary, the value of a subscript is rounded to the nearest integer.

## Reserving Space for Arrays

When you use DIM as a program statement, the computer reserves space for arrays when enter the RUN instruction, before your program is actually run. If the computer cannot reserve space for an array with the dimensions you specify, the message Memory Full in line-number is displayed, and the command does not execute.

When you use DIM as a command, if the computer cannot reserve space for an array with the dimensions you specify, the message Memory Full is displayed and the command does not execute.

Until you place values in an array, each element in a string array is a null string and each element in a numeric array has a value of zero.

## Naming Arrays

The rules for naming array variables follow the same pattern as the rules for other type variables, namely if a variable name ends in variable type descriptor defines the variable type.

NOTE: If a DEFSTR statement is executed then a string array name need not end in a \$.

Array variable names ending in % refer to integer variables.

Type/declaration tags, such as \$, %, take precedence over DEFvartype all declarations.

The following statements will remove arrays from memory:

NEW, OLD, MERGE, RUN (without continue)

CALL MEMSET --sets all elements of an array to a defined value. (See command MEMSET)

## Examples

```
100 DIM X$(30)
```

Reserves space in the computer's memory for 31 string numbers of the array called X\$.

```
100 DIM D(100),B(10,9)
```

Reserves space in the computer's memory for 101 members of the array called D and 110 (11 times 10) members of the array called B.

**DISPLAY****DISPLAY**

## Format

```

DISPLAY [print-list]
DISPLAY [AT(row,column)] [BEEP] [ERASE ALL] [CLIP] [INVERT/BLINK]
[SIZE(numeric-expression)] [:print-list]

```

## Cross Reference

DISPLAY USING, GRAPHICS, MARGINS, PRINT, BTIME, BCOLOR

## Description

The DISPLAY instruction enables you to display numbers and strings on the screen. The numeric- and/or string-expressions in the print-list can be constants and/or variables.

The options available with the DISPLAY instruction make it more versatile for screen output than in the PRINT instruction. You can display data at any screen position, sound a tone when data items are displayed, clear the screen or a portion of the display row before displaying data, and accentuate displayed data by using the INVERT/BLINK option.

You can use DISPLAY as either a program statement or a command.

The print-list consists of one or more print-items (items to be displayed on the screen) separated by print-separators. See PRINT for an explanation of the print-items and print-separators that make up a print-list.

## Options

You can enter the following options, separated by a space, in any order.

**AT--**The AT option enables you to specify the beginning of the display field. Row and column are relative to the upper-left corner of the screen window defined by the margins. If you do not use the AT option, the display field begins in the far left column of the bottom row of the current screen window. Before a new line is displayed at the bottom of the window, the entire contents of the window(excluding sprites) scroll up one line to make room for the new line. The contents of the top line of the window scroll off the screen and are discarded. If you use the AT option and your print-list includes a TAB function, the TAB location is relative to the beginning of the display field. If you use the AT option and a print-item is too long to fit in the display field, either the extra characters are discarded (if you use the SIZE option) or the print-item is moved to the beginning of the next screen line (if you do not use the SIZE option).

**BEEP--**The BEEP option sounds a short tone when the data items are displayed.

ERASE ALL--The ERASE ALL option places a space character (ASCII code 32) in every character position in the screen window before displaying the data.

SIZE--The SIZE option is a numeric-expression whose value specifies the number of character positions to be cleared, starting from the beginning of the display field, before the data is displayed. If the numeric-expression is greater than the number of characters remaining in the row (from the beginning of the display field to the right margin), or if you do not use the SIZE option, the display row is cleared from the beginning of the display field to the right margin.

#### New Options

CLIP--Using the CLIP option, the string represented in the "DISPLAY AT" statement will be clipped at the end of a line rather than wrapping around to the next line, as it does in the default mode. The CLIP option is particularly useful when using "DISPLAY AT" within a window.

BLINK/INVERT--BLINK will cause the line displayed to BLINK on and off. This is only available in GRAPHICS(3,1) mode.

INVERT--will cause the pixels in each character to invert their colors so the foreground- and background-colors will be inverted. This is only available in GRAPHICS(2,2), (2,3), (3,2), (3,3) modes.

#### Examples

```
100 DISPLAY AT(5,7):Y
```

Displays the value of Y at the fifth row, seventh column of the screen. It first clears row 5 from column 7 to the right margin.

```
100 DISPLAY ERASE ALL:B
```

Puts the blank character into all positions within the current screen window before displaying the value of B.

```
100 DISPLAY AT(R,C) SIZE(FIELDLEN)BEEP:X$
```

Displays the value of X\$ at row R, column C. First it beeps and blanks FIELDLEN characters.

#### Program

The following program illustrates a use of DISPLAY. It enables you to position blocks at any screen position to draw a figure or design.

Numbers must be entered as two digits (e.g., 1 would be "01", etc.). Do not press ENTER; the information is accepted as soon as the keys are pressed.

This example is valid only in GRAPHICS(1,1).

```
100 CALL CLEAR
110 CALL COLOR(27,5,5)
120 DISPLAY AT(23,1):"ENTER ROW AND COLUMN:"
130 DISPLAY AT (24,1):"ROW: COLUMN:"
140 FOR COUNT=1 TO 2
150 CALL KEY(0,ROW(COUNT),S)
160 IF S =0 THEN 150
170 DISPLAY AT(24,5+COUNT)SIZE(1):STR$(ROW(COUNT)-48)
180 NEXT COUNT
190 FOR COUNT=1 TO 2
200 CALL KEY(0,COLUMN(COUNT),S)
210 IF S =0 THEN 200
220 DISPLAY AT(24,16+COUNT)SIZE(1):STR$(COLUMN(COUNT)-48)
230 NEXT COUNT
240 ROW1=10*(ROW(1)-48)+ROW(2)-48
250 COLUMN1=10*(COLUMN(1)-48)+COLUMN(2)-48
260 DISPLAY AT(ROW1,COLUMN1)SIZE(1):CHR$(244)
270 GOTO 130
(Press CLEAR to stop the program.)
```

**DISPLAY USING****DISPLAY USING**

## Format

DISPLAY [option-list:]USING ;format-string[:print-list]; line-number;

## Cross Reference

DISPLAY, IMAGE, PRINT

## Description

The DISPLAY USING instruction enables you to define specific formats for numbers and strings you display.

You can use DISPLAY USING as either a program statement or a command.

The format-string specifies the display format. The format-string is a string expression; if you use a string constant, you must enclose it in quotation marks. See IMAGE for an explanation of format-strings.

You can optionally define a format-string in an IMAGE statement, as specified by the line-number.

See DISPLAY under "Options" for an explanation of the options AT, BEEP, ERASE ALL, and SIZE.

See PRINT for an explanation of the print-list and print-options.

The DISPLAY USING instruction is identical to the DISPLAY instruction with the addition of the USING option, except that:

You cannot use the TAB function.

You cannot use any print-separator other than a comma(,), except that the print-list can end with a semicolon (;).

## Examples

```
100 N=23.43
```

```
110 DISPLAY AT(10,4):USING"##.##":N
```

Displays the value of N at the tenth row and fourth column, with the format "##.##", after first clearing row 10 from column 4 to the right margin.

```
100 DISPLAY USING "##.##":N
```

Displays the value of N at the 24th row and first column, with the format "##.##".

## DISTANCE

## DISTANCE

### Format

#### Two Sprites

CALL DISTANCE(#sprite-number1,#sprite-number2,numeric-variable)

#### A Sprite and a Screen Pixel

CALL DISTANCE (#sprite-number,pixel -row, pixel -column ,numeric-variable)

### Cross Reference

COINC, SPRITE

### Description

The DISTANCE command enables you to ascertain the distance between two sprites or between a sprite and a specified screen pixel.

The DISTANCE command returns the square of the distance sought. (Note that this is not the same as the distance specified by the "tolerance" in the COINC command.)

The square of the distance is the sum of the square of the difference between pixel-rows and the square of the difference between pixel-columns. The distance between the two sprites (or the sprite and the screen pixel) is the square root of the number returned.

If the square of the distance is greater than 32767, the number returned is 32767.

#### Two Sprites

The distance between two sprites is considered to be the distance between the upper-left corners of the sprites.

Sprite-number1 and sprite-number2 are numeric-expressions whose values specify the numbers of the two sprites as assigned in the SPRITE command.

The number returned to the numeric-variable equals the square of the distance between two sprites.

#### A Sprite and a Screen Pixel

The distance between a sprite and a screen pixel is considered to be the distance between the upper-left corner of the sprite and the specified pixel.

Sprite-number is a numeric-expression whose value specifies the number of the sprite as assigned in the SPRITE command.

The pixel-row and pixel-column are numeric-expressions whose values specify the position of the screen pixel.

The number returned to the numeric-variable equals the square of the distance between the sprite and the screen pixel.

### Examples

```
100 CALL DISTANCE(#3,#4,DIST)
```

Sets DIST equal to the square of the distance between the upper-left corners of sprite #3 and sprite #4.

```
100 CALL DISTANCE(#4,18,89,D)
```

Sets D equal to the square of the distance between the upper-left corner of sprite #4 and position 18,89.

**DRAW****DRAW**

## Format

```
CALL DRAW(line-type,pixel-row1,pixel-column1,pixel-row2,pixel-column2
[,pixel-row3,pixel-column3,pixel-row4,pixel-column4[,...]])
```

## Cross Reference

CIRCLE, DCOLOR, DRAWTO, FILL, GRAPHICS, POINT, RECTANGLE

## Description

The DRAW command enables you to draw or erase lines between specified pixels.

The value of the numeric-expression line-type specifies the action taken by the DRAW command.

TYPE	ACTION
2	Reverses the status of each pixel on a line. Note: results may be unpredictable.
1	Draws a line of the foreground-color specified by the DCOLOR command. This is accomplished by turning on each pixel in the specified line.
0	Erases a line. This is accomplished by turning off each pixel in the specified line created with DCOLOR.

Pixel-row and pixel-column are numeric-expressions whose values specify the pixels to be connected by the line. You must specify at least two pixels to define the beginning and end points of a line.

You can optionally draw more lines by specifying additional pairs of pixels. The lines are not connected; each line extends from the first pixel of the pair to the second pixel of the pair. You must specify an even number of pixels.

The last pixel you specify becomes the current position used by the DRAWTO command.

DRAW cannot be used in GRAPHICS(1,1), (2,1) or (3,1).

In GRAPHICS(1,2) and (1,3) modes, the computer divides each pixel-row into 32 groups of 8 pixels each. (This is most obvious when you assign a background-color other than cyan or transparent.) The computer can assign 1 foreground-color and 1 background-color, from among the 16 available colors, to each 8-pixel group.

In the GRAPHICS(2,2),(2,3),(3,2) and (3,3) each pixel is independent of every other pixel on the screen.

### Programs

The following program draws a large triangle on the right of the screen.

```
100 CALL GRAPHICS(3,2)
110 CALL DCOLOR(16,2)
120 CALL DRAW(1,19,185,97,115,19,185,97,255)
140 CALL DRAW(1,97,115,97,255)
150 GOTO 150
```

(Press CLEAR to stop the program.)

The next program uses a FOR-NEXT loop to draw a pattern of lines.

```
100 CALL GRAPHICS(3,3)
110 CALL SCREEN(2)
120 CALL TCOLOR(16,2)::CALL DCOLOR(16,2)
130 FOR X=1 TO 255 STEP 5
140 CALL DRAW(1,1,X,128,256-X)
150 NEXT X
160 GOTO 160
```

(Press CLEAR to stop the program.)

**DRAWTO****DRAWTO**

Format

CALL

DRAWTO(line-type,pixel-row,pixel-column[,pixel-row2,pixel-column2[,...]])

Cross Reference

CIRCLE, DCOLOR, DRAW, FILL, GRAPHICS, POINT, RECTANGLE

Description

The DRAWTO command enables you to draw or erase lines between the current position and the specified pixels.

Line-type is a numeric-expression whose value specifies the action taken by the DRAWTO command.

TYPE	ACTION
2	Reverses the status of each pixel of a line. Note: results may be unpredictable.
1	Draws a line of the foreground-color specified by the DCOLOR command. This is accomplished by turning on each pixel in the specified line.
0	Erases a line. This is accomplished by turning off each pixel in the specified line.

The line drawn by DRAWTO extends from the pixel in the current position set by PSET, DRAW or a previous DRAWTO to the pixel specified by the values of the numeric-expressions pixel-row and pixel-column. You can optionally draw more lines by specifying additional sets of pixels. The default position of the pixel is (1,1). DRAWTO cannot be used in GRAPHICS(1,1), (2,1) OR (3,1).

In Graphics(1,2) and (1,3) modes, the computer divides each pixel-row into 32 groups of 8 pixels with each 8 pixel row taking on only 1 foreground and 1 background color.

The following program creates a pattern across the top of the screen.

```

100 CALL GRAPHICS(1,2)
110 CALL CLEAR
120 A=20::B=20
130 CALL DRAW(1,A,B,A,B)
140 FOR X=1 TO 10
150 B=B+20
160 CALL DRAWTO(1,A,B)
170 CALL DRAWTO(1,A+20,B-20)
180 CALL DRAWTO(1,A+20,B)
190 CALL DRAWTO(1,A,B-20)
200 NEXT X
210 GOTO 210
(Press CLEAR to stop the program.)

```

**ECOLOR****ECOLOR**

## Format

CALL ECOLOR(color)

## Cross reference

TCOLOR

## Description

CALL ECOLOR(color) is used to "color in" the edge between the text and the border in Graphics modes (2,2), (2,3), (3,2), (3,3).

Note: This command is most useful in GRAPHICS(3,3).

## Example

CALL ECOLOR(10) This would "color in" the edge as Light Red.

## Program

```
100 CALL GRAPHICS(3,3)
110 CALL TCOLOR(4,14)
120 CALL ECOLOR(14)
130 CALL DCOLOR(4,14)
140 DISPLAY ERASE ALL
150 PRINT "EDWIN ABBOT-FLATLAND"
```

Line 100 sets graphics mode to (3,3).

Line 110 would set the text area for characters as foreground-color of Light Green and background-color to Magenta.

Line 120 colors in the edge of the text (not border) with Magenta.

Line 130 Set the color of the screen to Green on Magenta.

Line 140 would PRINT the screen with ASCII 32(blank character) in the background-color of Magenta (a type of screen clear).

Line 150 Prints "EDWIN ABBOT-FLATLAND" with Green text and Magenta background

## END

## END

Format  
END

Cross Reference  
STOP

### Description

The END statement stops the execution of your program.

In addition to terminating program execution, END causes the computer to perform the following operations:

- It closes all open files.

- It restores the default character definitions of all characters.

- It restores the default foreground color and background color to all characters in the Graphic mode selected unless you have used TCOLOR or PALETTE in those modes where they are allowed.

- It restores the default screen color if you have not changed the screen color in those modes where they are allowed.

- It deletes all sprites.

- It resets the sprite magnification level to 1.

The graphic colors (see DCOLOR) and current position (see DRAWTO) are not affected.

An END statement is not necessary to stop your program; the program automatically stops after the highest line is executed.

END can be used interchangeably with the STOP statement, except that you cannot use STOP after a command.

## EOF

EOF

## Format

EOF(file-number)

## Type

DEFINT

## Cross Reference

ON ERROR

## Description

The EOF function returns a value indicating whether there are records remaining in a specified file.

The file-number is a numeric expression whose value specifies the number of the file as assigned in its OPEN instruction.

The value returned by the EOF function depends on the current file position. EOF always treats a file as if it were being accessed sequentially, even if it has been opened for relative access.

VALUE	MEANING
0	Not end-of-file.
(+)1	Logical end-of-file: No records remaining.
-1 no space	Physical end-of-file: No records remaining, and available for more records (storage medium full).

The EOF function cannot be used with an audio cassette.

For more information about using EOF with a particular device, refer to the owner's manual that comes with that device.

## Examples

```
100 PRINT EOF(3)
```

Prints a value according to whether you are at the end of the file opened as #3.

```
100 IF EOF(27)<>0 THEN 1150
```

Transfers control to line 1150 if you are at the end of the file opened as #27.

```
100 IF EOF(27) THEN 1150
```

Transfers control to line 1150 if you are at the end of the file opened as #27.

## ERR

## ERR

### Format

CALL ERR(error-code,error-type[,error-severity,[line-number]])

### Cross Reference

ON ERROR

### Description

The ERR command enables you to analyze the conditions that caused a program error.

ERR is normally called from a subroutine accessed by an ON ERROR statement.

The ERR command returns the error-code and error-type, and optionally the error-severity and line-number, of the most recent "uncleared" program error.

An error is "cleared" when another program error occurs or when the program ends. A RETURN statement in a subroutine accessed by an ON ERROR statement also clears the error.

ON ERROR will not trap an error caused by the RUN command.

ERR returns a two- or three-digit number to the numeric variable error-code. See Appendix J for a list of error codes and the conditions that cause them to be displayed.

An error-code of 130- indicates an input/output (I/O) error.

An error-code of 0 indicates that no error has occurred.

The error-type is a numeric variable.

When an I/O error occurs, the value returned in error-type is the number (as assigned in an OPEN instruction) of the file in which the error occurred.

A negative error-type indicates that the error occurred during program execution.

An error-type of 0 indicates that no error has occurred. Options

The value returned to the numeric variable error-severity is always nine.

The value returned to the numeric variable line-number is the line number of the program statement that was executing when the error occurred.

### Examples

```
100 CALL ERR(A,B)
```

Sets A equal to the error-code and B equal to the error-type of the most recent error.

```
100 CALL ERR(W,X,Y,Z)
```

Sets W equal to the error-code, X equal to the error-type, Y equal to the error-severity, and Z equal to the line-number of the most recent error.

### Program

The following program illustrates a use of CALL ERR.

```
100 ON ERROR 130
110 CALL SCREEN(18)
120 STOP
130 CALL ERR(W,X,Y,Z)
140 PRINT W;X;Y;Z
150 RETURN NEXT
RUN
79 -1 9 110
```

An error is caused in line 110 by an improper screen-color number. Because of line 100, control is transferred to line 130. Line 140 prints the values obtained. The 79 indicates that a bad value was provided, the -1 indicates that the error occurred during program execution, the 9 is the error-severity, and the 110 indicates that the error occurred in line 110.

## EXP

## EXP

### Format

EXP(numeric-expression)

### Type

REAL

### Cross Reference

LOG

### Description

The EXP function returns the value of e raised to the power of the value of the numeric-expression.

EXP is the inverse of the LOG function.

The value of e is 2.718281828459.

### Examples

```
100 Y=EXP(7)
```

Assigns to Y the value of e raised to the seventh power, which yields 1096.6331584290.

```
100 L=EXP(4.394960467)
```

Assigns to L the value of e raised to the 4.394960467 power, which yields 81.0414268887.

**FILES****FILES**

## Format

CALL FILES(pathname)

## Cross Reference

DOS Manual, Pathnames, Directories, OPEN, CLOSE, KILL, KEY LIST, CHDIR

## Description

You can use CALL FILES either as a program statement or a command.

Displays the names of the files and directories on a disk. If pathname is specified, BASIC lists all files that match that pathname. Default is all files and directories in the current directory on the current drive.

To halt list, depress any key. To continue the listing, press another or the same key. This only works in command mode.

## Examples

## CALL FILES

Displays files of the default drive. (see KEY LIST, PWD, CHDIR)

CALL FILES("DSK1.")

Displays files in drive 1.

CALL FILES("HDS1.")

Displays files on Hard Drive #1.

CALL FILES("DSK.UTILITIES.")

Searches all drives for the disk named "UTILITIES" and displays files.

CALL FILES(DSK1.SUBDIR3.)

Displays files of "SUBDIR3" . The maximum sub-directories for floppies is three.

CALL FILES(HDS1.SUBDIR1.SUBDIR2.)

Displays files of "SUBDIR2" which is a sub-directory of "SUBDIR1"

NOTE: DO NOT USE with a window less than 28 characters wide.

## FILL

## FILL

### Format

CALL FILL(pixel-row,pixel-column)

### Cross Reference

CIRCLE, DCOLOR, DRAW, DRAWTO, GRAPHICS, POINT, RECTANGLE

### Description

The FILL command enables you to fill in the area surrounding a specified pixel with a specified color.

Pixel-row and pixel-column are numeric-expressions whose values specify the center pixel that you want to surround with a color. The color of the FILL is the foreground-color specified by the DCOLOR command. the default fill color is light green.

The area surrounding the specified pixel is filled with the fill color until a screen edge or a foreground pixel (a pixel that is turned on) is encountered.

The boundaries of the area to be filled can be defined by lines drawn with CIRCLE, DRAW, DRAWTO, POINT and RECTANGLE.

FILL cannot be used in GRAPHICS(1,1),(2,1) OR (3,1).

FILL is faster with the GRAPHICS(2,x) and (3,x) modes than in GRAPHICS(1,x) modes.

Program example on next page.

## Program

The following program divides the upper portion of the screen into four horizontal columns and uses FILL to color them.

```
100 CALL CLEAR
110 CALL GRAPHICS(3,3)
120 CALL DRAW(1,48,1,48,512)
130 CALL DRAW(1,96,1,96,512)
140 CALL DRAW(1,144,1,144,512)
150 CALL DCOLOR(7,8)
160 CALL FILL(43,1)
170 CALL DCOLOR(11,8)
180 CALL FILL(90,1)
190 CALL DCOLOR(3,8)
200 CALL FILL(138,1)
210 CALL DCOLOR(2,8)
220 CALL FILL(188,1)
230 GOTO 230
(Press CLEAR to stop the program.)
```

## FOR TO

## FOR TO

### Format

FOR control-variable=initial-value TO limit[STEP increment]

### Cross Reference

NEXT

### Description

The FOR TO instruction is used with the NEXT instruction to form a FOR-NEXT loop, which you can use to control a repetitive process.

You can use FOR TO as either a program statement or a

command. FOR-NEXT Loop Execution

When a FOR TO instruction is executed, the initial-value is assigned to the control-variable. The computer executes instructions until it encounters a NEXT instruction (the group of instructions between the FOR TO and NEXT instructions are known as a "FOR-NEXT loop"). However, if the initial-value is greater than the limit (or, if you specify a negative increment, if the initial-value is less than the limit) the FOR-NEXT loop is not executed.

When the NEXT instruction is encountered, the increment is added to the control-variable; if you do not specify an increment, the control-variable is incremented by 1. Note that if the increment is negative, the value of the control-variable is decreased.

The control-variable in the NEXT instruction must be the same as the control-variable in the FOR TO instruction. The new value of the control-variable is then compared to the limit. If you specify a positive increment (or if you do not specify an increment), the FOR-NEXT loop is repeated if the control-variable is less than or equal to the limit. If you specify a negative increment, the FOR-NEXT loop is repeated if the control-variable is greater than or equal to the limit.

If the condition for repeating the FOR-NEXT loop is met, control passes to the instruction immediately following the FOR TO instruction. If the condition is not met, the FOR-NEXT loop terminates (control passes to the statement immediately following the NEXT statement).

### Specifications

The value of the numeric-expression control-variable is re-evaluated each time the NEXT instruction is executed. If you change its value while a FOR-NEXT loop is executing, you may affect the number of times the loop is repeated. A FOR-NEXT loop executes much faster if the control-variable has been declared as a DEFINT than it does if the control-variable is REAL.

The control-variable cannot be an element of an array.

The initial-value is a numeric-expression.

The value of the numeric-expression limit is not re-evaluated during the execution of a FOR-NEXT loop. If you change its value while a FOR-NEXT loop is executing, you do not affect the number of times the loop is repeated.

The value of the optional numeric-expression increment is not re-evaluated during the execution of a FOR-NEXT loop. If you change its value while a FOR-NEXT loop is executing, you do not affect the number of times the loop is repeated. The increment cannot be zero.

#### Nested FOR-NEXT Loops

FOR-NEXT loops may be "nested"; that is, one FOR-NEXT loop may be contained wholly within another. You must observe the following conventions:

Each FOR TO instruction must be paired with a NEXT instruction.

Each nested loop must use a different control-variable.

If a FOR-NEXT loop contains any portion of another FOR-NEXT loop, it must contain all of that FOR-NEXT loop. If a FOR-NEXT loop contains only part of another FOR-NEXT loop, an error occurs, and the message NEXT without FOR is displayed. If the FOR-NEXT loop is part of a program, the computer also displays the line-number where the error occurred.

#### FOR TO as a Program Statement

After you enter the RUN command, but before your program is actually run, the computer verifies that you have equal numbers of FOR TO and NEXT statements. If the numbers are not equal, the message FOR-NEXT nesting is displayed and the program is not run.

You can exit a FOR-NEXT loop by using a GOTO, ON GOTO, or IF THEN statement. If you use one of these statements to enter a loop, you could cause an error or create an infinite loop.

A FOR TO statement cannot be part of an IF THEN statement.

#### FOR TO as a Command

If you use FOR TO as a command, it must be part of a multiple-statement line. A NEXT instruction must also be part of the same line.

After you press ENTER to execute the command, but before the command is actually executed, the computer verifies that you have equal numbers of FOR TO and NEXT instructions. If the numbers are not equal, the message FOR-NEXT nesting is displayed and the command is not executed.

### Examples

```
100 FOR A=1 TO 5 STEP 2
110 PRINT A
120 NEXT A
```

Executes the statements between this FOR and NEXT A three times, with A having values of 1, 3, and 5.

```
100 FOR J=7 TO -5 STEP -.5
110 PRINT J
120 NEXT J
```

Executes the statements between this FOR and NEXT J 25 times, with J having values of 7, 6.5, 6, ..., -4, -4.5, and -5.

### Program

The following program illustrates a use of the FOR-TO-STEP statement. There are three FOR-NEXT loops, with control-variables of CHAR, ROW, and COLUMN.

```
100 CALL CLEAR
110 O=0
120 FOR CHAR=33 TO 63 STEP 30
130 FOR ROW=1+D TO 21+0 STEP 4
140 FOR COLUMN=1+D TO 29+D STEP 4
150 CALL VCHAR(ROW,COLUMN,CHAR)
160 NEXT COLUMN
170 NEXT ROW
180 D=2
190 NEXT CHAR
200 GOTO 200
```

(Press CLEAR to stop the program.)

**FREESPACE****FREESPACE****Format**

FREESPACE(memory-type)

**Type**

REAL

**Description**

The FREESPACE function returns a number representing, in bytes, the amount of memory space available for Geneve 9640 Advanced BASIC programs and data.

The following are the memory-types:

- 0 ALL memory
- 1 program space
- 2 data space
- 3 assembly space
- 4 stack space

**Garbage Collection**

Before FREESPACE returns a value, the computer executes an activity called "garbage collection".

All "inactive" strings are deleted. Strings become inactive when they are not associated with a variable. A string may be created by the computer for its internal use; it becomes inactive when no longer needed.

All "active" strings (strings that are still associated with variables) are moved to a contiguous area at the low end of memory. This leaves all available memory in one large, contiguous block.

The computer occasionally performs garbage collection by itself, i.e. when no memory is available because of an excess number and size of inactive strings.

NOTE: Stack space has a defined value of 3968 bytes. (>E000->EF80)

**Examples**

```
PRINT FREESPACE(0)
```

Prints a value that indicates the amount of available memory.

Note: always put a PRINT in front of FREESPACE or you will get a syntax error.

```
10 A=FREESPACE(2)
```

```
20 PRINT A
```

Can be used with a variable in a program.

Note: this replaces the SIZE command from TIXB.

## GCHAR & GPOINT

## GCHAR & GPOINT

### Format

```
GRAPHICS(1,1),(2,1),(3,1)
      CALL GCHAR(row,column,numeric-variable)
GRAPHICS(1,2),(1,3),(2,2),(2,3),(3,2),(3,3)
      CALL GPOINT(pixel-row,pixel-column,numeric-variable color value)
```

### Cross Reference

GRAPHICS,HCHAR,VCHAR,DRAW

### Description

The GCHAR command enables you to ascertain the character code of a character on the screen or the color value of a screen pixel.

The meaning of the value returned to the specified numeric-variable varies according to the graphics mode.

### **GRAPHICS(1,1),(2,1) &(3,1)**

Row and column are numeric-expressions whose values specify a character position on the screen.

GCHAR is not affected by margin settings. Row and column are relative to the upper-left corner of the screen, not to the corner of the window defined by the margins.

The character code of the character at the specified position is returned to the numeric-variable. See Appendix B for a list of ASCII character codes.

The character of the specified location is given by the value returned to the numeric-variable.

```
CALL GRAPHICS(1,1)
CALL GCHAR(12,12,X)
```

X will be the character value of GCHAR.

### **GRAPHICS(1,2),(1,3),(2,2),(2,3),(3,2) & (3,3)**

The pixel-row and pixel-column are numeric-expressions whose values specify a screen pixel position.

The color of the specified screen pixel is given by the value returned to the numeric-variable.

```
CALL GRAPHICS(3,3)
CALL GPOINT(106,256,X)
```

X will be the color value of GPOINT.

### Examples

```
100 CALL GRAPHICS(1,1)
200 DISPLAY AT(12,16):"FOUNDATION"
300 CALL GCHAR(12,16,X)
```

Assigns to X the single ASCII value of the character at row 12, column 16.

```
100 CALL GRAPHICS(3,3)
200 CALL DRAW(1,10,10,90,90)
300 CALL GPOINT(10,10,X)
```

Assigns to X the color value of the line at row 10, column 10.

## GOSUB

## GOSUB

### Format

GOSUB line-number

GO SUB

### Cross Reference

ON GOSUB, RETURN

### Description

The GOSUB statement transfers program control to the specified subroutine. A subroutine frequently is used to perform a specific operation several times in the same program.

The line-number is a numeric-expression whose value specifies the program statement at which the subroutine begins.

Use a RETURN statement to return program control to the statement immediately following the GOSUB statement that called the subroutine.

To avoid unexpected results, it is recommended that you exercise care if you use GOSUB to transfer control to or from a command or into a FOR- NEXT loop.

Subroutines may be recursive (self-referencing). To avoid constructing infinite loops, it is recommended that you exercise care when using recursive subroutines.

### Nested Subroutines

Subroutines may be "nested"; that is, within a subroutine you can use GOSUB to transfer control to another subroutine. Because RETURN restores program control to the statement immediately following the most recently executed GOSUB, it is important to exercise care when using nested subroutines.

For example, you might use GOSUB in your main program to transfer control to a subroutine. When the computer encounters a RETURN in the second subroutine the GOSUB in the first subroutine. Then, when a RETURN is encountered in the first subroutine, program control returns to the statement following the GOSUB in your main program.

### Example

100 GOSUB 200

Transfers control to statement 200. That statement and the ones up to RETURN are executed and then control returns to the statement after the calling statement.

## Program

The following program illustrates a use of GOSUB. The subroutine at line 260 figures the factorial of the value of NUMB.

```
100 CALL CLEAR
110 INPUT "ENTER X AND Y: ":X,Y
120 IF X<Y THEN 110
130 IF X>69 OR Y>69 THEN 110
140 IF X<0 THEN PRINT "NEGATIVE":GOTO 110 ELSE NUMB=X
150 GOSUB 260
160 NUMERATOR=NUMB
170 IF Y<0 THEN PRINT "NEGATIVE":GOTO 110 ELSE NUMB=Y
180 GOSUB 260
190 DENOMINATOR=NUMB
200 NUMB=X-Y
210 GOSUB 260
220 DENOMINATOR=DENOMINATOR*NUMB
230 NUMB=NUMERATOR/DENOMINATOR
240 PRINT "NUMBER IS";NUMB
250 STOP
260 REM CALCULATE FACTORIAL
270 IF NUMB<2 THEN NUMB=1::GOTO 320
280 MULT=NUMB-1
290 NUMB=NUMB*MULT
300 MULT=MULT-1
310 IF MULT>1 THEN 290
320 RETURN
```

## GOTO

## GOTO

### Format

GOTO line-number

GO TO

### Cross Reference

ON GOTO

### Description

The GOTO statement unconditionally transfers program control to the specified program statement.

The line-number is a numeric-expression whose value specifies the program statement to which unconditional program control is transferred.

To avoid unexpected results, it is recommended that you exercise care if you use GOTO to transfer control to or from a subroutine or into a FOR-NEXT loop.

### Program

The following program shows the use of GOTO in line 160. Any time that line is reached, the program executes line 130 next and proceeds from that new point.

```
100 REM ADD 1 THROUGH 100
110 ANSWER=0
120 NUMB=1
130 ANSWER=ANSWER+NUMB
140 NUMB=NUMB+1
150 IF NUMB>100 THEN 170
160 GOTO 130
170 PRINT "THE ANSWER IS";ANSWER
RUN
THE ANSWER IS 5050
```

**GRAPHICS****GRAPHICS**

## Format

CALL GRAPHICS(graphics-mode1,graphics mode2)

## Cross Reference

CHAR,CIRCLE,COLOR,DCOLOR,DRAW,DRAWTO,FILL,MARGINS,POINT,RECTANGLE,SCREEN

## Description

The CALL GRAPHICS command selects the default graphic capabilities for a program or sub-program.

When CALL GRAPHICS is executed it clear the screen, restores the default characters and colors, resets all sprites, clears MARGINS and turns off all sound.

**THE GRAPHIC MODES:**

## CALL GRAPHICS(1,1)

This is the standard TI99 32 column Pattern Mode with a slightly altered character set. Refer to the TI99 BASIC programmers manual of the TI99 Extended BASIC manual for more detail. DCOLOR, CIRCLE, DRAW, DRAWTO, FILL, POINT, or RECTANGLE **can not** be used in this mode.

## CALL GRAPHICS(1,2)

This is the TI99 bitmap mode. In this mode text color is not assigned to a specific character set but can be changed on the fly with TCOLOR. VCHAR & HCHAR operates the same as (1,1). COLOR can not be used. Resolution is 256 wide by 192 high. On screen colors are limited by TI99 bitmap limitations of every 8 pixels in a row only having 1 fore and 1 back ground color. Sprites are limited to visual of 4 sprites per line. DCOLOR, CIRCLE, DRAW, DRAWTO, FILL, POINT, or RECTANGLE **can** be used in this mode.

## CALL GRAPHICS(1,3)

This is same as (1,2) except allows for 8 visual sprites per line.

## CALL GRAPHICS(2,1)

This is the TI99 40 column text mode. Only one fore and back ground color can be used. You use TCOLOR to assign fore and back ground color for the text. You can not use sprites. COLOR, DCOLOR, CIRCLE, DRAW, DRAWTO, FILL, POINT, or RECTANGLE **can not** be used in this mode.

## CALL GRAPHICS(2,2)

This is a 256x192, 16 color pixel mode. Each pixel is addressable with color via DCOLOR. Text operates like the bitmap mode (1,2) with use of TCOLOR. Sprites are usable and are the 8 visible sprites per line. DCOLOR, CIRCLE, DRAW, DRAWTO, FILL, POINT, or RECTANGLE **can** be used in this mode.

## CALL GRAPHICS(2,3)

This is the 256x192, 256 color pixel mode. Only 16 colors seem to be available and the colors are non-standard and difficult to change. This mode is limited in it's usefulness in ABASIC.

## CALL GRAPHICS(3,1)

This is the 80 column text mode. Color usage and graphic limitations are the same as (2,1). This is also the default graphics mode for ABASIC.

## CALL GRAPHICS(3,2)

This is a 512x192, 4 color pixel mode. Colors in this mode are non-standard and difficult to change. This mode is limited in it's usefulness in ABASIC.

CALL GRAPHICS(3,3)

This is a 512x192, 16 color pixel mode with each pixel addressable via DCOLOR. Text operates like the bitmap mode (1,2) with use of TCOLOR. Sprites are usable and are the 8 visible sprites per line. DCOLOR, CIRCLE, DRAW, DRAWTO, FILL, POINT, or RECTANGLE can be used in this mode.

#### SUMMARY OF THE GRAPHIC MODES:

(1,1) - 32x24, TI99 pattern, 16 color, 4 sprite/line  
(1,2) - 256x192, TI99 bitmap, 16 color, 4 sprite/line  
(1,3) - 256x192, TI99 bitmap, 16 color, 8 sprite/line  
  
(2,1) - 40x24, TI99 40 text, 2 color, no sprites  
(2,2) - 256x192, pixel, 16 color, 8 sprite/line  
(2,3) - 256x192, pixel, 256 color, 8 sprite/line -limited usefulness  
  
(3,1) - 80x24, text, 2 color, no sprites  
(3,2) - 512x192, pixel, 4 color, 8 sprite/line -limited usefulness  
(3,3) - 512x192, pixel, 16 color, 8 sprite/line

In order to maintain compatibility with MYARC Extended BASIC II, CALL GRAPHICS(1)=(1,1), (2)=(2,1) and (3)=(1,2).

#### Examples

```
10 REM LINES
20 CALL GRAPHICS(3,1) :: CALL TCOLOR(16,2)
30 REM 1ST SET SCREEN COLOR IN (3,1) BEFORE SETTING GRAPHICS(3,3)
32 RANDOMIZE :: Z=RND*13+2
35 CALL GRAPHICS(3,3) :: CALL DCOLOR(Z,2) :: CALL CLEAR
40 X1=RND*89+29 :: X2=RND*99+29 :: Y1=RND*68+29 :: Y2=RND*70+29
50 A=2..1 :: B=-5..2 :: C=-4..3 :: D=3..4
110 CALL DRAW(1,Y1,X1,Y2,X2)
130 X1=X1+A :: Y1=Y1-B :: X2=X2-C :: Y2=Y2+D
150 IF Y1<29 OR Y1>170 THEN B=-B
155 IF Y2<29 OR Y2>170 THEN D=-D
160 IF X1<29 OR X1>437 THEN A=-A
165 IF X2<29 OR X2>437 THEN C=-C
167 IF RND>..85 THEN Z=RND*13+3 :: CALL DCOLOR(Z,2)
170 T=T+1 :: IF T>140 THEN CALL CLEAR :: T=0 ELSE 1200
1200 GOTO 110
```

```
10 REM HILL-GRAPH
12 DIM M(255)
15 CALL GRAPHICS(2,2)
18 CALL DCOLOR(15,2)
30 A=COS(PI/4)
40 FOR Y=1 TO 141 STEP 5
50 E=A*Y :: C=Y-70 :: C=C*C
80 FOR X=1 TO 141
90 D=X-70 :: Z=80*EXP(-0..001*(C+D*D)) :: X1=X+E :: Y1=Z+E
130 IF Y1>M(X1) THEN M(X1)=Y1 :: CALL POINT(1,ABS(Y1-141),X1)
140 NEXT X :: NEXT Y
150 DISPLAY AT(23,24):"DONE"
160 GOTO 160
```

```

10 REM MULTICOLOR FONT
20 CALL GRAPHICS(1,2)
25 CALL SCREEN(2)
30 RANDOMIZE
40 FOR I=1 TO 255
50 CALL TCOLOR(I,RND*14+1)
60 PRINT CHR$(I);
70 NEXT I

```

```

10 REM SADDLEBACK
20 RANDOMIZE
30 CALL GRAPHICS(3,1) :: CALL BCOLOR(5,2)
40 CALL DCOLOR(16,2)
50 DIM A(16,16),B(16,16),C(16,16)
180 Y1=-060 :: X=-194 :: KH=5 :: KV=5 :: L=0..9 :: U=5 :: V=15 :: R=0 ::
E=-210
190 Y=Y1
195 PRINT "creating graphic"
200 FOR J=0 TO 15
210 FOR I=0 TO 15
220 A(I,J)=X
230 B(I,J)=Y
240 C(I,J)=R
250 Y=Y+12 :: NEXT I
260 Y=Y1 :: X=X+12 :: NEXT J
270 A1=1 :: B1=1..19
280 FOR J=0 TO 15
290 FOR I=0 TO 15
300 W=(I-U)*(I-U)/A1/A1-(J-V)*(J-V)/B1/B1
310 C(I,J)=C(I,J)-W/2-E
320 IF C(I,J)<R THEN C(I,J)=R
325 PRINT "...";
330 NEXT I :: NEXT J
340 FOR J=0 TO 15
350 FOR I=0 TO 15
360 A(I,J)=A(I,J)+C(I,J)*L
370 B(I,J)=B(I,J)+C(I,J)*L
375 PRINT "...";
380 NEXT I :: NEXT J
390 REM Beginning of the drawing program
400 REM Graphic initialization and slides of the screens
410 CALL CLEAR :: CALL GRAPHICS(3,3)
420 FOR J=0 TO 14
430 FOR I=0 TO 14
440 CALL POINT(1,A(I,J),B(I,J)) :: CALL DRAWTO(1,A(I+1,J),B(I+1,J))
450 CALL DRAWTO(1,A(I+1,J+1),B(I+1,J+1)) :: CALL POINT(1,A(I,J),B(I,J))
460 CALL DRAWTO(1,A(I,J+1),B(I,J+1))
470 CALL DRAWTO(1,A(I+1,J+1),B(I+1,J+1))

```

**HCHAR****HCHAR**

## Format

CALL HCHAR(row,column,character-code[,number of repetitions])

## Cross Reference

DCOLOR, GCHAR, GRAPHICS, VCHAR

## Description

The HCHAR command enables you to place a character on the screen and repeat it horizontally.

Row and column are numeric-expressions whose values specify the position on the screen where the character is displayed.

The value of row must be greater than or equal to 1, and must be less than or equal to the total number of rows available on the screen. The value of column must be greater than or equal to 1 and must be less than or equal to the total number of columns available on the screen.

HCHAR is not affected by margin settings.

Character-code is a numeric-expression with a value from 0-255, specifying the number of the character. See Appendix B for a list of ASCII character codes.

The optional number-of-repetitions is a numeric-expression whose value specifies the number of times the character is repeated horizontally. If the repetitions extend past the end of a row they continue from the first character of the next row. If the repetitions extend past the end of the last row they continue from the first character of the first row.

If you use HCHAR to display a character on the screen, and then later use CHAR, COLOR, or DCOLOR to change the appearance of that character, the result depends on the Graphics Mode.

GRAPHICS(1,1),(2,1),(3,1), the displayed character changes to the newly specified pattern and/or color(s).

In other modes the displayed character remains unchanged.

## Examples

```
100 CALL HCHAR(12,16,33)
```

Places character 33 (an exclamation point) in row 12, column 16.

```
100 CALL HCHAR(1,1,ASC("!"),768)
```

Places an exclamation point in row 1, column 1, and repeats it 768 times, which fills the screen in Pattern Mode GRAPHICS(1,1) .

```
100 CALL HCHAR(R,C,K,T)
```

Places the character with an ASCII code specified by the value of K in row R, column C and repeats it T times.

## HEX\$

## HEX\$

### Format

HEX\$(numeric-expression)

### Description

Returns hexadecimal string equivalent to numeric-expression.

This command functions on integer values only.

### Example

```
A$ = HEX$(-1)::PRINT A$
```

The computer prints:

FFFF

## IF THEN ELSE

## IF THEN ELSE

### Format

IF relational-expression THEN line-number1 [ELSE line-number2] numeric-expression statement) statement2

### Description

The IF THEN statement enables you to transfer program control to a specified program statement, or to execute a statement or series of statements, based on the status of a condition you specify.

The condition tested by the IF THEN statement can be either a relational-expression or a numeric-expression.

A relational-expression is "true" if it accurately describes the relationship between the variables it references; otherwise, it is "false."

A numeric-expression is "false" if it has a value of zero; otherwise, it is "true."

The action specified following THEN or ELSE can be either a line-number or a statement.

If the conditional requirement is met and you specify a line-number, program control is transferred to the program statement located at that line-number.

If the conditional requirement is met and you specify a statement, the specified statement is executed. The statement may be either a single program statement or a series of program statements separated by a double colon (::) statement separator symbol.

If the tested condition is "true," the computer performs the action specified following THEN.

If the tested condition is "false" and you use the ELSE option, the computer performs the action specified following ELSE. Note: A statement separator symbol (::) must not immediately precede ELSE, as this causes a syntax error.

If the tested condition is "false" and you do not use the ELSE option, there are three possibilities.

IF THEN is followed by a statement, program execution proceeds with the next program line.

IF THEN is followed by a line-number only, program execution proceeds with the next program line.

IF THEN is followed by a line-number and a statement separator, program execution proceeds with the statements after the statement separator. Note: In this case, the statement separator symbol functions as an implied ELSE.

An IF THEN statement cannot contain a DEF, DIM, FOR, NEXT, OPTION BASE, SUB, or SUBEND instruction.

#### Examples

```
100 IF X>5 THEN GOSUB 300 ELSE X=X+5
```

If X is greater than 5, then 300 is executed. When the subroutine is ended control returns to the line following this line. If X is 5 or less, X is set equal to X+5 and control passes to the next line.

```
100 IF Q THEN C=C+1::GOTO 500 ELSE L=L/C::GOTO 300
```

If Q is not zero, then C is set equal to C+1 and control is transferred to line 500. If Q is zero, the L is set equal to L/C and control is transferred to line 300.

```
100 IF A$="Y" THEN COUNT=COUNT+1::DISPLAY AT(24,1):"HERE WE GO AGAIN!":GOTO 300
```

If A\$ is not equal to "Y", then control passes to the next line. If A\$ is equal to "Y", then COUNT is incremented by 1, a message is displayed, and control is transferred to line 300.

```
100 IF HOURS =40 THEN PAY=HOURS*WAGE ELSE PAY=HOURS*WAGE+.5*WAGE*  
(HOURS-40)::OT=1
```

If HOURS is less than or equal to 40, then PAY is set equal to HOURS\*WAGE and control passes to the next line. If HOURS is greater than 40, then PAY is set equal to HOURS\*WAGE+.5\*WAGE\*(HOURS-40), OT is set equal to 1, and control passes to the next line.

#### Program

The following program illustrates a use of IF THEN ELSE. It accepts up to 1000 numbers and then prints them in order from smallest to largest.

```
100 CALL CLEAR
110 DIM VALUE(1000)
120 PRINT "ENTER VALUES TO BE SORTED.":"ENTER '9999' TO END ENTRY."
130 FOR COUNT=1 TO 1000
140 INPUT VALUE(COUNT)
150 IF VALUE(COUNT)=9999 THEN 170
160 NEXT COUNT
170 COUNT=COUNT-1
180 PRINT "SORTING."
190 FOR SORT1=1 TO COUNT
200 FOR SORT2=COUNT TO 1
210 IF VALUE(SORT1)>VALUE(SORT2) THEN
    TEMP=VALUE(SORT1)::VALUE(SORT1)=VALUE(SORT2)::VALUE(SORT2)=TEMP
220 NEXT SORT2
230 NEXT SORT1
240 FOR SORTED=1 TO COUNT
250 PRINT VALUE(SORTED)
260 NEXT SORTED
```

## IMAGE

## IMAGE

### Format

IMAGE format-string

### Cross Reference

DISPLAY USING, PRINT USING

### Description

The IMAGE statement enables you to specify the format in which numbers or strings are printed or displayed by a PRINT USING or DISPLAY USING statement.

The format-string is a string constant.

A format-string containing a quotation mark or leading or trailing spaces must be enclosed in quotation marks. A format-string included in a PRINT USING or DISPLAY USING statement (rather than as part of an image statement) must be enclosed in quotation marks.

Any character can be part of a format-string. Certain combinations of characters are interpreted as format-fields, as described below.

An IMAGE statement is not executed.

An IMAGE statement cannot be part of a multiple-statement line.

### Format-Fields

A format-string can consist of one or more format-fields, each specifying the format of one print-item. Format-fields can be separated by any character except a decimal point or a pound sign.

A format-field may consist of the following characters:

A pound sign (#) is replaced by a character from a print-item in the print-list of a PRINT USING or DISPLAY USING instruction. Allow one pound sign for each digit or character; allow one pound sign for the minus sign if necessary. If you do not allow as many pound signs as are necessary to represent the print-item, each pound sign is replaced by an asterisk (\*). If you use more pound signs than are necessary to represent the print-item, each pound sign is replaced by a space. Added spaces precede a number (which right-justifies the number); added spaces follow a string (which left-justifies the string).

To indicate that a number is to be given in scientific notation, circumflexes (^) must be given for the E and power numbers. There must be four or five circumflexes, and 10 or fewer characters (minus sign, pound signs, and decimal point) when using the E format.

The decimal point separates the whole and fractional portions of numbers, and is printed where it appears in the IMAGE statement.

All other letters, numbers, and characters are printed exactly as they appear in the IMAGE statement.

Format-string may be enclosed in quotation marks. If it is not enclosed in quotation marks, leading and trailing spaces are ignored. However, when used directly in PRINT...USING or DISPLAY...USING, it must be enclosed in quotation marks.

Each IMAGE statement may have space for many images, separated by any character except a decimal point. If more values are given in the PRINT USING or DISPLAY USING statement than there are images, then the images are reused, starting at the beginning of the statement.

If you wish, you may put format-string directly in the PRINT...USING or DISPLAY USING statement immediately following USING. However, if a format-string is used often, it is more efficient to refer to an IMAGE statement.

#### Examples

```
100 IMAGE $####.###
```

```
110 PRINT USING 100:A
```

IMAGE \$####.### allows printing of any number from -999.999 to 9999.999. The following illustrates how some sample values would be printed or displayed:

VALUE	APPEARANCE
-999.999	\$-999.999
-34.5	\$ -34.500
0	\$ 0.000
12.4565	\$ 12.457
6312.991	\$6312.999
99999999	\$*****

```
100 IMAGE ANSWERS ARE ### AND ##.##
```

```
110 PRINT USING 100:A,B
```

Allows printing of two numbers. The first may be from -99 to 999 and the second may be from -9.99 to 99.99. The following illustrates how some sample values would be printed or displayed:

VALUES	APPEARANCE
-99 -9.99	ANSWERS ARE -99 AND -9.99
-7 -3.459	ANSWERS ARE -7 AND -3.46
0 0	ANSWERS ARE 0 AND .00 .00
14.8 12.75	ANSWERS ARE 15 AND 12.75
795 852	ANSWERS ARE 795 and ****
-984 64.7	ANSWERS ARE *** AND 64.70

```
300 IMAGE DEAR ####
```

```
310 PRINT USING 300:X$
```

Allows printing a four-character string. The following illustrates how some sample values would be printed or displayed:

## VALUES

JOHN  
TOM  
RALPH

## APPEARANCE

DEAR JOHN,  
DEAR TOM ,  
DEAR \*\*\*\*,

## Programs

The following program illustrates a use of IMAGE. It reads and prints seven numbers and their totals.

```

100 CALL CLEAR
110 IMAGE $####.##
120 IMAGE " ####.##"
130 DATA 233.45,-147.95,8.4,37.263,-51.299,85.2,464
140 TOTAL=0
150 FOR A=1 TO 7
160 READ AMOUNT
170 TOTAL=TOTAL+AMOUNT
180 IF A=1 THEN PRINT USING 110:AMOUNT ELSE PRINT USING 120:AMOUNT
190 NEXT A
200 PRINT " _____"
210 PRINT USING "$####.##":TOTAL
RUN
$ 233.45
-147.95
   8.40
   37.26
  -51.30
   85.20
  464.00
-----
      $ 629.06

```

Lines 110 and 120 set up the images. They are the same except for the dollar sign in line 110. To keep the blank space where the dollar sign was, the format-string in line 120 is enclosed in quotation marks.

Line 180 prints the values using the IMAGE statements.

Line 210 shows that the format can be put directly in the PRINT USING statement.

The amounts are printed with the decimal points aligned.

The following program shows the effect of using more values in the PRINT USING statement than there are images in the IMAGE statement.

```

100 IMAGE ###.##,###.##
110 PRINT USING 100:50.34,50.34,37.26,37.26
RUN
50.34, 50.3
37.26, 37.3

```

**INIT****INIT**

Format  
CALL INIT

Cross Reference  
LINK, LOAD

**Description**

The INIT command reserves memory space to enable the computer to run assembly-language commands. It also removes the pointers in memory to any previously loaded assembly-language program.

The amount of memory set aside for assembly-language programs is 49,152 bytes.

The following is how the memory is allocated;

Total memory block	>2000->E000	49152
BASIC utilities table	>DF68->DFFF	152
BASIC utilities	>2000->24F4	1268
Available for Programs		47732

If you are loading multiple assembly-language programs and they are RORG "type" and the total bytes do not exceed the total bytes available then CALL INIT is only required before the first program is loaded.

**INP****INP**

Format  
CALL INP(port, databyte[, databyte...])

Cross Reference  
OUTP

You may use CALL INP either as a program statement or a command. Use only ports 1 or 2 as the PIO or PIO/2 ports respectively. Sends a databyte to a port.

The databyte may be any integer between 0 and 255.

Data is received and sent internally through various components within the computer, known as ports.

The INP statement is used to obtain direct control of a device such as the keyboard, sound, etc.

INP is the complement function to the OUTP command.

**INPUT****INPUT**

## Format

## Keyboard Input

```
INPUT [input-prompt:]variable-list
```

## File input

```
INPUT #file-number[,REC record-number]
```

## Cross Reference

ACCEPT, EOF, LINPUT, OPEN, REC, TERMCHAR

## Description

The INPUT statement suspends program execution to enable you to enter data from the keyboard. INPUT can be used to retrieve data from an external device.

The variable-list consists of one or more variables separated by commas. Values are assigned to the variables in the variable-list in the order they are input. A value assigned to a numeric variable must be a number; a value assigned to a string variable may be a string or a number.

Variables are assigned to a values sequentially in the variable-list. A value can be assigned to a variable, and then that variable can be used as a subscript later in the same variable-list.

## Input from the Keyboard

If you do not specify a file-number, the program pauses to accept input from the keyboard.

If you enter an input-prompt, it appears at the beginning of the input field, followed immediately by the flashing cursor.

The input-prompt is a string expression; if you use a string constant, you must enclose it in quotation marks.

If you do not enter an input-prompt, a question mark (?) appears at the beginning of the input field, followed by a space. The flashing cursor appears in the character position following the space.

The input field begins in the far left column of the bottom row of the screen window defined by the margins. You can enter up to 157 characters from the keyboard; however, an exceptionally long entry may not be processed correctly by the computer.

The values entered to the variable-list of one INPUT statement must be separated by commas. You must enter the same number of values as there are variables in the variable-list.

A string value entered from the keyboard can optionally be enclosed in quotation marks. However, a string containing a comma, a quotation mark, or

leading or trailing spaces must be enclosed in quotation marks. A quotation mark within a string is represented by two adjacent quotation marks.

You normally press ENTER to complete keyboard input; however, you can also use Alt 7(AID), Alt 9(BACK), Alt 5(BEGIN), CLEAR, Alt 6(PROC'D), DOWN ARROW, or UP ARROW. You can use the TERMCHAR function to determine which of these keys was pressed to exit from the previous INPUT, LINPUT, or ACCEPT instruction.

Note that pressing CLEAR during keyboard input normally causes a break in the program. However, if your program includes an ON BREAK NEXT statement, you can use CLEAR to exit from an input field.

The computer sounds a short tone to signal that it is ready to accept keyboard input.

### Examples

100 INPUT X  
Allows the input of a number.

100 INPUT X\$,Y  
Allows the input of a string and a number.

100 INPUT "ENTER TWO NUMBERS: ":A,B  
Displays the prompt ENTER TWO NUMBERS and then allows the entry of two numbers.

100 INPUT A(J),J  
First evaluates the subscript of A and then accepts data into that element of the array A. Then a value is accepted into J.

100 INPUT J,A(J)  
First accepts data into J and then accepts data into the Jth element of the array A.

### Program

The following program illustrates a use of INPUT from the keyboard.

```

100 CALL CLEAR
110 INPUT "ENTER YOUR FIRST NAME: ":FNAME$
120 INPUT "ENTER YOUR LAST NAME: ":LNAME$
130 INPUT "ENTER A THREE DIGIT NUMBER: ":DOLLARS
140 INPUT "ENTER A TWO DIGIT NUMBER: ":CENTS
150 IMAGE OF $###.## AND THAT IF YOU
160 CALL CLEAR
170 PRINT "DEAR ";FNAME$;"," :
180 PRINT "      THIS IS TO REMIND YOU"
190 PRINT "THAT YOU OWE US THE AMOUNT"
200 PRINT USING 150:DOLLARS+CENTS/100
210 PRINT "IF YOU DO NOT PAY US, YOU WILL SOON"
220 PRINT "RECEIVE A LETTER FROM OUR"
```

```
230 PRINT "ATTORNEY, ADDRESSED TO"  
240 PRINT FNAME$;" ";LNAME$;"!": :  
250 PRINT TAB(15);"SINCERELY," : :TAB(15);"I. DUN YOU": :  
260 GOTO 260  
(Press CLEAR to stop the program.)
```

Lines 110 through 140 allow the person using the program to enter data, as requested with the input-prompts.

Lines 170 through 250 construct a letter based on the input. (Be certain to enter the colons exactly as indicated, because they control line spacing.)

#### Input from a File

If you include a file-number, input is accepted from the specified device.

The file-number is a numeric-expression whose value specifies the number of the file as assigned in its OPEN instruction.

If necessary, file-number is rounded to the nearest integer.

If you use the REC option, the record-number is a numeric-expression whose value specifies the number of the record from which you want to input to the variable-list. The records in a file are numbered sequentially, starting with zero. The \_REC option can be used only with a file opened for RELATIVE access.

If necessary, record-number is rounded to the nearest integer.

You can accept input only from files opened in INPUT or UPDATE mode. DISPLAY files must have fewer than 161 characters in each record to be used with an INPUT statement; however, an exceptionally long record may not be processed correctly by the computer.

If there are more variables in the variable-list than there are values in the current record, the computer proceeds as follows:

In the case of INTERNAL FIXED records, null strings are assigned to the remaining variables, causing a program error if any of the remaining variables are numeric.

For other records, the computer reads the next record in the file, and uses its values to complete the variable-list.

If there are more values in the current record than are necessary to fill the variable-list, the remaining values are discarded. However, if the variable-list ends with a comma, the computer is placed in an input-pending condition. The remaining values are assigned to the variables in the variable-list of the next INPUT statement unless that statement includes the REC option, in which case the remaining values are discarded.

## Examples

```
100 INPUT #1:X$
```

Puts into X\$ the next value available in the file that was opened as #1.

```
100 INPUT #23:X,A,LL$
```

Puts into X, A, and LL\$ the next three values from the file that was opened as #23 with data in INTERNAL format.

```
100 INPUT #11,REC 44:TAX
```

Puts into TAX the first value of record number 44 of the file that was opened as #11 with RELATIVE file organization.

```
100 INPUT #3:A,B,C,
```

```
110 INPUT #3:X,Y,Z
```

Puts into A, B, and C the next three values from the file opened as #3. The comma after C creates an input-pending condition, and because the INPUT statement in line 110 has no REC clause, the computer assigns to X, Y, and Z data values beginning where the previous INPUT statement stopped.

## Program

The following program illustrates a use of the INPUT statement. It opens a file on disk drive 1 called TEST and writes 5 records to the file. It then goes back and reads the records and displays them on the screen.

```
100 OPEN #1:"DSK1.TEST",SEQUENTIAL,INTERNAL,OUTPUT,FIXED 64
```

```
110 FOR A=1 TO 5
```

```
120 PRINT #1:"THIS IS RECORD",A
```

```
130 NEXT A
```

```
140 CLOSE #1
```

```
150 CALL CLEAR
```

```
160 OPEN #1:"DSK1.TEST",SEQUENTIAL,INTERNAL,INPUT,FIXED 64
```

```
170 PRINT
```

```
180 FOR B=1 TO 5
```

```
190 INPUT #1:A$,C
```

```
200 PRINT A$;C
```

```
210 NEXT B
```

```
220 CLOSE #1
```

```
RUN
```

```
THIS IS RECORD 1
```

```
THIS IS RECORD 2
```

```
THIS IS RECORD 3
```

```
THIS IS RECORD 4
```

```
THIS IS RECORD 5
```

## INT

## INT

### Format

INT(numeric-expression)

### Type

Real

### Description

The INT function returns the largest integer not greater than the value of the numeric-expression.

If the value of the numeric-expression is an integer, INT returns the value of the numeric-expression itself. If the numeric-expression is not an integer, INT returns the largest integer not greater than the numeric-expression.

### Examples

```
100 PRINT INT(3.4)
```

Prints 3.

```
100 X=INT(3.9)
```

Sets X equal to 3.

```
100 P=INT(3.9999999999)
```

Sets P equal to 3.

```
100 DISPLAY AT(3,7):INT(4.0)
```

Displays 4 at the third row, seventh column of the current screen window.

```
100 N=INT(-3.9)
```

Sets N equal to -4.

```
100 K=INT(-3.000000001)
```

Sets K equal to -4.

**JOYST --Joystick****JOYST****Format**

CALL JOYST(key-unit,x,y)

**Description**

The JOYST command enables you to ascertain the position of either of the Joystick Controllers.

The numeric-expression key-unit can have a value of 1 or 2, specifying the joystick you are testing.

The position of the specified joystick is returned in the numeric variables x and y as follows:

POSITION	X	
Center	0	0
Up	0	(+)4
Upper Right	(+)4	(+)4
Right	(+)4	0
Lower Right	(+)4	-4
Down	0	-4
Lower Left	-4	-4
Left	-4	0
Upper Left	-4	(+)4

If the specified joystick is not connected to the computer, x and y are both returned as 0.

**Example**

```
100 CALL JOYST(1,X,Y)
```

Returns values in X and Y according to the position of joystick number 1.

**Program**

The following program illustrates a use of the JOYST command. It creates a sprite and then moves it around according to the input from a joystick.

```
100 CALL CLEAR
110 CALL SPRITE(#1,33,5,96,128)
120 CALL JOYST(1,X,Y)
130 CALL MOTION(#1,-Y*4,X*4)
140 GOTO 120
(Press CLEAR to stop the program.)
```

**CALL KEY****CALL KEY**

## Format

CALL KEY(key-unit,key,status)

## Description

The KEY command enables you to transfer one character from the keyboard directly to a program.

CALL KEY can sometimes replace an INPUT statement, especially for the input of a single character.

The numeric-expression key-unit can have a value from 0 to 5, as explained below.

The character code of the key pressed is returned in the numeric variable key. If no key is pressed, a value of 0 is returned.

See Appendix B for a list of the available characters.

The keyboard status is returned in the numeric variable status as explained below.

Because the character represented by the key pressed is not displayed on the screen, the information already on the screen is not disturbed.

## Key-Unit Options

The value you specify for the key-unit determines what portion of the keyboard is active and how the key pressed is interpreted.

**KEY-UNIT    RESULTS**

- 0 Console keyboard, in mode previously specified by CALL KEY.
- 1 Only the left side of the keyboard is active.
- 2 Only the right side of the keyboard is active.
- 3 Places keyboard in the same mode as mode 0.
- 4 Remaps the keyboard in the PASCAL mode. Both upper- and lower-case alphabetical character codes are returned by the computer. It is not recommended to use this mode.
- 5 Places the key board in 99/4A BASIC mode. Both upper- and lower-case alphabetical character codes are returned by the computer.

## Status

The value returned as the status can be interpreted as follows:

- 1 The same key was pressed as was returned the last time KEY was called.
- 0 No key was pressed.
- 1 A different key was pressed than was returned the last time KEY was called.

See Appendix M for the return values of all KEY modes.

## Example

```
100 CALL KEY(0,K,S)
```

Returns in K the ASCII code of any key pressed on the keyboard except SHIFT, CTRL, ALT, and CAPS and in S a value indicating whether a key was pressed.

### Program

The following program illustrates a use of the KEY command. It creates a sprite and then enables you to move it around by using the arrow keys(E, S, D, and X) without pressing ALT. Note that line 130 returns to line 120 if no key has been pressed.

To stop the sprite's movement, press any key(except the arrow keys) on the left side of keyboard.

```
100 CALL CLEAR
110 CALL SPRITE(#1,33,5,96,128)
120 CALL KEY(1,K,S)
130 IF S=0 THEN 120
140 IF K=5 THEN Y=-4
150 IF K=0 THEN Y=4
160 IF K=2 THEN Y=-4
170 IF K=3 THEN X=4
180 IF K=1 THEN X,Y=0
190 IF K>5 THEN X,Y=0
200 CALL MOTION(#1,Y,X)
210 GOTO 120
(Press CLEAR to stop the program.)
```

```
150 IF K=0 THEN Y=4 160 IF K=2 THEN Y=-4
170 IF K=3 THEN X=4
180 IF K=1 THEN X,Y=0
190 IF K>5 THEN X,Y=0
200 CALL MOTION(#1,Y,X)
210 GOTO 120
(Press CLEAR to stop the program.)
```

**KEY****KEY**

Format

KEY ON, KEY OFF {scroll-lock}

Description

The KEY ON function displays a list of the pre-defined function keys.

KEY OFF turns off the list.

KEY LIST list the keys.

SCROLL-LOCK makes the pre-defined keys live.

**Note:** Pressing the Scroll-lock will over ride the standard function keys such as F2=insert and F3=erase for as long as Scroll-Lock is turned on. Turn off Scroll-Lock (pressing the key again) to bring back standard function keys.

Pressing Scroll-Lock the function KEYS 1-10 are predefined as follows:

F1	LIST	F6	MERGE
F2	RUN	F7	NUM
F3	OLD	F8	TRACE
F4	SAVE	F9	PRINT
F5	CON	F10	KEY

Use KEY ON or KEY OFF to display /remove function key menu in screen modes (3,1), (3,2), (3,3).

Using HCHAR at row 25 in a program, a second menu can be added of more user defined key items.

You can use the command KEY LIST to view the complete list on the screen.

**Redefining KEY.**

To define new KEY assignments use KEY(key number)="new assignment"

Example

KEY(6)="CALL GRAPHICS(3,1)"

Now whenever you press F6 after pressing SCROLL-LOCK the command CALL GRAPHICS(3,1) will appear on the screen instead of MERGE.

## ASCII CODES

The following predefined characters may be printed or displayed on the screen.

ASCII CODE	CHARACTER	ASCII CODE	
30	(cursor)	63	? (question mark)
31	(space)	64	@ (at sign)
32	(space)	65	A
33	! (exclamation point)	66	B
34	" (quote)	67	C
35	# (number or pound sign)	68	D
36	\$ (dollar)	69	E
37	% (percent)	70	F
38	& (ampersand)	71	G
39	' (apostrophe)	72	H
40	( (open parenthesis)	73	I
41	) (close parenthesis)	74	J
42	* (asterisk)	75	K
43	+ (plus)	76	L
44	, (comma)	77	M
45	- (minus)	78	N
46	. (period)	79	O
47	/ (slash)	80	P
48	0	81	Q
49	1	82	R
50	2	83	S
51	3	84	T
52	4	85	U
53	5	86	V
54	6	87	W
55	7	88	X
56	8	89	Y
57	9	90	Z
58	: (colon)	91	[ (open bracket)
59	; (semicolon)	92	\ (reverse slant)
60	< (less than)	93	] (close bracket)
61	= (equals)	94	^ (exponentiation)
62	> (greater than)	95	_ (underline)

## KILL

## KILL

### Format

KILL file-specification

### Cross Reference

CLOSE

### Description

The KILL instruction removes a file from an external storage device. Although the file is not physically erased, the space it occupies becomes available for you to store another file in the future.

You can use KILL as either a program statement or a command.

The file-specification indicates the name of the file to be deleted. The file-specification is a string-expression; if you use a string constant, you must enclose it in quotation marks.

You can also remove files stored on some external devices by using the KILL option in the CLOSE instruction.

For more information about the options available with a particular device, refer to the owner's manual that comes with that device.

### Example

```
KILL "DSK1.MYFILE"
```

Deletes the file named MYFILE from the diskette in disk drive 1.

### Program

The following program illustrates a use of KILL.

```
100 INPUT "NAME OF FILE TO BE DELETED: ":X$  
110 KILL X$
```

### NOTE: For TI 99/4A PROGRAMS

Delete will no longer be used to delete files from disk storage device (see KILL, CLOSE, FILES). However programs that contain a "DELETE" file statement will execute exactly as they did under TI BASIC or TI EXTENDED BASIC. The token used internally will now be occupied by the KILL command. As long as the program is stored in tokenized form (program file, or DV163 merge format) the execution will not be affected. On listing the program the word "KILL" will be listed instead of "DELETE".

**LEFT\$****LEFT\$**

## Format

LEFT\$(string\$,numvar)

## Cross Reference

SEG\$, RIGHT\$, POS

## Description

LEFT\$() returns the leftmost portion of the string represented by string\$ of length numvar.

The LEFT\$ function creates a new string but does not destroy the original string.

LEFT\$(A\$,5) is equivalent to SEG\$(A\$,1,5) if A\$ is at least 5 characters long.

If the string is shorter than the length specified, the string LEFT\$ function will pad the string with blank spaces rather than return an error condition

LEFT\$ can be used with numerical data if the number is first converted to a string using the STR\$(n) function.

## Example

```
100 B$=LEFT$("1234",3)
110 PRINT B$
120 C$=VAL(LEFT$(STR$(-1234),4)
130 PRINT C$
RUN
123
-123
```

LEFT\$ can also be used to make a program user friendly by separating first from last names, checking the first character of a response etc.

## Example

```
100 INPUT "What is your full name please ":NAME$
110 SP=POS(NAME$," ",1)
120 FIRST$=LEFT$(NAME$,SP-1)
130 INPUT FIRST$&" IS THE AUTHOR OF THE COLOR OF MAGIC ?":ANSWER$
135 A$=LEFT$(ANSWER$,1)
140 IF A$="Y" OR A$="y" THEN PRINT "I'M SORRY ";FIRST$;" that is not
    correct":GOTO 170
150 IF A$="N" OR A$="n" THEN PRINT "* THAT IS RIGHT":STOP
160 PRINT "TYPE YES or NO as a response please ":GOTO 130
RUN
What is your full name please ? ALFRED BESTER
ALFRED IS THE AUTHOR OF THE COLOR OF MAGIC ? NO
THAT IS RIGHT
```

## LEN

## LEN

### Format

LEN(string-expression)

### Type

DEFINT

### Description

The LEN function returns the number of characters in the string specified by the string-expression.

If the string-expression is a null string, LEN returns a zero.

Remember that a space is a valid character and is considered to be part of the length of a string.

### Examples

```
100 PRINT LEN("ABCDE")  
Prints 5.
```

```
100 X=LEN("THIS IS A SENTENCE.")  
Sets X equal to 19.
```

```
100 DISPLAY LEN("")  
Displays 0.
```

```
100 DISPLAY LEN(" ")  
Displays 1.
```

```
100 A$="ANNE MCCAFFREY"  
110 DISPLAY LEN(A$)  
Displays 14 as the string length.
```

**LET****LET**

## Format

[LET ]variable-list=expression

## Description

The LET instruction, often called the "assignment" instruction, enables you to assign values to variables.

You can use LET as either a program statement or a command.

The variable-list consists of one or more variables separated by commas. Do not mix numeric and string variables in the same variable-list. However, you can include both DEFINT and REAL numeric variables in the same variable-list.

The value of expression is assigned to all variables in the variable-list. If the variable-list contains numeric variables, the expression must be a numeric-expression. If the variable-list contains string variables, the expression must be a string-expression.

The word LET can be optionally omitted from instruction.

## Examples

```
100 LET T=4
```

Assigns to T the value 4.

```
100 LET X,Y,Z=12.4
```

Assigns to X, Y, and Z the value 12.4.

```
100 LET A=3<5
```

Assigns -1 to A because it is true that 3 is less than 5.

```
100 LET B=12<7
```

Assigns 0 to B because it is not true that 12 is less than 7.

```
100 LET L$,D$,B$="B"
```

Assigns to L\$, D\$, and B\$ the string constant "B".

## Program

The following program illustrates a use of LET.

```
100 LET K=1
110 LET K,A(K)=3
120 PRINT K;A(1)
130 PRINT A(3);A(K)
RUN
3 3
0 0
```

In line 100, the variable K is assigned the value 1.

In line 110, the variable K and the array element A(K) are assigned the value of 3. Note that when line 110 is executed, the subscript K is not assigned a new value, but has the same value it had before the line was executed. Therefore, A(K) is an expression equivalent to A(1), referring to the same element of the array.

In line 120, the values of K and A(1) are printed.

When line 130 is executed, K has a value of 3; therefore, A(K) is now an expression equivalent to A(3). Both expressions have a value of 0 (the default value) because no value has been assigned to this element of array.

**LINK****LINK**

## Format

```
CALL LINK(command-name[,parameter-list])
```

## Cross Reference

```
INIT, LOAD, SUB
```

## Description

The LINK command enables you to transfer control from a Geneve 9640 Advanced BASIC program to an assembly-language command.

The subprogram-name is an entry point in an assembly-language subprogram that you have previously loaded into memory with the LOAD command. The subprogram-name is a string-expression; if you use a string constant, it must be enclosed in quotation marks.

The optional parameter-list consists of one or more parameters, separated by commas, that are to be passed to the assembly-language subprogram. The contents of the parameter-list depend on the particular subprogram you are accessing.

The rules for passing parameters to an assembly-language subprogram are the same as the rules for passing parameters to a Geneve 9640 Advanced BASIC subprogram (see SUB).

## Example

```
100 CALL LINK("START",1,3)
```

Links the Geneve 9640 Advanced BASIC program to the assembly-language subprogram

START, and passes the values 1 and 3 to it.

**LINPUT****LINPUT**

## Format

## Keyboard Input

```
LINPUT [input-prompt:]string-variable
```

## File Input

```
LINPUT #file-number[,REC record-number]:string-variable
```

## Cross Reference

ACCEPT, EOF, INPUT, OPEN, TERMCHAR

## Description

The LINPUT statement suspends program execution to enable you to enter a line of unedited data from the keyboard. LINPUT can be used also to retrieve an unedited record from an external device.

LINPUT assigns an entire line, a file record, or the remaining portion of a file record (if there is an input-pending condition) to the string-variable.

See INPUT for an explanation of keyboard- and file-input, and input options.

No editing is performed on the input data. All characters (including commas, quotation marks, colons, semicolons, and leading and trailing spaces) are assigned to the string-variable as they are encountered.

The maximum value that can be input from the keyboard is 255 characters.

LINPUT is frequently used instead of INPUT when the input data may include a comma. (A comma is not accepted as input by the INPUT statement, except as part of a string enclosed in quotation marks.)

To use LINPUT for file input the file must be in DISPLAY format.

You normally press ENTER to complete keyboard input; however, you can also use AID, BACK, BEGIN, CLEAR, PROC'D, DOWN ARROW, or UP ARROW. You can use the TERMCHAR function to determine which of these keys was pressed to exit from the previous ACCEPT, INPUT, or LINPUT instruction.

Note that pressing CLEAR during keyboard input normally causes a break in the program. However, if your program includes an ON BREAK NEXT statement, you can use CLEAR to exit from an input field.

## Examples

```
100 LINPUT L$
```

Assigns to L\$ anything typed before ENTER is pressed.

```
100 LINPUT "NAME: "NM$
```

Displays NAME: and assigns to NM\$ anything typed before ENTER is pressed.

```
100 LINPUT #1,REC M:L$(M)
```

Assigns to L\$(M) the value that was in record M of the file that was opened as #1 with RELATIVE DISPLAY file organization.

#### Program

The following program illustrates a use of LINPUT. It reads a previously existing file and displays only the lines that contain the word "THE."

```
100 OPEN #1:"DSK1.TEXT1",INPUT,FIXED 80,DISPLAY
110 IF EOF(1) THEN CLOSE #1 :: STOP
120 LINPUT #1:A$
130 X=POS(A$,"THE",1)
140 IF X>0 THEN PRINT A$
150 GOTO 110
```

#### NOTE:

Remember to press the two keys, Control + Break whenever the Manual refers to "CLEAR".

**LIST****LIST**

## Format

List to the screen

LIST [line-number-range]

List to a File (or Device)

LIST "file-specification"[:line-number-range]

## Cross Reference

LLIST

## Description

The LIST command displays the program (or a portion of it) currently in memory. You can also use LIST to output the program listing to an external device.

The optional line-number-range specifies the portion of the program to be listed. If you do not enter a line-number-range, the entire program is listed. The program lines are always listed in ascending order.

If you enter a file-specification, the program listing is output to the specified file or device. The file-specification, a string constant, must be enclosed in quotation marks.

The program listing is output as a SEQUENTIAL file in DISPLAY format with VARIABLE records (see OPEN); the file-specification option can be used only with devices that accept these options. For more information about listing a program on a particular device, refer to the owner's manual that comes with that device. If you do not enter a file-specification, the program listing is displayed on the screen.

You can stop the listing at any time by pressing CLEAR. Pressing any other key (except SHIFT, ALT, or CTRL) causes the listing to pause until you press a key again.

The LIST command only works with peripherals that support DISPLAY/VARIABLE type records.

### The Line-Number-Range

A line-number-range can consist of a single line number, a single line number followed by a hyphen, a single line number preceded by a hyphen, or a range of line numbers.

COMMAND	LINES LISTED
LIST	All lines.
LIST X	Line number X only.
LIST X-	Lines from number X to the highest line number, inclusive.
LIST -X	Lines from the lowest line number to line number X, inclusive.
LIST X-Y or LIST X Y	All lines from line number X to line number Y, inclusive.

If the line-number-range does not include a line number in your program, the following conventions apply:

If line-number-range is higher than any line number in the program, the highest-numbered program line is listed.

If line-number-range is lower than any line number in the program, the lowest-numbered program line is listed.

If line-number-range is between lines in the program, the next higher numbered program line is listed.

### Examples

LIST  
Lists the entire program in memory on the display screen.

LIST 100  
Lists line 100.

LIST 100-  
Lists line 100 and all after it.

LIST -200  
Lists all lines up to and including line 200.

LIST 100-200  
Lists all lines from 100 through 200.

**LLIST****LLIST****Format**

LLIST[linenum1][-][linenum2][ w/w] or [ w/w(width)]

**Cross Reference**

LIST

**Description**

Same line format as LIST except that LLIST automatically sends list to default print device.

COMMAND	LINES LISTED
LLIST	All lines.
LLIST X	Line X only.
LLIST X-	Lines from X to the highest line number, inclusive.
LLIST -X	Lines from the lowest line number to line number X, inclusive.
LLIST X-Y or X Y	All lines from line numbers X to Y, inclusive
LLIST X-Y,W or W132	All lines from line numbers X to Y, I Inclusive are printed using a page width of W to a maximum of 160.

If the line-number-range does not include a line number in the program, the following conventions apply.

If line-number-range is higher than any line number in the program, the highest-numbered program line is listed.

If line-number-range is lower than any line number in the program, the lowest-numbered program line is listed.

If line-number-range is between lines in the program, the next higher numbered program line is listed.

Width is the number of characters across the page and the default is 80 characters. W has a default of 160 characters. W can be upper or lower case.

If the page width depends upon an escape code or control code sequence, then that sequence must be sent to the print device before using LLIST. This can be accomplished by the following method.

From the command prompt;

For 132 or 136 width printer OPEN #X:"PIO"::PRINT #X:CHR\$(15)::CLOSE #1

For 160(condensed elite) width OPEN #x:"PIO"::PRINT#X:CHR\$(15);CHR\$(27);CHR\$(77)  
::CLOSE #1

The default device can be changed by changing the name of LPT.

LPT device.filename from command prompt or KEY(12)="PIO" or "RS232.[options]" from command prompt or within a program.

Any width greater than 80 or less than 80 will create a file of that length on a storage device.

## Examples

LLIST

Prints the entire program in memory on the display screen.

LLIST 100

Prints line 100.

LLIST 100-

Prints line 100 and all after it.

LLIST -200

Prints all lines up to and including line 200.

LLIST 100-200

Prints all lines from 100 through 200.

LLIST 100-200,132

Prints all lines from 100 through 200 on a page width of 132 characters.

**LOAD****LOAD**

## Format

## File Only

```
CALL LOAD(file-specification-list)
```

## Data Only

```
CALL LOAD(address,byte-list[, "",address,byte-list[,...]])
```

## File and Data

```
CALL LOAD(file-specification-list,address,byte-list[,...])
```

```
CALL LOAD(address,byte-list,file-specification-list[,...])
```

## Cross Reference

INIT, LINK, PEEK, PEEKV, POKEV, VALHEX

## Description

The LOAD command enables you to load assembly-language subprograms into memory. You can also use LOAD to assign values directly to specified CPU (Central Processing Unit) memory addresses. You can use the POKEV command to assign values to VDP (Video Display Processor) memory.

To load an assembly-language subprogram, specify a file-specification-list; to assign values to CPU memory, specify an address and a byte-list (an address must always be followed by a byte-list).

You must enter at least one parameter. The first parameter you specify can be either a file-specification-list or an address.

If you wish to follow an address and byte-list with another address and byte-list, enter a file-specification-list or a null string (two-adjacent quotation marks) as a separator.

The optional file-specification-list consists of one or more file-specifications separated by commas. A file-specification is a string-expression; if you use a string constant, you must enclose it in quotation marks.

Each file-specification names an assembly-language object (program) file to be loaded into memory. The specified file can include subprogram names, so that the subprograms can be executed by the LINK command.

The object file to be loaded must be in DISPLAY format with FIXED records (see OPEN). For more information about the file options available with a particular device, refer to the owner's manual that comes with that device.

You can optionally load bytes of data to a specified CPU memory address. The address specifies the first address where the data is to be loaded; if the byte-list specifies more than one byte of data, the bytes are assigned to sequential memory addresses starting with the address you specify.

The numeric-expression address must have a value from -32768 to 32767 inclusive.

You can specify an address from 0 to 32767 inclusive by specifying the actual address.

You can specify an address from 32768 to 65535 inclusive by subtracting 65536 from the actual address. This will result in a value from -32768 to -1 inclusive.

If you know the hexadecimal value of the address, you can use the VALHEX function to convert it to a decimal numeric-expression, eliminating the possible need for calculations.

If necessary, the address is rounded to the nearest integer.

The byte-list consists of one or more bytes of data, separated by commas, that are to be loaded into CPU memory starting with the specified address.

Each byte in the byte-list must be a numeric-expression with a value from 0 to 32767. If the value of a byte is greater than 255, it is repeatedly reduced by 256 until it is less than 256. If necessary, a byte is rounded to the nearest integer.

Note that you must use the INIT command to reserve memory space before you use LOAD to load a subprogram.

If you call the LOAD command with invalid parameters or load an object file with absolute (rather than relocatable) addresses, the computer may function erratically or cease to function entirely. If this occurs, turn off the computer, wait several seconds, then turn the computer back on again.

#### The Loader

LOAD uses a "relocatable linking" loader.

Because it is "relocatable," you cannot use LOAD to specify a memory address at which you want to load a file. However, the file you are loading may specify an absolute load address if it includes an AORG directive.

Because it is "linking", the object files specified in the file-specification-list can reference each other.

**LOCATE****LOCATE**

## Format

```
CALL LOCATE(#sprite-number,pixel-row,pixel-column[,...])
```

## Cross Reference

DELSprite, Sprite, Sprite2

## Description

The LOCATE command enables you to change the location of one or more sprites.

The sprite-number is a numeric-expression whose value specifies the number of a sprite as assigned by the Sprite command.

The pixel-row and pixel-column are numeric-expressions whose values specify the screen pixel location of the pixel at the upper-left corner of the sprite. Note: Values can not exceed screen resolution.

LOCATE can cause a sprite that has been deleted with DELSprite sprite-number to reappear.

## Program

The following program illustrates a use of the LOCATE command.

```
100 CALL CLEAR
110 CALL Sprite(#1,33,7,1,1,25,25)
120 YLOC=INT(RND* 150+1)
130 XLOC=INT(RND* 200+1)
140 FOR DELAY=1 TO 300 :: NEXT DELAY
150 CALL LOCATE(#1,YLOC,XLOC)
160 GOTO 120
(Press CLEAR to stop the program.)
```

Line 110 creates a sprite as a fairly quickly moving red exclamation point.

Line 140 locates the sprite at a location randomly chosen in lines 120 and 130.

Line 150 repeats the process.

Also see the third example of the Sprite command.

**LOG****LOG**

## Format

LOG(numeric-expression)

## Type

REAL

## Cross Reference

EXP

## Description

The LOG function returns the natural logarithm of the value of the numeric-expression. LOG is the inverse of the EXP function.

The value of the numeric-expression must be greater than zero. Examples

```
100 PRINT LOG(3.4)
```

Prints the natural logarithm of 3.4, which is 1.223775432.

```
100 X=LOG(EXP(7.2))
```

Sets X equal to the natural logarithm of e raised to the 7.2 power, which is 7.2.

```
100 S=LOG(SQR(T))
```

Sets S equal to the natural logarithm of the square root of the value of T.

## Program

The following program returns the logarithm of any positive number in any base.

```
100 CALL CLEAR
110 INPUT "BASE: ":B
120 IF B =1 THEN 110
130 INPUT "NUMBER: ":N
140 IF N =0 THEN 130
150 LG=LOG(N)/LOG(B)
160 PRINT "LOG BASE";B;"OF";N;"IS";LG
170 PRINT
180 GOTO 110
(Press CLEAR to stop the program.)
```

## LPR

## LPR

### Format

CALL LPR(x,y)

### Cross Reference

POINT, DRAW, DRAWTO, LINE, PSET or preset or the current position of the mouse cursor.

### Description

Last Point Referenced returns the coordinates of the last point referenced by the graphics commands.

## LPT

## LPT

### Syntax

LPT device name string

### Cross Reference

DOS Manual, DEFAULTS, LCOPY, LTRACE, LLIST

### Description

You can use LPT either as a program statement or a command.

LPT is used to modify the name of the default print device. Example

LPT "PIO"

LPT "RS232.BA=9600,DA=8"

LPT "DSK1.FILENAME"

The default print device is accessed from BASIC in the command mode or within a program by use of the following commands: LCOPY, LTRACE, LLIST.

## LTRACE

## LTRACE

Cross Reference  
TRACE, BREAK

### Description

LTRACE is used exactly as TRACE except the output is directed towards the default print device rather than the screen.  
LTRACE ON turns it on. LTRACE OFF turns it off.

LTRACE is a valuable aid because it is not affected by screen clearing commands such as:

CALL CLEAR, CLS, DISPLAY, ERASE ALL, CALL GRAPHICS( ) etc.

**MAGNIFY****MAGNIFY**

## Format

CALL MAGNIFY(numeric-expression)

## Cross Reference

CHAR, SPRITE, SPRITE2

## Description

The MAGNIFY command enables you to specify whether all sprites are single- or double-sized and whether they are un-magnified or magnified.

The value of the numeric-expression specifies the size and magnification "level" of all sprites. (You cannot specify the level of an individual sprite.)

<b>LEVEL</b>	<b>CHARACTERISTICS</b>
1	Single-sized, un-magnified
2	Single-sized, magnified
3	Double-sized, un-magnified
4	Double-sized, magnified

The screen position of the pixel in the upper-left corner of a sprite is considered to be the position of that sprite. That pixel remains in the same screen position regardless of changes to the magnification level.

When you enter Geneve 9640 Advanced BASIC, sprites are single-sized and un-magnified (level 1). When your program ends (either normally or because of an error), stops at a break-point, or changes graphics mode, the sprite magnification level is restored to 1.

## Single-Sized Sprites

A single-sized sprite is defined only by the character you specify when the sprite is created.

## Double-Sized Sprites

A double-sized sprite is defined by four consecutive characters, including the character that you specify when the sprite is created.

If the number of the character you specify is a multiple of 4, that character is the first of the four characters that comprise the sprite's definition. If the character number is not a multiple of 4, the next lower character that is a multiple of four is the first character of the sprite.

The first of the four characters defines the upper-left quarter of the sprite, the second character defines the lower-left quarter of the sprite, the third defines the upper-right quarter of the sprite, and the last of the four characters defines the lower-right quarter of the sprite.

### un-magnified Sprites

An un-magnified sprite occupies only the number of characters on the screen specified by the characters that define it.

A single-sized un-magnified sprite occupies 1 character position on the screen; a double-sized un-magnified sprite occupies 4 character positions.

### Magnified Sprites

A magnified sprite expands to twice the height and twice the width of a un-magnified sprite. The expansion occurs down and to the right; the pixel in the upper-left corner of the sprite remains in the same screen position.

A magnified sprite has 4 times the area of an un-magnified sprite. When you magnify a sprite, each pixel of the un-magnified sprite expands to 4 pixels of the magnified sprite.

A single-sized magnified sprite occupies 4 character positions on the screen; a double-sized magnified sprite occupies 16 character positions.

### Program

The following program illustrates a use of the MAGNIFY command.

A little figure (single-sized, un-magnified) appears near the center of the screen. In a moment, it becomes twice as big (single-sized, magnified), covering four character positions. In another moment, it is replaced by the upper-left corner of a larger figure (single-sized, magnified), still covering four character positions. Then the full figure appears (double-sized, magnified), covering sixteen character positions. Finally it is reduced in size to four character positions (double-sized, un-magnified).

```

100 CALL CLEAR
110 CALL CHAR(148,"1898FF3D3C3CE404")
120 CALL SPRITE(#1,148,5,92,124)
130 GOSUB 230
140 CALL MAGNIFY(2)
150 GOSUB 230
160 CALL CHAR(148,"0103C3417F3F070707077E7C40000080C0C080
FCFEE2E3E0E0E060606070")
170 GOSUB 230
180 CALL MAGNIFY(4)
190 GOSUB 230
200 CALL MAGNIFY(3)
210 GOSUB 230
220 STOP
230 REM DELAY
240 FOR DELAY=1 TO 500
250 NEXT DELAY
260 RETURN

```

Line 110 defines character 148.

Line 120 sets up sprite using character 148. By default the magnification factor is 1.

Line 140 changes the magnification factor to 2.

Line 160 redefines character 148. Because the definition is 64 characters long, it also defines characters 149, 150, and 151.

Line 180 changes the magnification factor to 4.

Line 200 changes the magnification factor to 3.

**MARGINS****MARGINS**

CALL MARGINS(left,right,top,bottom)

Cross Reference

ACCEPT,DISPLAY,DISPLAY USING,GRAPHICS,INPUT,LINPUT,PRINT,PRINT USING

Description

The MARGINS command enables you to define screen margins. The margins you specify create a screen window for text that is separate from the rest of the screen.

The margins cannot "overlap"; that is, the position of the top margin must be higher on the screen than the bottom margin, and the position of the left margin must be farther left on the screen than the right margin.

The upper-left corner of the window is considered to be row 1 and column 1 of ACCEPT, DISPLAY, DISPLAY USING commands while using the AT (R,C) option. The maximum row and column will maximum width and height of the window.

The lower-left corner of the window is considered to be the beginning of the input line by the ACCEPT, INPUT, and LINPUT instructions.

The lower-left corner of the window is considered to be the beginning of the print line by the DISPLAY, DISPLAY USING, PRINT, and PRINT USING instructions.

When the ACCEPT, INPUT, LINPUT, or PRINT USING causes scrolling, scrolling will only occur within the window.

The row and column is the text maximum of the graphic mode you are using.  
 GRAPHICS(1,x) modes row maximum=32, column=24  
 GRAPHICS(2,x) modes row maximum=40, column=24  
 GRAPHICS(3,x) modes row maximum=80, column=24

The CLEAR, GCHAR, HCHAR, VCHAR commands are not affected by the margins setting.

In all modes, the margins can extend to the edges of the screen.

When a program is stopped after MARGINS has been set the listing of the program will be within the window created by MARGINS. A CALL GRAPHICS(x,x) command will then clear the MARGINS.

## Examples

```

100 CALL GRAPHICS(1,1)
200 CALL MARGINS(2,14,2,18)
300 PRINT "H.BEAN PIPER"
400 DISPLAY AT(2,1):"LITTLE FUZZY"
500 CALL HCHAR(1,1,67)
1000 GOTO 1000
(Break to end)
CALL GRAPHICS(1,1)

```

Line 100 sets graphics mode to (1,1).

Line 200 creates a windows top=2, bottom=14, right=2, left=18 within the main screen.

Line 300 prints "H.BEAN PIPER" at the bottom of the window at row=14, column=2

Line 400 displays "LITTLE FUZZY" at the top of the window at row=2, column=2

Line 500 HCHAR ignores the MARGINS window and displays a 'C' at row=1, column=1 outside the window.

After BREAK the CALL GRAPHICS(1,1) clears the margins so that the listing of the program isn't restrained inside the MARGINS window.

```

100 CALL GRAPHICS(2,1)

```

```

200 CALL MARGINS(1,40,1,24)

```

Sets the left, right, top and bottom margins to the extreme edges of the screen in the 40 column Text Mode GRAPHICS(2,1).

```

100 CALL GRAPHICS(3,2)

```

```

200 CALL MARGINS(1,60,3,14)

```

Sets the left, right, top and bottom margins for the graphics 80 column Mode GRAPHICS(3,1).

**MAX****MAX**

## Format

MAX(numeric-expression1,numeric-expression2)

## Type

Numeric (REAL or DEFINT)

## Cross Reference

MIN

## Description

The MAX function returns the larger value of two numeric-expressions.

MAX is the opposite of the MIN function.

If the values of the numeric-expressions are equal, MAX returns that value.

## Examples

```
100 PRINT MAX(3,8)
```

Prints 8.

```
100 F=MAX(3E12,1800000)
```

Sets F equal to 3E12.

```
100 G=MAX(-12,-4)
```

Sets G equal to -4.

```
100 A=7::6=-5
```

```
110 L=MAX(A,B)
```

Sets L equal to 7 when A=7 and B=-5.

## MEMSET

## MEMSET

### Format

CALL MEMSET(array-variable(),expression)

### Cross Reference

DIM, SWAP

### Description

The MEMSET statement will set all elements of the designated numeric or string array to the value of the expression.

Note: MULTI-dimensional arrays require a ',' (comma) in the array-variable() designation for each dimension, I.e. DIM A(2,2) then CALL MEMSET(A(,),NUM) or DIM A(2,2,2) then CALL MEMSET(A(,,),NUM).

### Example

```
100 DIM A$(2,2),C(400)
110 CALL MEMSET(A$(,),"8")
120 PRINT A$(2,1)
130 CALL MEMSET(C),234)
140 PRINT C(1);C(400)
RUN
B
234 234
```

**MERGE****MERGE**

## Format

```
MERGE["]file-specification["]
```

## Cross Reference

SAVE

## Description

The MERGE command combines a program from an external storage device with the program currently in memory. MERGE is frequently used to combine several previously written program segments into one program.

The file-specification is a string constant that indicates the name of the program on the external device. The file-specification can optionally be enclosed in quotation marks.

The lines of the external program are inserted in line-number order among the lines of the program in memory. If a line number in the external program duplicates a line number in the program in memory, the new line replaces the old line.

The MERGE command does not clear break-points.

A program on an external device can be merged only if it was saved with the MERGE option of the SAVE command.

## Example

```
MERGE DSK1.SUB
```

Merges the program SUB into the program currently in memory.

## Program

Listed below is an example of how to merge programs. If the following program is saved on DSK1 as BOUNCE with the merge option, it can be merged with other programs.

```
100 CALL CLEAR
110 RANDOMIZE
140 DEF RN050=INT(RND* 50-25)
150 GOSUB 10000
10000 FOR AA=1 TO 100
10010 QQ=RND50
10020 LL=RND50
10030 CALL MOTION(#1,QQ,LL)
10040 NEXT AA
10050 RETURN
SAVE "DSK1.BOUNCE",MERGE
NEW
```

Place the following program into the computer's memory.

```
120 CALL CHAR(96,"18183CFFFF3C1818")
130 CALL SPRITE(#1,96,7,92,128)
150 GOSUB 500
160 STOP
```

Now merge BOUNCE with the above program.

```
MERGE DSK1.BOUNCE
```

The program that results from merging BOUNCE with the above program is shown here.

```
LIST
100 CALL CLEAR
110 RANDOMIZE
120 CALL CHAR(96,"18183CFFFF3C1818")
130 CALL SPRITE(#1,96,7,92,128)
140 DEF RND50=INT(RND* 50-25)
150 GOSUB 10000
160 STOP
10000 FOR AA=1 TO 100
10010 QQ=RND50
10020 LL=RND50
10030 CALL MOTION(#1,QQ,LL)
10040 NEXT AA
10050 RETURN
```

Note that line 150 is from the program that was merged (BOUNCE), not from the program that was in memory.

**MIN****MIN**

## Format

MIN(numeric-expression1,numeric-expression2)

## Type

Numeric

## Cross Reference

MAX

## Description

The MIN function returns the smaller value of two numeric-expressions. MIN is the opposite of the MAX function.

If the values of the numeric-expressions are equal, MIN returns that value.

## Examples

```
100 PRINT MIN(3,8)
```

Prints 3.

```
100 F=MIN(3E12,1800000)
```

Sets F equal to 1800000.

```
100 G=MIN(-12,-4)
```

Sets G equal to -12.

```
100 A=7::8=-5
```

```
110 L=MIN(A,B)
```

Sets L equal to -5 when A=7 and 8=-5.

## MOD

## MOD

### Format

MOD(numvar1,numvar2)

### Description

MOD computes the arithmetic remainder (MODulo) from the expression numvar1,numvar2. The remainder is then rounded up or down to the nearest integer.

### Example

```
10 FOR I=1 TO 1000
20 R = MOD(I,20)
30 PRINT I,R
40 NEXT I RUN
```

The above program prints to the screen the modulo base 20 of all integers between 1 and 1000.

**MOTION****MOTION**

## Format

CALL MOTION(#sprite-number,vertical-velocity,horizontal-velocity[,...])

## Cross Reference

SPRITE

## Description

The MOTION command enables you to change the velocity of one or more sprites.

The sprite-number is a numeric-expression whose value specifies the number of a sprite as assigned by the SPRITE command.

The vertical- and horizontal-velocity are numeric-expressions whose values range from -128 to 127. If both values are zero, the sprite is stationary. The speed of a sprite is in direct linear proportion to the absolute value of the specified velocity.

A positive vertical-velocity causes the sprite to move toward the bottom of the screen; a negative vertical-velocity causes the sprite to move toward the top of the screen.

A positive-horizontal-velocity causes the sprite to move to the right; a negative horizontal-velocity causes the sprite to move to the left.

If neither the vertical- nor horizontal-velocity are zero, the sprite moves at an angle in a direction and at a speed determined by the velocity values.

When a moving sprite reaches an edge of the screen, it disappears. The sprite reappears in the corresponding position at the opposite edge of the screen.

## Program

The following program illustrates a use of the MOTION command.

```
100 CALL CLEAR
110 CALL SPRITE(#1,33,5,92,124)
120 FOR XVEL=-16 TO 16 STEP 2
130 FOR YVEL=-16 TO 16 STEP 2
140 DISPLAY AT(12,11):XVEL;YVEL
150 CALL MOTION(#1,YVEL,XVEL)
160 NEXT YVEL
170 NEXT XVEL
```

Line 110 creates a sprite.

Line 120 and 130 set values for the motion of the sprite.

Line 150 sets the sprite in motion.

Lines 160 and 170 complete the loops that set the values for the motion of the sprite.

**MOUSE Commands****MOUSE Commands**

The Geneve 9640 supports the industry standard MS mouse interface. Software within the operating system is used to position the mouse on the screen and detect mouse key depressions. The mouse itself is implemented as sprite #0 and therefore sprite #0 should not be used elsewhere in the program when using the mouse. In order to easily interface to these low level routines, Geneve 9640 Advanced BASIC implements a standard set of mouse commands. An example program is given in Appendix L illustrating the use of these commands.

**MOUSE ON**

Turns on mouse interrupt. Mouse buttons are checked at the start of each BASIC statement and mouse movement is enabled.

If a mouse button is pressed, program execution is branched to an "ON MOUSE" subroutine.

The mouse commands are interrupt enabled. Therefore once turned on it will be enacted anytime a mouse movement is detected or a button is pressed.

**MOUSE OFF**

Turns off mouse interrupt checking.

**MOUSE STOP**

Delays action of the mouse button until MOUSE ON statement is encountered.

**ON MOUSE(buttonnum) GOSUB (linenum)**

The program line number of a sub routine is executed when its corresponding button is pressed. This command in interrupt driven therefore needs to be put early in the program and only once per button.

There are three buttons on the Geneve mouse.

Left Button      = 1  
Right Button     = 2  
Center Button    = 3

**CALL MKEY(button1status,button2status,button3status,pxlrow,pxlcol)**

The variables you use for button#status return the following:

-1 button was pressed only once.  
0 button is not being or has not been pressed  
1 button was pressed once since last call

pxlrow and pxlcol return the mouse's position.

**CALL MLOC(pxlrow,pxlcol)**

Returns the location of the row and column when a mouse button was last pressed.

The mouse is always sprite pattern 252. It is also always sprite #0. The mouse shape can be defined by using CALL SCHAR(252,"pattern"). Default color is 16 and can be changed using CALL COLOR(#0,color).

**CALL MREL(px1row,px1col)**

Returns information of row and column when mouse button was released.

**CALL MOUSEDRAW(ON,linecolor)**

Draws a solid line as you move the mouse. The line-color is 1-16 or 1-256 or 1-4 depending on the mode used. The left button controls the drag. MODE(3,2) will usually require a redefined PALETTE for effective use.

**CALL MOUSEDRAW(OFF)**

Reverse mouse drag ON command.

**CALL HIDEMOUSE**

Eliminates mouse cursor.

**CALL SEEMOUSE(px1row,px1col,speed [,color])**

Displays mouse cursor at px1row, px1col. Speed range 1-8. Color option (1-16) is available if using sprite mode 2. See Appendix K.

NOTE: The MOUSEDRAW ON command and ON MOUSE(1) GOSUB CAN NOT be used together. Once the ON MOUSE has been used it stays active even if you issue a new GOSUB to a different line number.

**Example**

```

100 CALL GRAPHICS(3,3)::REM can be (1,1)(1,2)(1,3)(2,2)(2,3)(3,2)(3,3)
110 CALL SCHAR(252,"E0C0A01")
120 MOUSE ON
130 ON MOUSE(1) GOSUB 220::REM Activates in gosub routines
140 ON MOUSE(2) GOSUB 240
150 ON MOUSE(3) GOSUB 250
160 CALL SEEMOUSE(100,100,3,4)
170 CALL MKEY(BUT1,BUT2,BUT3,ROW,COL)
180 DISPLAY AT(15,1):BUT1;BUT2;BUT3;ROW;COL
190 IF ROW>150 THEN 210::REM End program if row greater than 150
200 GOTO 170
210 CALL HIDEMOUSE::MOUSE OFF::END
220 CALL MLOC(ROW1,COL1)::CALL MREL(ROW2,COL2)
230 DISPLAY AT(17,1):TIME$;ROW1;COL1;ROW2;COL2::RETURN
240 DISPLAY AT(19,1):DATE$;"MOUSE KEY 2"::RETURN
250 KEY STOP
260 ON MOUSE(2) GOSUB 220
270 ON MOUSE(3) GOSUB 210
280 CALL MOUSEDRAW(ON,4)
290 RETURN

```

MOUSE(1) REPORTS MLOC and MREL info  
 MOUSE(2) reports date

First time MOUSE(3) eliminates MOUSE(1), redefines MOUSE(2) to report MLOC and MREL and turns on button #1 to activate drawing on the screen. Second press ends program.

**MYART****MYART**

## Format

MYART(path.filename)

## Description

CALL MYART(path.filename) loads and displays a MYART picture.

Graphics mode must match picture graphics resolution before it is called.

Example program to detect graphics mode

```

100 CALL RESETPLT
110 CALL GRAPHICS(3,1)
120 CLS
130 DISPLAY AT(20,10):"MYART path.filename"
140 ACCEPT AT(21,16)BEEP:MY$
150 OPEN #1:MY$,INPUT,DISPLAY,FIXED 128
160 INPUT #1:A$
170 CLOSE #1
180 IF SEG$(A$,2,1)=CHR$(0) THEN 200
190 CALL GRAPHICS(3,3) :: GOTO 210
200 CALL GRAPHICS(2,3)
210 CALL MYART(MY$)
220 CALL KEY(0,K,S) :: IF S<1 THEN 220
230 CALL RESETPLT
240 CALL GRAPHICS(3,1)

```

**NEW****NEW**

## Format

NEW

## Description

The NEW command erases the program currently in memory, so that you can enter a new program.

The NEW command restores the computer to the condition it was in when you selected Geneve 9640 Advanced BASIC from the main selection list with the following exceptions:

The INIT command does not effect the memory available for Geneve 9640 Advanced BASIC programs.

Assembly-language subprograms loaded by the LOAD command remain in memory, but is a separate memory and does not reduce the memory available for Geneve 9640 Advanced BASIC programs.

NEW restores all other default values, closes any open files, and cancels any BREAK command in effect.

**NEXT****NEXT**

Format  
 NEXT control-variable

Cross Reference  
 FOR TO

Description  
 The NEXT instruction marks the end of a FOR-NEXT loop.

You can use NEXT as either a program statement or a command.

The control-variable is the same control-variable that appears in the corresponding FOR TO instruction.

The NEXT instruction is always paired with a FOR TO instruction to form a FOR-NEXT loop (see FOR TO).

A NEXT statement cannot be part of an IF THEN statement.

If NEXT is used as a command, it must be part of a multiple-statement line. A FOR TO instruction must precede it on the same line.

Note: You can not use the NEXT command in an IF...THEN statement.

### Program

The following program illustrates a use of the NEXT statement in lines 130 and 140.

```

100 TOTAL=0
110 FOR COUNT=10 TO 0 STEP -2
120 TOTAL=TOTAL+COUNT
130 NEXT COUNT
140 FOR DELAY=1 TO 100::NEXT DELAY
150 PRINT TOTAL,COUNT;DELAY
RUN
30          -2 101
```

**NUMBER****NUMBER**

## Format

NUMBER [initial-line-number][,increment]

NUM

## Description

The NUMBER command puts the computer in Number Mode, so that it automatically generates line numbers for your program.

If you enter an initial-line-number, the first line number displayed is the one you specify. If you do not specify an initial-line-number, the computer starts with line number 100.

Succeeding line numbers are generated by adding the value of the numeric expression increment to the previous line number. To specify increment only (without specifying an initial-line-number), you must precede the increment with a comma. The default increment is 10.

If a line number generated by the NUMBER command is the number of a line already in the program in memory, the existing program line is displayed with the line number. To indicate that the displayed line is an existing program line, the prompt symbol (>) that normally appears to the left of the line number is not displayed. When the computer displays an existing program line, you can either edit the line or press ENTER to leave the line unchanged.

If you enter a program line that contains an error, the appropriate error message is displayed, and the same line number appears again, enabling you to retype the line correctly.

If the next line number to be generated is greater than 32767, the computer leaves Number Mode.

To leave Number Mode, press ESC. If the computer is displaying only a line number (that is, a line number not followed by any characters), you can leave Number Mode by pressing ENTER, UP ARROW, DOWN ARROW.

## Special Editing Keys in Number Mode

In Number Mode, you can use the editing keys whether you are changing existing program lines or entering new ones.

LEFT ARROW --Pressing LEFT ARROW moves the cursor one character position to the left. When the cursor moves over a character, it does not change or delete it.

RIGHT ARROW --Pressing RIGHT ARROW moves the cursor one character position to the right. When the cursor moves over a character, it does not change or delete it.

INS --Pressing INS enables you to insert characters at the cursor position. characters that you type are inserted until you press one of the other special editing keys. The character at the cursor position and all characters to the right of the cursor move to the right as you type. You may lose characters if they move so far to the right that they are no longer in the program line.

DEL --Pressing DEL deletes the character in the cursor position. All Characters to the right of the cursor move to the left.

ERASE (Ctrl C) --Pressing ERASE erases the program line currently displayed (including the line number). The program line is erased only from the screen, not from memory.

REDO (Alt + F8) --Pressing REDO causes the program line or other text most recently input to be displayed. This line can be especially helpful if you make an error while editing a program line, causing the computer not to accept it. Pressing REDO displays the original line so that you can make corrections without having retype the entire line. When you press REDO, the computer leaves Number Mode and enters Edit Mode.

ESC (Ctrl +Break) --Pressing ESC causes the computer to leave Number Mode. If you were entering a new program line, it is not accepted. If you were changing an existing program line, any changes that you made are ignored.

ENTER --If you press ENTER when the computer is displaying only a line number (that is, a line number not followed by any characters), the computer leaves Number Mode. If the line number is the number of an existing program line, that program line is not changed or deleted.

If you press ENTER when the computer is displaying a line number followed by a program line, that line is accepted and the next line number is generated. The displayed line may be a new line that you have entered, an existing program line that you have not changed, or an existing program line that you have edited.

UP ARROW --UP ARROW works exactly the same as ENTER in Number Mode.

DOWN ARROW --DOWN ARROW works exactly the same as ENTER in Number Mode.

## Example

In the following, what you type is UNDERLINED. Press ENTER after each line.  
 NUM instructs the computer to number starting at 100 with increments of 10.

NUM

100 X=4  
 110 Z=10  
 120

NUM 110

110 Z=11  
 120 PRINT (Y+X)/Z  
 130

NUM 105,5

105 Y=7  
 110 Z=11  
 115

LIST

100 X=4  
 105 Y=7  
 110 Z=11  
 120 PRINT (X+Y)/Z

NUM 110 instructs the computer to number starting at 110 with increments of 10. Change line 110 to Z=11.

NUM 105,5 instructs the computer to number starting at line 105 with increments of 5. Line 110 already exists.

**OLD****OLD**

## Format

OLD ["]file-specification["]

## Cross Reference

SAVE

## Description

The OLD command loads a program from an external storage device into memory.

The file-specification indicates the name of the program to be loaded from the external device. The file-specification, a string constant, can optionally be enclosed in quotation marks.

The program to be loaded can be one of the following:

A saved Geneve 9640 Advanced BASIC program.

A file in DISPLAY VARIABLE 80 format, created by the LIST command or a text editing or word processing program.

A specially prepared assembly-language program that executes automatically when it is loaded.

Before the program is loaded, all open files are closed. The program currently in memory is erased after the program begins to load. For more information see "Loading an Existing Program".

## Protected and Unprotected Programs

To execute an unprotected Geneve 9640 Advanced BASIC program that has been loaded into memory, enter the RUN command when the cursor appears. You can use the LIST command to display the program or any portion of the program.

If the program was saved using the PROTECTED option of the SAVE command, it starts executing automatically when it is loaded. When the program ends (either normally or because of an error) or stops at a break-point, it is erased from memory.

## Examples

OLD CSI

Displays instructions and then loads into the computer's memory a program from a cassette recorder.

OLD "DSK1.MYPROG"

Loads into the computer's memory the program MYPROG from diskette in disk drive one.

OLD DSK.DISK3.UPDATE85

Loads into the computer's memory the program UPDATE85 from the diskette named DISK3.

**ON BREAK****ON BREAK**

## Format

ON BREAK STOP

ON BREAK NEXT

## Cross Reference

BREAK

## Description

The ON BREAK statement enables you to specify the action you want the computer to take when either a break-point is encountered or CLEAR is pressed.

If you enter the STOP option, or if your program does not include an ON BREAK statement, program execution stops when a break-point is encountered or CLEAR is pressed.

If you enter the NEXT option, program execution continues normally (with the next program statement) when a break-point is encountered or CLEAR is pressed. If you press CLEAR while the computer is performing an input or an output operation with certain external devices, an error condition occurs, causing the program to halt. When the NEXT option is in effect, pressing CTL-ALT-DEL is the only way to interrupt your program. However, by doing so, you perform a "reboot" of the system therefore erasing the program in memory and causing you to exit from Geneve 9640 Advanced BASIC without closing any open files, possibly causing the loss of data in those files.

ON BREAK does not affect a break-point that occurs when a BREAK statement with no line-number-list is encountered in a program.

## Program

The following program illustrates the use of ON BREAK.

```

100 CALL CLEAR
110 BREAK 150
120 ON BREAK NEXT
130 BREAK
140 FOR A=1 TO 50
150 PRINT "CLEAR IS DISABLED."
160 NEXT A
170 ON BREAK STOP
180 FOR A=1 TO 50
190 PRINT "NOW IT WORKS."
200 NEXT A

```

Line 110 sets a break-point at line 150.

Line 120 sets break-point handling to go to the next line.

A break-point occurs at line 130 despite line 120, because no line number has been specified after BREAK. Enter CONTINUE.

No break-point occurs at line 150 because of line 120; CLEAR has no effect during the execution of lines 140 through 160 because of line 120. Line 170 restores the normal use of CLEAR.

**ON ERROR****ON ERROR**

## Format

ON ERROR STOP

ON ERROR line-number

## Cross Reference

ERR, GOSUB, RETURN

## Description

The ON ERROR statement enables you to specify the action you want the computer to take if a program error occurs.

If you enter the STOP option, or if your program does not include an ON ERROR statement, program execution stops when a program error occurs.

If you enter a line-number, a program error causes program control to be transferred to the subroutine that begins at the specified line-number. A RETURN statement in the subroutine returns control to a specified program statement.

When an error transfers control to a subroutine, the line-number option is canceled. If you wish to restore it, your program must execute an ON ERROR line-number statement again.

The ON ERROR line-number statement does not transfer control when the error is caused by a RUN statement.

Note: Exiting an ON ERROR command before its RETURN may give unexpected results.

## Program

The following program illustrates a use of ON ERROR.

```

100 CALL CLEAR
110 DATA "A","4","B","C"
120 ON ERROR 190
130 FOR G=1 TO 4
140 READ X$
150 X=VAL(X$)
160 PRINT X;"SQUARED IS";X*X
170 NEXT G
180 STOP
190 REM ERROR SUBROUTINE
200 ON ERROR 230
210 X$="5"
220 RETURN
230 REM SECOND ERROR
240 CALL ERR(CODE,TYPE,SEVER,LINE)
250 PRINT "ERROR";CODE;" IN LINE";LINE
260 RETURN 170

```

Line 120 causes any error to pass control to line 190

Line 130 begins a loop. An error occurs in line 150 and control passes to line 190.

Line 200 causes the next error to pass control to line 230.

Line 210 changes the value of X\$ to an acceptable value. Line 220 returns control to the line in which the error occurred (line 150).

The second time an error occurs, the SECOND ERROR subroutine is called because of line 200. Line 240 obtains specific information about the error by using CALL ERR. Line 250 reports the nature of the error, and line 260 returns control to line 170 of the main program, which begins the next iteration of the loop.

When the third error occurs, the message Bad Argument in 150 is displayed because the program does not specify what action to take if another error occurs. Program execution ceases.

## ON GOSUB

## ON GOSUB

### Format

ON numeric-expression;GOSUB; line-number-list  
GOSUB

### Cross Reference

GOSUB, RETURN

### Description

The ON GOSUB statement enables you to transfer conditional program control to one of several subroutines.

The value of the numeric-expression determines to which of the line numbers in the line-number-list program control is transferred.

If the value of the numeric-expression is 1, program control is transferred to the subroutine that begins at the program statement specified by the first line number in the line-number-list; if the value of the numeric-expression is 2, program control is transferred to the subroutine that begins at the program statement specified by the second line number in the line-number-list; and so on.

If necessary, the value of the numeric-expression is rounded to the nearest integer. The value of the numeric-expression must be greater than or equal to 1 and less than or equal to the number of line numbers in the line-number-list.

The line-number-list consists of one or more line numbers separated by commas. Each line number specifies a program statement at which a subroutine begins.

Use a RETURN statement to return program control to the statement immediately following the ON GOSUB statement that called the subroutine.

To avoid unexpected results, it is recommended that you exercise special care if you use ON GOSUB to transfer control to or from a subprogram or into a FOR-NEXT loop.

### Examples

```
100 ON X GOSUB 1000,2000,300
```

Transfers control to 1000 if X is 1, 2000 if X is 2, and 300 if X is 3.

```
100 ON P-4 GOSUB 200,250,300,800,170
```

Transfers control to 200 if P-4 is 1 (P is 5), 250 if P-4 is 2, 300 if P-4 is 3, 800 if P-4 is 4, and 170 if P-4 is 5.

## Program

The following program illustrates a use of ON GOSUB.

```
100 CALL CLEAR
110 DISPLAY AT(11,1):"CHOOSE ONE OF THE FOLLOWING:"
120 DISPLAY AT(13,1):"1 ADD TWO NUMBERS."
130 DISPLAY AT(14,1):"2 MULTIPLY TWO NUMBERS."
140 DISPLAY AT(15,1):"3 SUBTRACT TWO NUMBERS."
150 DISPLAY AT(16,1):"4 EXIT PROGRAM."
160 DISPLAY AT(20,1):"YOUR CHOICE:"
170 DISPLAY AT(22,2):"FIRST NUMBER."
180 DISPLAY AT(23,1):"SECOND NUMBER."
190 CALL MARGIN(3,30,1,24)
200 ACCEPT AT(20,14)VALIDATE(DIGIT):CHOICE
210 IF CHOICE<1 OR CHOICE>4 THEN 200
220 IF CHOICE=4 THEN STOP
230 ACCEPT AT(22,16)VALIDATE(NUMERIC):FIRST
240 ACCEPT AT(23,16)VALIDATE(NUMERIC):SECOND
250 CALL MARGIN(3,30,1,8)
260 ON CHOICE GOSUB 280,300,320
270 GOTO 190
280 DISPLAY AT(3,1)ERASE ALL:FIRST;"PLUS";SECOND;"EQUALS";FIRST+SECOND
290 RETURN
300 DISPLAY AT(3,1)ERASE ALL:FIRST;"TIMES";SECOND;"EQUALS";FIRST*SECOND
310 RETURN
320 DISPLAY AT(3,1)ERASE ALL:FIRST;"MINUS";SECOND;"EQUALS";FIRST-SECOND
330 RETURN
```

Line 260 determines where to go according to the value of CHOICE.

## ON GOTO

## ON GOTO

### Format

ON numeric-expression GOTO line-number-list  
GOTO

### Cross Reference

GOTO

### Description

The ON GOTO statement enables you to transfer unconditional program control to one of several program statements.

The value of the numeric-expression determines to which of the line numbers in the line-number-list program control is transferred. If the value of the numeric-expression is 1, program control is transferred to the program statement specified by the first line number in the line-number-list; if the value of the numeric-expression is 2, program control is transferred to the program statement specified by the second line number in the line-number-list; and so on.

If necessary, the value of the numeric-expression is rounded to the nearest integer. The value of the numeric-expression must be greater than or equal to 1 and less than or equal to the number of line numbers in the line-number-list.

The line-number-list consists of one or more line numbers separated by commas. Each line number specifies a program statement.

To avoid unexpected results, it is recommended that you exercise care if you use ON GOTO to transfer control to or from a subroutine or a subprogram or into a FOR-NEXT loop.

### Examples

```
100 ON X GOTO 1000,2000,300
```

Transfers control to 1000 if X is 1, 2000 if X is 2, and 300 if X is 3. The equivalent statement using an IF-THEN-ELSE statement is IF X=1 THEN 1000 ELSE IF X=2 THEN 2000 ELSE IF X=3 THEN 300 ELSE PRINT "ERROR!":STOP.

```
100 ON P-4 GOTO 200,250,300,800,170
```

Transfers control to 200 if P-4 is 1 (P is 5), 250 if P-4 is 2, 300 if P-4 is 3, 800 if P-4 is 4, and 170 if P-4 is 5.

## Program

The following program illustrates a use of ON GOTO. Line 260 determines where to go according to the value of CHOICE.

```
100 CALL CLEAR
110 DISPLAY AT(11,1):"CHOOSE ONE OF THE FOLLOWING:"
120 DISPLAY AT(13,1):"1 ADD TWO NUMBERS."
130 DISPLAY AT(14,1):"2 MULTIPLY TWO NUMBERS."
140 DISPLAY AT(15,1):"3 SUBTRACT TWO NUMBERS."
150 DISPLAY AT(16,1):"4 EXIT PROGRAM."
160 DISPLAY AT(20,1):"YOUR CHOICE:"
170 DISPLAY AT(22,2):"FIRST NUMBER:"
180 DISPLAY AT(23,1):"SECOND NUMBER:"
190 CALL MARGIN(3,30,1,24)
200 ACCEPT AT(20,14)VALIDATE(DIGIT):CHOICE
210 IF CHOICE<1 OR CHOICE>4 THEN 200
220 IF CHOICE=4 THEN STOP
230 ACCEPT AT(22,16)VALIDATE(NUMERIC):FIRST
240 ACCEPT AT(23,16)VALIDATE(NUMERIC):SECOND
250 CALL MARGIN(3,30,1,8)
260 ON CHOICE GOTO 270,290,310
270 DISPLAY AT(3,1)ERASE ALL:FIRST;"PLUS";SECOND;"EQUALS";FIRST+SECOND
280 GOTO 190
290 DISPLAY AT(3,1)ERASE ALL:FIRST;"TIMES";SECOND;"EQUALS";FIRST*SECOND
300 GOTO 190
310 DISPLAY AT(3,1)ERASE ALL:FIRST;"MINUS";SECOND;"EQUALS";FIRST-SECOND
320 GOTO 190
```

## ON WARNING

## ON WARNING

### Format

```
ON WARNING PRINT
                STOP
                NEXT
```

### Description

The ON WARNING statement enables you to specify the action you want the computer to take if a warning condition occurs during the execution of your program.

A warning, a condition caused by invalid input or output, does not normally cause program execution to be terminated.

If you enter the PRINT option, or if your program does not include an ON WARNING statement, the computer displays a warning message when a warning condition occurs during program execution.

If you enter the STOP option, program execution stops when a warning condition occurs during program execution.

If you enter the NEXT option, program execution continues normally when a warning condition occurs and no warning message is displayed. Normally, execution continues beginning with the next program statement; however, if the cause of the warning is an invalid response to an INPUT statement, program execution continues beginning with that same INPUT statement.

You may have multiple ON WARNING statements in the same program.

### Program

The following program illustrates a use of ON WARNING.

```
100 CALL CLEAR
110 ON WARNING NEXT
120 PRINT 120,5/0
130 ON WARNING PRINT
140 PRINT 140,5/0
```

```
150 ON WARNING STOP
160 PRINT 160,5/0
170 PRINT 170
RUN
120 9.99999E+**
140 * WARNING NUMERIC OVERFLOW IN 140 9.99999E+"
160 * WARNING NUMERIC OVERFLOW IN 160
```

Line 110 sets warning handling to go to the next line. Line 120 therefore prints the result without any message.

Line 130 sets warning handling to the default, printing the message and then continuing execution. Line 140 therefore prints 140, then the warning, and then continues.

Line 150 sets warning handling to print the warning message and then stop execution. Line 160 therefore prints 160 and the warning message and then stops.

**OPEN****OPEN**

## Format

```
OPEN #file-number:file-specification[ file-organization[ size]]
[,file-type][,open-mode][,record-type[ record-length]]
```

## Cross Reference

CLOSE, INPUT, PRINT

## Description

The OPEN instruction establishes an association between the computer and an external device, enabling you to store, retrieve, and process data.

The file-number is a numeric-expression having a value between 1 and 255. The file-number is assigned to the external file or device indicated by the file-specification so that input/output processing instructions may refer to the file by its file-number. While a file is open, its file-number cannot be assigned to another file. However, you may have more than one file open to a device at one time. File-number 0 always refers to the keyboard and screen of your computer, and is always open. You cannot open or close file-number 0.

If necessary, the file-number is rounded to the nearest integer.

The file-specification is a string-expression; if you use a string constant, you must enclose it in quotation marks.

## Options

The following options may be entered in any order.

The file-organization specifies whether records are to be accessed sequentially or randomly. Enter SEQUENTIAL for sequential access, or RELATIVE for random access. Records in a sequential-access file are read or written in sequence from beginning to end. Records in a random-access (relative-record) file can be accessed in any order (they can be processed randomly or sequentially.)

If you do not specify a file-organization, it is assumed to be SEQUENTIAL.

You can optionally specify the initial size of the file. Size is a numeric-expression, the value of which specifies the initial number of records in the file. Note: The size option cannot be used with all peripherals.

The file-type specifies the format of data in the file.

INTERNAL--The computer transfers data in binary format. This is the most efficient method of sending data.

DISPLAY--The computer transfers data in ASCII format. DISPLAY

files can only use FIXED records of 64 or 128. If no file-type is specified in OPEN, the default is DISPLAY.

DISPLAY type files require a special kind of output record. Each element in the PRINT field must be separated by a comma enclosed in quotation marks. The comma serves as a field separator in the file. The omission of this comma causes an I/O error. Note: This is not the same as a print separator, which must be inserted between an element in the PRINT field and the field separator.

The open-mode specifies the input/output operations that can be performed on the file.

INPUT--The computer can only read data from the file. OUTPUT--

The computer can only write data to the file. UPDATE--The computer can both read from and write to the file.

APPEND--The computer can only write data and only at the end of the file; records already in the file cannot be accessed.

If you open an existing file for OUTPUT, the data items you write to the file replace those currently in the file.

If you do not specify an open-mode, it is assumed to be an UPDATE.

The record-type specifies whether the records in the file are FIXED (all of the same length) or VARIABLE (of various lengths).

SEQUENTIAL files can have FIXED or VARIABLE records. If you do not specify the record-type of a SEQUENTIAL file, it is assumed to be VARIABLE.

RELATIVE files must have FIXED records. If you do not specify the record-type of a RELATIVE file, it is assumed to be FIXED.

You can optionally specify the length of records in the file. Record-length is a numeric-expression, the value of which specifies the fixed size (for FIXED records) or maximum size (for VARIABLE records) of each record.

If you do not specify a record-length, its value is supplied by the peripheral.

If you open a file that does not exist, a file is created with the options you specify. If you open a file that does exist, the options you specify must be the same as the options that you specified when you created the file, except that a file with FIXED records can be opened as either SEQUENTIAL or RELATIVE, regardless of the file-organization that you specified when you created the file.

For more information about the options available with a particular device, refer to the owner's manual that comes with that device.

### Examples

```
100 OPEN #1:"CS1",OUTPUT,FIXED
```

Opens a file on cassette. The file is SEQUENTIAL, with data stored in DISPLAY format. The file is opened in OUTPUT mode with FIXED length records of 64 bytes.

```
300 OPEN #23:"DSK.MYDISK.X",RELATIVE 100,INTERNAL,FIXED,UPDATE
```

Opens a file named "X". The file is on the diskette named MYDISK in whichever drive that diskette is located. The file is RELATIVE, with data kept in INTERNAL format with FIXED length records of 80 bytes. The file is opened in UPDATE mode and starts with 100 records made available for it.

```
100 OPEN #234:A$,INTERNAL
```

where A\$ equals "DSK2.ABC", assumes a file on the diskette in drive 2 with a name of ABC. The file is SEQUENTIAL, with data kept in INTERNAL format. The file is opened in UPDATE mode with VARIABLE length records that have a maximum length of 80 bytes.

### Program

The following program illustrates a use of the SIZE option in an OPEN statement.

```
100 OPEN #1:"DSK1.LARGE",RELATIVE
110 PRINT #1,REC 100:0
120 CLOSE #1
130 OPEN #1:"DSK1.LARGE",SEQUENTIAL,FIXED
200 CLOSE #1
```

Line 100 opens a RELATIVE file on diskette.

Line 110 writes to the 100th record, thereby reserving space for 100 contiguous records.

Line 120 closes the file.

Line 130 reopens the file, this time with SEQUENTIAL file organization.

Line 200 closes the file.

**OPTION BASE****OPTION BASE**

## Format

OPTION BASE 0 or 1

## Cross Reference

DIM

## Description

The OPTION BASE statement enables you to set the lower limit of array subscripts.

You can use the OPTION BASE statement to specify a lower array-subscript limit of either 0 or 1. If your program does not include an OPTION BASE statement, the lower limit is set to 0.

The OPTION BASE statement applies to every array in your program. You can have only one OPTION BASE statement in a program.

If you do not set the lower array-subscript limit to 1, the computer reserves memory for element 0 of each dimension of each array. To avoid reserving unnecessary memory, it is recommended that you set the lower limit to 1 if your program does not use element 0.

The OPTION BASE statement must have a lower line number than any DIM statement or any reference to an array in your program. The OPTION BASE statement is evaluated during pre-scan and is not executed.

The OPTION BASE statement cannot be part of an IF THEN statement.

## Example

100 OPTION BASE 1

Sets the lowest allowable subscript of all arrays to one.

## OUTP

## OUTP

### Format

CALL OUTP(port,databyte)

### Cross Reference

INP

You may use CALL OUTP either as a program statement or a command.

Use only ports 1 or 2 as the PIO or PIO/2 ports respectively.

Sends a databyte to a port.

The databyte may be any integer between 0 and 255.

Data is received and sent internally through various components within the computer, known as ports.

The OUTP statement is used to obtain direct control of a device such as the keyboard, sound, etc.

OUTP is the complement function to the INP command.

## PALETTE

## PALETTE

### Format

CALL

PALETTE(#color,redvalue,bluevalue,greenvalue[,#color2,redvalue2,bluevalue2,greenvalue2,...])

### Cross Reference

TCOLOR,RESETPLT

### Description

Mixes a new color from redvalue, bluevalue, greenvalue to one of the 16 standard #color registers.

each color value are from 8-light to 1-dark

GRAPHICS(3,2) which is limited to the first four color registers (See CALL GRAPHICS).

### Examples

```
100 CALL GRAPHICS(1,2)
200 CALL PALETTE(16,1,1,1)
300 CALL TCOLOR(16,7)
400 PRINT "WHITE NOW BLACK TEXT ON RED"
```

Note: this will permanently change the text color even after exiting ABASIC back to MDOS.

**PATTERN****PATTERN**

## Format

CALL PATTERN(#sprite-number,character-coed[....])

## Cross Reference

CHAR, MAGNIFY, SPRITE

## Description

The PATTERN command enables you to change the pattern on one or more sprites.

The sprite-number is a numeric-expression whose value specifies the number of the sprite as assigned in the SPRITE command.

Character-code is a numeric-expression with a value from 0-255, specifying the character number of the character you want to use as the pattern for a sprite.

If you use the MAGNIFY command to change to double-sized sprites, the sprite definition includes the character specified by the character-code and three additional characters (See MAGNIFY.)

## Program

The following program illustrates a use of the PATTERN command.

```

100 CALL CLEAR
110 CALL COLOR(12,16,16)
120 FOR A=19 TO 24
130 CALL HCHAR(A,1,120,32)
140 NEXT A
150 A$="0171821214141FFFFF4141212119070080E09884848282FFFFF8282848498E000"
160 B$="01061820305C4681814246242C180700806018342462428181623A0C0418E000"
170 C$="0106182C2446428181465C3020180700806018040C3A6281814262243418E000"
180 CALL CHAR(244,A$,248,B$,252,C$)
190 CALL SPRITE(#1,244,5,130,1,0,8)
200 CALL MAGNIFY(3)
210 FOR A=244 TO 252 STEP 4
220 CALL PATTERN(#1,A)
230 FOR DELAY=1 TO 5 :: NEXT DELAY
240 NEXT A
250 GOTO 210
(Press CLEAR to stop program.)

```

Lines 110 through 140 build a floor.

Lines 150 through 180 define characters 244 through 255.

Line 190 creates a sprite in the shape of a wheel and starts it moving to the right.

Line 200 makes the sprite double-sized.

Lines 210 through 250 make the spokes of the wheel appear to move as the character displayed is changed.

**PEEK****PEEK**

Format CALL PEEK(address, numeric-variable-list[, "", address, numeric-variable-list[, ...]])

**Cross Reference**

LOAD, PEEKV, POKEV, VALHEX

**Description**

The PEEK command enables you to ascertain the contents of specified CPU memory addresses.

You can use the PEEKV command to ascertain the contents of VDP memory.

The address is a numeric-expression whose value specifies the first CPU (Central Processing Unit) memory address at which you want to peek.

The address must have a value from -32768 to 32767 inclusive.

You can specify an address from 0 to 32767 inclusive by specifying the actual address.

You can specify an address from 32768 to 65535 inclusive by subtracting 65536 from the actual address. This will result in a value from -32768 to -1 inclusive.

If you know the hexadecimal value of the address, you can use the VALHEX function to convert it to a decimal numeric-expression, eliminating the need for manual calculations.

If necessary, the address is rounded to the nearest integer.

The numeric-variable-list consists of one or more numeric-variables separated by commas. Bytes of data starting from the specified CPU memory address are assigned sequentially to the numeric-variables in the numeric-variable-list.

One byte, with a value from 0 to 255 inclusive, is returned to each specified numeric-variable.

You can specify multiple addresses and numeric-variable-lists by entering a null string (two adjacent quotation marks) as a separator between a numeric-variable-list and the next address.

If you call the PEEK command with invalid parameter, the computer may function erratically or cease to function entirely. If this occurs, turn off the computer, wait several seconds, and then turn the computer back on again.

## Examples

```
100 CALL PEEK(8192,X1,X2,X3,X4)
```

Returns the values in memory locations 8192, 8193, 8194, and 8195 in the variables X1, X2, X3, and X4, respectively.

```
100 CALL PEEK(22433,A,B,C,"",-4276,X,Y,Z)
```

Returns the values in locations 22433, 22434, and 22435 in A, B, C, respectively; and the values in locations 61260, 61261, and 61263 in X, Y, and Z, respectively.

```
100 CALL PEEK(VALHEX("4F55"),V1,V2,V3)
```

Uses VALHEX to ascertain the decimal equivalent of the hexadecimal number 4F55, which is 20309. Then the values in locations 20309, 20310, and 20311 are returned in V1, V2, and V3, respectively.

## Program

The following program returns in A the number of the highest numbered sprite (#15) currently in use. A zero is returned to B, because no sprites are defined after the DELSPRITE statement.

```
100 CALL CLEAR
110 CALL SPRITE(#15,33,7,100,100,0,0)
120 CALL PEEK(VALHEX("837A"),A)
130 CALL DELSPRITE(ALL)
140 CALL PEEK(VALHEX("837A"),B)
150 PRINT A,B
```

**PEEKV****PEEKV**

## Format

```
CALL PEEKV(address,numeric-variable-list[,",",address,
numeric-variable-list[,...])
```

## Cross Reference

LOAD, PEEK, POKEY, VALHEX

## Description

The PEEKV command enables you to ascertain the contents of specified VDP memory addresses. You can use the PEEK command to ascertain the contents of CPU memory.

The address is a numeric-expression whose value specifies the first VDP (Video Display Processor) memory address at which you want to peek.

The address must have a value from 0 to 16383 inclusive.

If you know the hexadecimal value of the address (0000-3FFF), you can use the VALHEX function to convert it to a decimal numeric-expression.

If necessary, the address is rounded to the nearest integer.

The numeric-variable-list consists of one or more numeric-variables separated by commas. Bytes of data starting from the specified VDP memory address are assigned sequentially to the numeric-variables in the numeric-variable-list.

One byte, with a value from 0 to 255 inclusive, is returned to each specified numeric-variable.

You can specify multiple addresses and numeric-variable-lists by entering a null string (two adjacent quotation marks) as a separator between a numeric-variable-list and the next address.

If you call the PEEKV command with invalid parameters, the computer may function erratically. If this occurs, turn off the computer, wait several seconds, then turn the computer back on.

## Example

```
100 CALL PEEKV(6300,A1,A2,A3)
```

Returns the values in locations 6300, 6301, and 6302 in A1, A2, and A3, respectively.

The following program illustrates a use of the PEEKV command.

```
100 CALL CLEAR
110 CALL POKEV(32* 16+12,66)
120 CALL PEEKV(32* 16+12,A)
130 PRINT A
```

Line 110 pokes a "B" into a location that causes it to appear of in the middle of the screen. Line 120 peeks at that location, and assigns the value found there (66) to the variable A.

The next program starts a sprite moving diagonally across the screen. Line 120 assigns the values of the row and column coordinates of and X and Y respectively.

```
100 CALL CLEAR
110 CALL SPRITE(#1,33,5,100,100,25,25)
120 CALL PEEKV(VALHEX("300"),X,Y)
130 DISPLAY AT(24,1):Y;X
140 GOTO 120
(Press CLEAR to stop the program.)
```

## PI --Function--Pi

Format  
PI

Type  
REAL

Description  
The PI function returns the value of pi.

The value of pi is 3.14159265359.

Example

```
100 VOLUME=4/3*PI*6^3
Sets VOLUME equal to four-thirds times pi times six cubed,
which is the volume of a sphere with a radius of six.
```

**POINT****POINT**

## Format

```
CALL POINT(pixel-type,pixel-row,pixel-column[,pixel-row,pixel-column2[,...]])
```

## Cross Reference

CIRCLE, DCOLOR, DRAW, DRAWTO, FILL, GCHAR, GRAPHICS, RECTANGLE

## Description

The POINT command enables you to place, or erase specific points (pixels) on the screen, one or more at a time.

Pixel-type is a numeric-expression whose value specifies the action taken by the POINT command.

TYPE	ACTION
2 (pixel).	Reverses the status of the specified point (If a pixel is on, it is turned off; if a pixel is off, it is turned on). This effectively reverses the color of the specified pixel.
1	Places a point, of the foreground-color specified by the DCOLOR command, at a specified pixel-row and pixel-column. This is accomplished by turning on the pixel at the designated row and column.
0	Erases a point at a specified pixel-row and pixel-column. This is accomplished by turning on the pixel at the designated row and column.

Pixel-row and pixel-column are numeric-expressions whose values represent the screen position where the point will be placed (turned on or off).

You can optionally place more points by specifying additional sets of pixels.

Pixel-row and pixel-column must be within the range of the particular graphics mode of the screen.

The last pixel-row/pixel-column you specify becomes the current position used by the DRAWTO command.

Note: POINT cannot be used in GRAPHICS(1,1),(2,1) & (3,1)

## Example

```
100 CALL POINT(1,96,128)
Turns on a single pixel in the center of the screen.
```

**POKEV****POKEV****Format**

CALL POKEV(address,byte-list[,","",address,byte-list[,...]])

**Cross Reference**

LOAD, PEEK, PEEKV, VALHEX

**Description**

The POKEV command enables you to assign values directly to specified VDP memory addresses.

You can use the LOAD command to assign values to CPU.

The address is a numeric-expression whose value specifies the first VDP(Video Display Processor) memory address where data is to be poked. If the byte-list specifies more than one byte of data, the bytes are assigned to sequential memory addresses starting with the address you specify.

The address must have a value from 0 to 16383 inclusive.

If you know the hexadecimal value of the address (>0000->3FFF), you can use the valhex function to convert it to a decimal numeric-expression.

If necessary, the address is rounded to the nearest integer.

The byte-list consists of one or more bytes of data, separated by commas, that are to be poked into VDP memory starting with the specified address.

Each byte in the byte-list must be a numeric-expression with a value from 0 to 32767. If the value of a byte is greater than 255, it is repeatedly reduced by 256 until it is less than 256. If necessary, a byte is rounded to the nearest integer.

You can specify multiple addresses and byte-lists by entering a null string(two adjacent quotation marks) as a separator between a byte-list and the next address.

If you call the POKEV command with invalid parameters the computer may function erratically. If this occurs, turn off the computer, wait several seconds, then turn the computer back on.

**Examples**

100 CALL POKEV(3333,233)  
Pokes the value 233 into location 3333.

100 CALL POKEV(13784,273)  
Pokes the value 17 (273 reduced by 256 once) into location 13784.

100 CALL POKEV(7343,246,"",VALHEX("2E4F"),433)  
Pokes the value 246 into location 7343, and uses VALHEX to ascertain the decimal value equivalent of the hexadecimal number 2E4F (11855). The value 177(433 reduced by 256 once) is then poked into this location.

### Program

The following program uses POKEV to display on the screen the characters that correspond to ASCII codes 65 through 255, at the specified by line 130.

```
1 CALL GRAPHICS(1,1)
100 CALL CLEAR :: X=0
110 FOR R=0 TO 23
120 FOR C=0 TO 31 STEP 3
130 CALL POKEV(R*32+C)+1024,X)
140 X=X+1::NEXT C :: NEXT R
```

**POS****POS**

## Format

POS(string-expression,substring,numeric-expression)

## Type

DEFINT

## Description

The POS function returns the position of the first occurrence of a substring within a specified string.

The string-expression specifies the string within which you are seeking the substring. If you use a string constant, it must be enclosed in quotation marks.

The substring is the segment (of the string-expression) you are trying to locate. The substring is a string-expression; if you use a string constant, it must be enclosed in quotation marks.

The value of the numeric-expression specifies the character position in the string-expression where the search for the substring begins.

If necessary, the value of the numeric-expression is rounded to the nearest integer.

If the substring is present within the string-expression, POS returns the number of the character position (within the string-expression) of the first character of the substring.

If the substring is not present, or if the value of the numeric-expression is greater than the number of characters in the string-expression, POS returns a zero.

## Examples

```
100 X=POS("PAN","A",1)
```

Sets X equal to 2 because A is the second letter in PAN.

```
100 Y=POS("APAN","A",2)
```

Sets Y=3 because the A in the third position in APAN is the first occurrence of A in the portion of APAN that was searched.

```
100 Z=POS("PAN","A",3)
```

Sets Z equal to 0 because A was not in the part of PAN that was searched.

```
100 R=POS("PABNAN","AN",1)
```

Sets R equal to 5 because the first occurrence of AN starts with the A in the fifth position in PABNAN.

## Program

The following program illustrates a use of POS. Input is searched for spaces, and is then printed with each word on a single line.

```
100 CALL CLEAR
110 PRINT "ENTER A SENTENCE."
120 LINPUT X$
130 S=POS(X$," ",1)
140 IF S=0 THEN PRINT X$::PRINT::GOTO 110
150 Y$=SEG$(X$,1,5)::PRINT Y$
160 X$=SEG$(X$,S+1,LEN(X$))
170 GOTO 130
(Press CLEAR to stop the program.)
```

**POSITION****POSITION**

## Format

CALL POSITION(#sprite-number,numeric-variable1,numeric-variable2[,...])

## Cross Reference

SPRITE

## Description

The POSITION command enables you to ascertain the current position of one or more sprites.

The sprite-number is a numeric-expression whose value specifies the number of the sprite as assigned in the SPRITE command.

The current screen position of a sprite is returned as two numeric-variables representing the pixelrow and pixelcol, respectively, specifying the position of a screen pixel.

The screen position of the pixel in the upper-left corner of a sprite is considered to be the position of that sprite.

Note that a sprite in motion continues to move during and following the execution of the POSITION command. Remember to allow for this continued motion in your program.

## Example

```
100 CALL POSITION(#1,Y,X)
```

Returns the position of the upper left corner of sprite #1. Also see the third example of the SPRITE command.

**PPT****PPT**

Cross Reference  
LPT,KEY LIST,KEY

**Description**

Prints current printer device-name or output device name to screen.  
i.e. LPT path.filename would list program in memory to a storage device  
when LLIST is used from the command prompt. PPT is a command only.

**PRINT****PRINT****Format**

Print to the screen

PRINT [print-list]

Print to a File (or Device)

PRINT #file-number[,REC record-number][:print-list]

**Cross Reference**

DISPLAY,OPEN,PRINT USING,TAB

**Description**

The PRINT instruction enables you to display data items on the screen or print them to an external device. You can use PRINT as either a program statement or a command.

The print-list consists of one or more items( items to be printed or displayed) separated by print separators. A PRINT instruction without a print-list advances the print position to the first position of the next record. This has the effect of printing a blank record, unless the preceding PRINT instruction ended with a print-separator.

The numeric- and/or string-expressions in the print-list can be constants and/or variables.

Print items are the numeric- and string expressions to be printed. Any function is also a valid print item.

Print separators are the punctuation(commas, semicolons, and colons) between print items specifying the placement of the print items in the print record.

**Printing to the Screen**

Each print item is displayed in the row of the screen window defined by the margins, starting from the far left column of the window. Before a new line is displayed at the bottom of the window, the entire contents of the window(excluding sprites) scroll up one line to make room for the new line. The contents of the top line of the window scroll off the screen and are discarded.

Each line on the screen is treated as one print record. The record length of the screen is the width of the window.

#### Printing to a File

If you include an optional file-number, the print-list is sent to the specified device. The file-number is a numeric-expression whose value specifies the number of the file as assigned in its OPEN instruction. You cannot print to a file opened in INPUT mode.

If you do not specify a file-number (or if you specify file-number 0), the print-list is displayed on the screen.

If you use the REC option, the record-number is a numeric-expression whose value specifies the number of the record in which you want to print the print-list. The records in a file are numbered sequentially, starting with zero. The REC option can be used only with a file opened for RELATIVE access.

If you print to a file opened in INTERNAL format with FIXED records, each record is filled with trailing binary zeros, if necessary, to bring it to its specified length. If a record is longer than the record length of the file, it is truncated (extra characters are discarded).

For more information about printing to a particular device, refer to the owner's manual that comes with that device.

#### Printing Numbers: INTERNAL Files

The amount of memory space allocated to a number printed to a file opened in INTERNAL format varies according to its data-type. A DEFINT is always allocated 3 bytes, whereas a REAL number is always allocated 9 bytes.

Note that if you print a DEFINT value to a file, you cannot access that file on a Home Computer that does not support the INTEGER data-type. You can circumvent this by converting all DEFINT variables and functions to REAL variables before printing them to a file.

#### Printing Numbers: The Screen and DISPLAY Files

The format of a number printed to the screen or to a file opened in DISPLAY format varies according to the characteristics of the number.

Positive numbers and zero are printed with a leading space (instead of a plus sign); negative numbers are printed with a leading minus sign. All numbers are printed with a trailing space.

Numbers are printed in either decimal form or scientific notation, according to these rules:

All numbers with 10 or fewer digits are printed in decimal form.

REAL numbers with more than 10 digits are printed in scientific notation only if they can be presented with more significant digits in scientific notation than in decimal form. If printed in decimal form, all digits beyond the tenth are omitted.

If a number is printed in decimal form, the following rules apply:

DEFINT numbers and REAL numbers with no decimal portion are printed without decimal points.

REAL numbers are printed with decimal points in the proper position. If the number has more than 10 digits, it is rounded to 10 digits. A zero is not printed by itself to the left of the decimal point. Trailing zeros after the decimal point are omitted.

If number is printed in scientific notation, the following rules

apply: The format is Mantissa Exponent.

The mantissa is printed with six or fewer digits, with one digit to the left of the decimal point.

Trailing zeros are omitted after the decimal point of the mantissa.

If there are more than five digits after the decimal point of the mantissa, the fifth digit is rounded.

The exponent is a two-digit number displayed with a plus or minus sign.

If you attempt to print a number with an exponent greater than 99 or less than -99, the computer prints two asterisks (\*\*) following the sign of the exponent.

## Printing Strings

A string constant in a print-list must be enclosed in quotation marks. A quotation mark within a string constant is represented by two adjacent quotation marks.

A string printed to a file opened in INTERNAL format has a length one greater than the length of the string.

When a string is printed to the screen or to a file opened in DISPLAY format, no leading or trailing spaces are added to the string.

## Print Separators

At least one print separator must be placed between adjacent print items in the print-list. Valid print separators are the semicolon (;), the colon (:), and the comma (,).

A semicolon (;) print separator causes the next print item to print immediately after the current print item.

A colon (:) print separator causes the next print item to print at the beginning of the next record. Consecutive colons used as print separators must be divided by a space. Otherwise, they are treated as a statement separator symbol.

If you print to the screen or to a file opened in DISPLAY format, a comma (,) print separator causes the next print item to print at the beginning of the next "zone." Print records are divided into 14-character zones; the number of zones in a print record varies according to its record length.

If you print to a file opened in INTERNAL format, a comma print separator has the same effect as a semicolon print separator.

If a print separator would have the effect of splitting the next print item between two records, the print item is moved to the beginning of the following record. However, if discarding the trailing space from a numeric print item allows it to fit in the current record, the number is printed in the current record without its trailing space.

If the print-list ends with a print separator, the computer is placed in a print-pending condition. Unless the next PRINT instruction includes the REC option, it is considered to be a continuation of the current PRINT instruction. RESTORE #file-number terminates a print-pending condition.

If the print-list is not terminated by a print separator, the computer considers the current record complete when all the print items in the print-list are printed. The first print-item in the next PRINT instruction begins in the next record.

### Examples

100 PRINT

Causes a blank line to appear on the display screen.

100 PRINT "THE ANSWER IS";A

Causes the string constant THE ANSWER IS to be printed on the display screen, followed immediately by the value of ANSWER. If ANSWER is positive, there will be a blank for the positive sign after IS.

100 PRINT X:Y/2

Causes the value of X to be printed on a line and the value of Y/2 to be printed on the next line.

```
100 PRINT #12,REC 7:A
```

Causes the value of A to be printed on the eighth record of the file that was opened as number 12 with RELATIVE file organization. (Record number 0 is the first record.)

```
100 PRINT #32:A,B,C,
```

Causes the values of A, B, and C to be printed on the next record of the file that was opened as number 32. The final comma creates a pending print-condition. The next PRINT statement directed to file number 32 will print on the same record as this PRINT statement unless it specifies a record, or a RESTORE #32 statement is executed, thereby closing the print-pending print condition.

```
100 PRINT #1,REC 3:A,B
```

```
150 PRINT #1:C,D
```

Causes A and B to be printed in record 3 of the file that was opened as number 1. PRINT #1:C,D causes C and D to be printed in record 4 of the same file.

### Program

The following program prints out values in various positions on the screen.

```
100 CALL CLEAR
```

```
110 PRINT 1;2;3;4;5;6;7;8;9
```

```
120 PRINT 1,2,3,4,5,6
```

```
130 PRINT 1:2:3
```

```
140 PRINT
```

```
150 PRINT 1;2;3;
```

```
160 PRINT 4;5;6/4
```

```
RUN
```

```
1 2 3 4 5 6 7 8 9
```

```
1 2
```

```
3 4
```

```
5 6
```

```
1
```

```
2
```

```
3
```

```
1 2 3 4 5 1.5
```

**PRINT USING  
USING****PRINT**

## Format

Print to the Screen

`PRINT USING format-string[:print-list]`

Print to a File (or Device)

`PRINT #file-number[,REC record-number],USING format-string[print-list]`

## Cross Reference

IMAGE, PRINT

## Description

The PRINT USING instruction enables you to define specific formats for numbers and strings you print.

You can use PRINT USING as either a program statement or a command.

The format-string specifies the print format.

See IMAGE for an explanation of format-strings where you can also optionally define a format-string in an IMAGE statement.

See PRINT for an explanation of the print-list print options.

With PRINT USING instruction:

You cannot use the TAB function.

You cannot use any print separator except (,) and semicolon at the end (;).

If you use PRINT USING to print to a file, the file must have been previously opened in DISPLAY format.

## Examples

```
100 PRINT USING "###.##":32.5
Prints 32.50.
```

```
100 PRINT USING 185:37.4,-86.2
185 IMAGE ###.#
Prints the values of 37.4 and -86.2 using the IMAGE statement in line 185.
```

**PSET****PSET**

Format

`PSET (pixel-row,pixel-column)`

Cross Reference

`DRAW, DRAWTO, GRAPHICS, POINT, RECTANGLE`

## Descriptions

used to set and invisible starting point for DRAWTO.

Example:

```
100 CALL GRAPHICS(3,2)
200 PSET (10,10)
300 CALL DRAWTO(1,20,20)
```

Sets an invisible point at 10,10 then draws a line to 20,20.

Geneve 9640 Advanced BASIC

## RANDOMIZE

## RANDOMIZE

Format

RANDOMIZE[seed]

Cross Reference

RND

Description

The RANDOMIZE instruction varies the sequence of pseudo-random numbers generated by the RND function.

You can use RANDOMIZE as either a program statement or a command.

The optional seed is a numeric-expression whose value specifies the random number sequence to be generated by RND functions. The first two bytes of the internal representation of the value of the seed determine the random number sequence generated by RND. If the first two bytes of the seed are identical each time you run your program, the same random number sequence is generated. If you do not enter a seed, a different and unpredictable sequence of random numbers is generated by RND each time you run your program.

Program

The following program illustrates a use of the RANDOMIZE statement. It accepts a value for the seed and prints the first 10 values obtained using the RND function.

```
100 CALL CLEAR
110 INPUT "SEED: ":S
120 RANDOMIZE S
130 FOR A=1 TO 10::PRINT A;RND::NEXT A::PRINT
140 GOTO 110
(Press CLEAR to stop the program.)
```



**READ****READ**

## Format

READ variable-list

## Cross Reference

DATA, RESTORE

## Description

The READ statement enables you to assign constants (stored within your program in DATA statements) to variables.

The variable-list, consisting of one or more variables separated by commas, specifies the numeric and/or string variables that are to be assigned values. When a READ statement is executed, the variables in its variable-list are assigned values from the data-list of a DATA statement. Unless you use a RESTORE statement to specify otherwise, DATA statements are read in ascending line-number order.

If a data-list does not contain enough values to assign to all the variables, the READ statement assigns values from subsequent DATA statements until all the variables have been assigned a value. If there are no more DATA statements, a program error occurs and the message Data error in line-number is displayed.

If a numeric variable is specified in the variable-list, a numeric constant must be in the corresponding position in the data-list of a DATA statement. If a string variable is specified in the variable-list, either a string or a numeric constant can be in the corresponding position in the DATA statement.

See the DATA statement for examples.

**REC****REC**

## Format

REC(file-number)

## Type

DEFINT

## Description

The REC function returns a record number reflecting the position of the next record in the specified file.

The file-number is a numeric-expression whose value specifies the number of the file as assigned in its OPEN instruction.

The REC function returns the number of the record in the specified file that is to be accessed by the next PRINT, INPUT, or LINPUT instruction (the next sequential record). (REC always treats a file as if it were being accessed sequentially, even if it has been opened for relative access.)

The records in a file are numbered sequentially starting with zero. Example

```
100 PRINT REC(4)
```

Prints the position of the next record in the file that was opened as number 4.

## Program

The following program illustrates a use of the REC function.

```
100 CALL CLEAR
110 OPEN #1:"DSK1.PROFILE",RELATIVE,INTERNAL
120 FOR A=0 TO 3
130 PRINT #1:"THIS IS RECORD",A
140 NEXT A
150 RESTORE #1
160 FOR A=0 TO 3
170 PRINT REC(1)
180 INPUT #1:A$,B
190 PRINT A$;B
200 NEXT A
210 CLOSE #1
RUN
```

```
0
THIS IS RECORD 0
1
THIS IS RECORD 1
2
THIS IS RECORD 2
3
THIS IS RECORD 3
```

Line 110 opens a file.

Lines 120 through 140 write four records on the file.

Line 150 resets the file to the beginning.

Lines 160 through 200 print the file position and read and print the values at that position.

Line 210 closes the file.

**RECTANGLE****RECTANGLE**

## Format

```
CALL RECTANGLE(line-type,pixel-row1,pixel-column1,
pixel-row2,pixel-column2,pixel-row3 ,pixel-column3[,...]))
```

## Cross Reference

CIRCLE, DCOLOR, DRAW, DRAWTO, FILL, GRAPHICS, POINT

## Description

The RECTANGLE command enables you to place rectangles of various types and proportions on the screen.

Rectangles may be hollow (only the perimeter of the rectangle is drawn), or solid (both the perimeter and the entire area enclosed by the perimeter is drawn).

Line-type is a numeric-expression whose value specifies the action taken by the RECTANGLE command.

TYPE	ACTION
5 specified	Reverses the status of each pixel of the solid rectangle. Note: results may be unpredictable.
4	Draws a rectangle (solid), of the foreground-color specified by the DCOLOR command. This is accomplished by turning on each pixel in the specified rectangle.
3 accomplished by	Erases a rectangle (solid). This is accomplished by turning off each pixel in the specified rectangle.
2 perimeter of the	Reverses the status of each pixel in the specified rectangle. Note:results may be unpredictable.
1	Draws the perimeter of a rectangle, of the foreground-color specified by the DCOLOR command. This is accomplished by turning on each pixel in the specified rectangle.
0	Erases the perimeter of a rectangle. This is accomplished by turning off each pixel in the specified rectangle.

Pixel-row(#), and pixel-column(#), are numeric-expressions whose values represent the screen positions of specific points of the rectangle. There are three points needed to define the rectangle, as shown below.

Pixel-row1 / pixel-column1 specify the TOP LEFT corner of the rectangle.

Pixel-row2 / pixel-column2 specify the TOP RIGHT corner of the rectangle.

Pixel-row3 / pixel-column3 specify the BOTTOM LEFT corner of the rectangle.

All pixel-rows must have a value from 1 to 192. All pixel-columns must have a value from 1 to 256.

Note that the first pixel set (pixel-row1 and pixel-column1) represents the top leftmost point of the rectangle and must have a lower column value than the second pixel set. The second pixel set represents the top rightmost point of the rectangle. In the same manner, the third pixel set, which represents the bottom leftmost point of the rectangle, must have a higher row value than set1 or set2.

If the procedure outlined above is not followed, an error is issued.

You can optionally draw more rectangles by specifying additional sets of pixels. You must specify three sets of pixels for each rectangle.

The bottom-rightmost point of the last rectangle drawn becomes the current position used by the DRAWTO command.

RECTANGLE cannot be used in GRAPHICS(1,1),(2,1) & (3,1).

Program

```
100 CALL GRAPHICS(1,2)
110 CALL RECTANGLE(1,8,80,8,175,134,80)
120 FOR T=1 TO 8 :: CALL RECTANGLE(4,T* 16,100,T* 16,155,T* 16+T-1,100)
    NEXT T
130 FOR DELAY=1 TO 2000 :: NEXT DELAY
140 CALL RECTANGLE(3,16,100,16,155,128,100)
150 FOR DELAY=1 TO 2000 :: NEXT DELAY
160 END
```

Line 100 selects a usable graphics mode (and clears the

screen). Line 110 draws a large box on the screen.

Line 120 uses a for-next loop to fill the box with lines of different thickness. (This shows how RECTANGLE could be used to replace DRAW. RECTANGLE is slower, but more versatile.)

Line 130 uses a for-next loop to delay execution of the next statement.

Line 140 clears the lines, but leaves the box to illustrate how RECTANGLE can be used as an eraser.

Line 150 delays the execution of the next statement.

Line 160 ends the program.

## REM

RE

M

Format  
REM remark  
! remark

### Description

The REM statement enables you to document your program by including explanatory remarks within the program itself.

You can use any character in a remark.

The length of a REM statement is limited only by the length of a program statement.

A REM statement encountered during program execution is ignored by the computer.

### Trailing Remarks

In addition to the REM statement, trailing remarks can be added to the ends of lines in Geneve 9640 Advanced BASIC, allowing detailed internal documentation of programs. An exclamation mark (!) begins each trailing remark.

### Example

100 REM BEGIN SUBROUTINE  
Identifies a section beginning a subroutine.

100 FOR X=1 to 16 :: ! BEGIN LOOP Identifies a section beginning a FOR-NEXT loop.

## RESETPLT

RESETPLT

Format  
CALL RESETPLT

### Description

Resets all of the color palette back to default colors.

**RESEQUENCE****RESEQUENCE****Format**

RESEQUENCE [initial-line-number][,increment]  
 RES

**Description**

The RESEQUENCE command assigns new line numbers to all lines in the program currently in memory.

If you enter an initial-line-number, the first line number assigned is one you specify. If you do not specify an initial-line-number, the computer starts with line number 100.

Succeeding line numbers are assigned by adding the value of the numeric-expression increment to the previous line number. Note that to specify an increment only (without specifying an initial-line-number), you must precede the increment with a comma. The default increment is 10.

To ensure that your program continues to function properly, all line-number references within your program are changed to reflect the newly assigned line numbers. (Line numbers mentioned in REM statements are not affected.) If an invalid line-number reference (a reference to a line number that does not exist in your program) is encountered, the computer changes the line-number reference to 32767, without displaying any error message or warning.

If the values you enter for the initial-line-number and increment would have the effect of creating a line number greater than 32767, the message Bad line number is displayed and the program is not re-sequenced.

**Examples**

RES

Re-sequences the lines of the program in memory to start with 100 and number by 10s.

RES 1000

Re-sequences the lines of the program to start with 1000 and number by 10s.

RES 1000,15

Re-sequences the lines of the program in memory to start with 1000 and number by 15s.

RES ,15

Re-sequences the lines of the program in memory to start with 100 and number by 15s.

**RESTORE****RESTORE**

## Format

## Restore Data

```
RESTORE [line-number]
```

## Restore a File

```
RESTORE #file-number[,REC record-number]
```

## Cross Reference

DATA, INPUT, PRINT, READ

## Description

The RESTORE instruction specifies either the DATA statement to be used with the next READ statement or the record to be accessed by the next file-processing instruction.

## RESTORE with DATA and READ Statements

If you enter a line-number, the next READ statement executed assigns values beginning from the data-list in the specified DATA statement.

If the specified line-number is not the line-number of a DATA statement, the computer uses the first DATA statement with a line-number higher than the one you specified.

If there is no higher numbered DATA statement, a program error occurs and the message Data error in line-number is displayed (the line-number is the line number of the READ statement that caused the error).

If you do not enter a line-number or a file-number, the next READ statement executed assigns values beginning from the data-list of the first DATA statement in your program.

If there are **no** DATA statements in your program, the message Data error in line-number is displayed.

## RESTORE with a File

If you enter a file-number, RESTORE positions the specified file at its first record, record zero (unless you use the REC option). The file-number is a numeric-expression whose value specifies the number of the file as assigned in its OPEN instruction.

If you use the REC option, the record-number is a numeric-expression specifying the number of the record at which you want to position the file. The records in a file are numbered sequentially, starting with zero. The REC option can be used only with a file opened for RELATIVE access.

RESTORE terminates any print- or input-pending conditions.

## Examples

100 RESTORE

Sets the next DATA statement to be used to the first DATA statement in the program.

100 RESTORE 130

Sets the next DATA statement to be used to the DATA statement at line 130 or, if line 130 is not a DATA statement, to the next DATA statement after line 130.

100 RESTORE #1

Sets the next record to be used by the next PRINT, INPUT, or LINPUT statement using file #1 to be the first record in the file.

100 RESTORE #4,REC H5

Sets the next record to be used by the next PRINT, INPUT, or LINPUT statement using file #4 to be record H5.

**RETURN****RETURN**

## Format

With GOSUB and ON GOSUB

RETURN

With ON ERROR

RETURN [NEXT  
line-number]

## Cross Reference

GOSUB, ON GOSUB, ON ERROR

## Description

The RETURN statement causes program control to return to the main program from a subroutine called by a GOSUB, ON GOSUB, or ON ERROR statement.

## RETURN with GOSUB and ON GOSUB

When the computer encounters a RETURN statement in a subroutine called by a GOSUB or ON GOSUB statement, program control returns to the statement immediately following the GOSUB or ON GOSUB statement.

No options are allowed with a RETURN statement in a subroutine called by a GOSUB or ON GOSUB statement.

## RETURN with ON ERROR

The action taken by the computer when it encounters a RETURN statement in a subroutine called by an ON ERROR statement depends on the RETURN option.

If you specify the NEXT option, program control returns to the statement immediately following the statement that caused the error.

If you specify a line-number, program control is transferred to the specified program statement.

If you do not specify an option, program control returns to the statement that caused the error. The statement is re-executed.

RETURN "clears" the error, so that it can no longer be analyzed by the ERR command.

## Programs

The following program illustrates a use of RETURN as used with GOSUB. The program figures interest on an amount of money put into savings.

```
100 CALL CLEAR
110 INPUT "AMOUNT DEPOSITED: ":AMOUNT
120 INPUT "ANNUAL INTEREST RATE: ":RATE
130 IF RATE 1 THEN RATE=RATE* 100
140 PRINT "NUMBER OF TIMES COMPOUNDED"
```

```

150 INPUT "ANNUALLY: "COMP
160 INPUT "STARTING YEAR: ":Y
170 INPUT "NUMBER OF YEARS: ":N
180 CALL CLEAR
190 FOR A=Y TO Y+N
200 GOSUB 240
210 PRINT A,INT(AMOUNT* 100+.5)/100
220 NEXT A
230 STOP
240 FOR 8=1 TO COMP
250 AMOUNT=AMOUNT+AMOUNT*RATE/(COMP* 100)
260 NEXT B
270 RETURN

```

The following program illustrates a use of RETURN with ON ERROR.

```

100 CALL CLEAR
110 A=1
120 ON ERROR 160
130 X=VAL("D")
140 PRINT 140
150 STOP
160 REM ERROR HANDLING
170 IF A>4 THEN 220
180 A=A+1
190 PRINT 190
200 ON ERROR 160
210 RETURN
220 PRINT 220 :: RETURN NEXT
RUN

190
190
190
190
220
140

```

Line 120 causes an error to transfer control to line 160. Line 130 causes an error.

Line 170 checks to see if the error has occurred four times and transfers control to 220 if it has. Line 180 increments the error counter by one. Line 190 prints 190. Line 200 resets the error handling to transfer to line 160. Line 210 returns to the line that caused the error and executes it again.

Line 220, which is executed only after the error has occurred four times, prints 220 and returns to the line following the line that caused the error.

Line 140, the next one after the one that causes the error, prints

140. See also example of the ON ERROR statement.

## RIGHT\$

## RIGHT\$

### Format

RIGHT\$(string-expression,length)

### Cross Reference

LEFT\$, POS, STR\$

### Description

RIGHT\$ returns the right-most "length" of characters from the string expression. If the string-expression is shorter than the length, the actual string-expression will be returned.

### Example

```
10 A$="MY NAME IS URSULA LE GUIN "  
20 PRINT RIGHT$(A$,15)  
RUN  
URSULA LE GUIN
```

**RND****RND**

## Format

RND

## Type

REAL

## Cross Reference

RANDOMIZE

## Description

The RND function returns a pseudo-random number.

RND returns the next pseudo-random number in the current series of pseudo-random numbers. The number returned is always greater than or equal to 0 and less than 1.

The numbers returned by RND are called "pseudo-random" because they are not generated strictly at random, but are generated as members of predefined series. You can use the RANDOMIZE instruction to make the numbers generated by RND more random.

The same sequence of random numbers is generated by RND each time you run a particular program unless the program includes a RANDOMIZE instruction.

## Examples

```
100 COLOR16=INT(RND* 16)+1
```

Sets COLOR16 equal to some number from 1 through 16.

```
100 VALUE=INT(RND* 16)+10
```

Sets VALUE equal to some number from 10 through 25.

```
100 LL(8)=INT(RND*(13-A+1))+A
```

Sets LL(8) equal to some number from A through B.

**RPT\$****RPT\$****Format****RPT\$(string-expression,numeric-expression)****Type****String****Description**

The RPT\$ function returns a string consisting of a specified string repeated a specified number of times.

The string-expression specifies the string to be repeated. If you use a string constant, it must be enclosed in quotation marks.

The value of the numeric-expression specifies the number of repetitions of the string-expression.

If the length of the string-expression and the value of the numeric-expression would create a string longer than 255 characters, the excess characters are discarded and the following message is displayed:

\*WARNING

STRING TRUNCATED

**Examples**

```
100 M$=RPT$("ABCO",4)
```

Sets M\$ equal to "ABCDABCDABCDABCD".

```
100 CALL CHAR(244,RPTW"0000FFFF",8))
```

Defines characters 244 through 247 with the string

"0000FFFF0000FFFF0000FFFF0000FFFF0000FFFF0000FFFF0000FFFF".

```
100 PRINT USING RPT$("#",40):X$
```

Prints the value of X\$ using an image that consists of 40 number signs

**RUN****RUN****Format**

Execute Program in Memory

RUN [line-number]

Execute Program on External Device

RUN file-specification[,Continue]

**Description**

The RUN instruction causes the computer either to execute the program currently in memory or to both load and execute a program from an external. You can use RUN as either a program statement or a command.

When you use RUN as a program statement, one program can start the execution of another program. This enables you to divide a large program into smaller segments, each of which can be loaded into memory only as needed.

If you specify a line-number, your program starts running at the specified program line.

If you enter a file-specification, your program is first loaded into memory from the specified external device, and then executed starting from the lowest-numbered line in the program. The file-specification is a string expression; if you use a string constant, you must enclose it in quotation marks. If you additionally specify the Continue option, the new program loaded must contain only variables used in the previous program. A syntax error will occur when trying to use a variable not contained in the previous program.

If you do not enter either a line-number or a file-specification, the computer executes the program currently in memory starting with the lowest-numbered line in the program.

Before the program starts running, the computer:

Sets the values of all numeric variables to zero.

Sets the values of all string variables to null strings (strings containing no characters).

Closes all open files.

Restores the default screen color (cyan).

Deletes all sprites.

Resets the sprite magnification level to 1.

Checks for certain program errors.

RUN does not affect the graphics mode, margin settings, graphics colors (see DCOLOR), or current position (see DRAWTO).

## Examples

RUN

Causes the computer to begin execution of the program in memory.

RUN 200

100 RUN 200

Causes the computer to begin execution of the program in memory starting at line 200.

RUN "DSK1.PRG3"

100 RUN "DSK1.PRG3"

Causes the computer to load and begin execution of the program named PRG3 from the diskette in disk drive 1.

100 A\$="DSK1.MYFILE"

110 RUN A\$

Causes the computer to load and begin execution of the program named MYFILE from the diskette in disk drive 1.

## Program

The following program illustrates a use of the RUN command used as a statement. It creates a "menu" and lets the person using the program choose what other program he wishes to run. The other programs should RUN this program rather than ending in the usual way, so that the menu is given again after they are finished.

100 CALL CLEAR

110 PRINT "1 PROGRAM 1."

120 PRINT "2 PROGRAM 2."

130 PRINT "3 PROGRAM 3."

140 PRINT "4 END."

150 PRINT

160 INPUT "YOUR CHOICE: "C

170 IF C=1 THEN RUN "DSK1.PRG1"

180 IF C=2 THEN RUN "DSK1.PRG2"

190 IF C=3 THEN RUN "DSK1.PRG3"

200 IF C=4 THEN STOP

210 GOTO 100

**SAVE****SAVE****Format**

SAVE file-specification[,INTERNAL][,MERGE][PROTECTED]

**Cross Reference**

MERGE, OLD

**Description**

The SAVE command copies the program in memory to an external storage device. When you are using SAVE, your program remains in memory, even if an error occurs.

The saved program can later be loaded back into memory with the OLD command.

The file-specifications names the program to be stored. The file-specification, a string constant, optionally can be enclosed in quotation marks.

To specify that your program is to be available for merging with other programs, use the MERGE option. If you use the MERGE option, the program is stored as a SEQUENTIAL file in DISPLAY format with VARIABLE records (DV/163)(see OPEN); MERGE can be used only with devices that accept these options.

For more information about using MERGE with a particular device, refer to the owner's manual that comes with that device.

If you do not use the MERGE option, your program cannot later be merged with another program.

If you use the PROTECTED option, you ensure that the program, when later loaded with the OLD command, cannot be listed, edited, or saved in ABASIC.

As the PROTECTED option is not reversible, it is recommended that you keep an unprotected version of the program. If you also wish to protect a diskette-based program from being deleted, use the protect feature of the Disk Manager.

If you use the INTERNAL option, your program will be saved in INTERNAL format with VARIABLE records and will be compatible with the TI 99/4A. The program size in bytes should be limited to approx. 24K and cannot have ANY of the reserved words of Geneve 9640 Advanced BASIC.

SAVE removes any break-points you have set in your program.

**Examples****SAVE PRG1**

Saves program to the current working directory(see PWD or KEY LIST)

**SAVE DSK1.PRG1**

Saves the program in memory on the diskette or harddrive(if you have emulate set) in disk drive 1 under the name PRG1.

SAVE DSK1.PRG1,PROTECTED

Saves the program in memory on the diskette in disk drive 1 under the name PRG1. The program may be loaded into memory, but it may not be edited, listed(screen or printer), or re-saved.

SAVE DSK1.PRG1,MERGE

Saves the program in memory on the diskette in disk drive 1 under the name PRG1. The program may later be merged with a program in memory by using the MERGE command.

**SAY****SAY****Format**

CALL SAY(word-string[,direct-string][,...])

**Cross Reference**

SPGET

**Description**

The SAY command enables you to instruct the computer to produce speech.

word-string is a string-expression whose value is any of the words or phrases in the computer's resident vocabulary. If you use a string constant, you must enclose it in quotation marks. Alphabetic characters must be upper-case.

The computer substitutes "UHOH" for a word-string not in the vocabulary.

A speech phrase (more than one word) must be enclosed in pound signs(#). A speech phrase must be predefined; that is it must be resident in the computer's vocabulary.

A compound is a new word formed by combining two words already in the vocabulary. For example, SOME+THING produces "something" and THERE+FOUR produces "therefore". A compound must not be enclosed in pound signs.

See Appendix H for a list of the computer's resident vocabulary .

Direct-string is a string-expression whose value is the computer's internal representation of a word or phrase. You can use or modify a direct-string returned by the SPGET command.

See Appendix I for information on adding suffixes to direct-strings. You can specify multiple word-strings and direct-strings by alternating them. To specify two consecutive word-strings or direct-strings, enter an extra comma as a separator between them.

**Examples**

```
100 CALL SAY("HELLO, HOW ARE YOU")
```

Causes the computer to say "Hello, how are you".

```
CALL SAY(A$, ,B$)
```

Causes the computer to say the words indicated by A\$ and b\$, which must have been returned by SPGET.

The following program illustrates a use of CALL SAY with a word-string and three direct-strings.

```
100 CALL SPGET("HOW",X$)
110 CALL SPGET("ARE",Y$)
120 CALL SPGET("YOU",Z$)
130 CALL SAY("HELLO",X$, ,Y$, ,Z$)
```

## SCHAR

## SCHAR

### Format

CALL SCHAR(char#,string-variable)

### Cross Reference

CHAR,SPRITE

### Description

The SCHAR command enables you to define sprites. It works just like CALL CHAR except CHAR defines characters and sprites. The exception to this is switching to GRAPHICS(1,1) redefines both characters and sprites.

## SCREEN

## SCREEN

### Format

CALL SCREEN(background-color)

### Cross Reference

COLOR,DCOLOR,GRAPHICS

### Description

The SCREEN command enables you to change the screen color. The screen color is the color of the border and the background color of the screen.

The codes for the available colors are listed in Appendix F.

```
100 CALL SCREEN(8)
```

Changes the screen to cyan.

```
100 CALL SCREEN(2)
```

Changes the screen to black.

### Program

The following program uses CALL SCREEN with CALL VCHAR and PRINT in the Text Mode to change the color of a character.

```
100 CALL CLEAR
110 CALL GRAPHICS(2,1)
120 CALL VCHAR(12,12,33,3)
130 CALL SCREEN(5)
140 PRINT "DARK BLUE SCREEN WITH WHITE LETTERS"
150 GOTO 150
(Press CLEAR to stop the program.)
```

Line 130 changes the screen to dark blue and the characters to white.

**SEG\$****SEG\$**

## Format

SEG\$(string-expression, start-position,length)

## Type

String

## Description

The SEG\$ function returns a specified substring (segment of a string).

The string-expression specifies the string of which you want to specify a substring. If you use a string constant, it must be enclosed in quotation marks.

The start-position is a numeric-expression whose value specifies the character position in the string-expression where the substring begins. The value of the start-position must be greater than zero.

The length is a numeric-expression whose value specifies the length of the substring.

If the start-position is greater than the length of the string-expression, or if the length is zero, SEG\$ returns a null string.

If the specified length is greater than the remaining length of the string-expression (starting from the specified start-position), SEG\$ returns a substring consisting of all characters in the string-expression starting from the start-position to the end of the string-expression.

## Examples

```
100 X$=SEG$("FIRSTNAME LASTNAME",1,9)
Sets X$ equal to FIRSTNAME.
```

```
100 Y$=SEG$("FIRSTNAME LASTNAME"11,8)
Sets Y$ equal to LASTNAME.
```

```
100 Z$=SEG$("FIRSTNAME LASTNAME",10,1)
Sets Z$ equal to " ".
```

```
100 PRINT SEG$(A$,B,C)
Prints the substring of A$ starting at the character at position B and
extending for C characters.
```

**SGN --Function--Signum (Sign)****SGN****Format**

SGN(numeric-expression)

**Type**

DEFINT

**Description**

The SGN function returns a number indicating the algebraic sign of the value of the numeric-expression.

If the value of the numeric-expression is negative, SGN returns a -1.

If the value of the numeric-expression is zero, SGN returns a 0.

If the value of the numeric-expression is positive, SGN returns a

(+)1. Examples

```
100 IF SGN(X2)=1 THEN 300 ELSE 400
```

Transfers control to line 300 if X2 is positive and to line 400 if X2 is zero or negative.

```
100 ON SGN(X)+2 GOTO 200,300,400
```

Transfers control to line 200 if X is negative, line 300 if X is zero, and line 400 if X is positive.

## SIN

## SIN

### Format

SIN(numeric-expression)

### Type

REAL

### Cross Reference

ATN, COS, TAN

### Description

The SIN function returns the sine of the angle whose measurement in radians is the value of the numeric-expression.

The value of the numeric-expression cannot be less than -1.5707963267944E10 or greater than 1.5707963267944E10.

To convert the measure of an angle from degrees to radians, multiply pi/180.

### Program

The following program gives the sine for each of several angles.

```
100 A=.5235987755982
110 B=30
120 C=45*PI/180
130 PRINT SIN(A);SIN(B)
140 PRINT SIN(B*PI/180)
150 PRINT SIN(C)
RUN
.5      -.9880316241
.5
.7071067812
```

**SOUND****SOUND****Format**

```
CALL SOUND(duration,frequency1,volume1[,frequency2,volume2]
[,frequency3,volume3][,frequency4,volume4])
```

**Description**

The SOUND command enables you to instruct the computer to produce musical tones or noise.

The computer contains three music generators and one noise generator, enabling you to create up to four different sounds at once. You can specify the frequency and volume of each sound independently.

Duration is a numeric-expression whose absolute value specifies the length of the sound in milliseconds (thousandths of seconds). Duration can have an absolute value from 1 to 4250. (A value of 1000 will produce a sound for one second.)

The actual duration produced by the computer may vary by as much as one sixtieth (1/60) of a second from the value you specify.

You can enter only one duration, which applies to all specified sounds (music and noise).

Frequency is a numeric-expression that has different meanings depending on whether you use it to specify one of the music generators or the noise generator.

You must enter at least one frequency.

The frequency of a music generator specifies the frequency of the tone in Hertz (cycles per second). The acceptable values range from 110 to 44733; the upper limit exceeds the range of human hearing.

The actual frequency produced by the computer may vary by as much as ten percent from the value you specify.

See Appendix C for the frequencies of some commonly used tones.

The frequency of the noise generator has a value from -1 to -8, specifying the type of noise produced.

The frequencies from -1 to -3 produce different types of periodic noise. A frequency of -4 produces a periodic noise that varies depending on the frequency value of the third music generator.

The frequencies from -5 to -7 produce different types of white noise. A frequency of -8 produces a white noise that varies depending on the frequency value of the third music generator.

Volume is a numeric-expression whose value is inversely proportional to the loudness of the sound.

You must enter at least one volume.

The volume can be from 0 to 30. Zero is the maximum volume and 30 is silence.

If you call SOUND while the computer is still producing the tones specified in a previous call to the SOUND command, the result depends on the algebraic sign of the duration of the previous call to SOUND. If the duration was positive, the new sound does not begin until the old sound is complete. If the duration was negative, the new sound begins immediately, interrupting the old sound.

#### Examples

```
100 CALL SOUND(1000,110,0)
Plays A below low C loudly for one second.
```

```
100 CALL SOUND(500,110,0,131,0,196,3)
Plays A below low C and low C loudly, and G below C not as loudly, all for half a second.
```

```
100 CALL SOUND(4250,-8,0)
Plays loud white noise for 4.250 seconds.
```

```
100 CALL SOUND(DUR, TONE,VOL)
Plays the tone indicated by TONE for a duration indicated by DUR, at a volume indicated by VOL.
```

#### Program

The following program plays \*the 13 notes of the first octave that is available on the computer.

```
100 X=2^(1/12)
110 FOR A=1 TO 13
120 CALL SOUND(100,110*X^A,0)
130 NEXT A
```

## MUSICAL TONE FREQUENCIES

The following table gives the frequencies(rounded to integers) of four octaves of the tempered scale (one half step between notes). While this list does not represent the entire range of notes that the computer can produce, it can be helpful for programming music.

FREQUENCY	NOTE	FREQUENCY	NOTE
110	A	440	A (above middle C)
117	A#,Bb	466	A#,Bb
123	B	494	B
131	C (low C)	523	C (high C)
139	C#,Db	554	C#,Db
147	D	587	D
156	D#,Eb	622	D#,Eb
165	E	659	E
175	F	698	F
185	F#,Gb	740	F#,Gb
196	G	784	G
208	G#,Ab	831	G#,Ab
220	A (below middle C)	880	A (above high C)
220	A (above middle C)	880	A (above high C)
223	A#,Bb	932	A#,Bb
247	B	988	B
262	C (middle C)	1047	C
277	C#,Db	1109	C#,Db
294	D	1175	D
311	D#,Eb	1245	D#,Eb
330	E	1319	E
349	F	1397	F
370	F#,Gb	1480	F#,Gb
392	G	1568	G
415	G#,Ab	1661	G#,Ab
440	A (above middle C)	1760	A

**SPGET****SPGET**

## Format

```
CALL SPGET(word-string,string-variable[,...])
```

## Cross Reference

SAY

## Description

The SPGET command enables you to assign the computer's internal representation of a speech word to a variable.

SPGET is especially useful if you want to add a suffix to a word in the computer's resident vocabulary.

word-string is a string-expression whose value is any of the words or phrases in the computer's resident vocabulary. If you use a string constant, you must enclose it in quotes.

The computer substitutes "UHOH" for a word-string not in the vocabulary.

A speech phrase (more than one word) must be enclosed in pound signs(#).

See Appendix for a list of the computer's resident vocabulary.

The internal representation of the word-string (the direct-string) is returned in the string-variable.

See Appendix I for information on adding suffixes to direct-strings.

You can specify multiple word-strings and direct strings by alternating them.

## Program

The following program illustrates using CALL SPGET.

```
110 CALL SPGET("COMPUTER",Y$)
120 CALL SAY("I AM A",Y$)
```

**SPRITE****SPRITE****Format**

CALL SPRITE(#sprite-number,character-code,foreground-color,  
pixel-row,pixel-column[, vertical-velocity,horizontal-velocity][,...])

**Cross Reference**

SPRITE2, CHAR, COINC, COLOR, DELSPRITE, DISTANCE, GRAPHICS, LOCATE,  
MAGNIFY, MOTION, PATTERN, POSITION, SCREEN

**Description**

The SPRITE command enables you to create sprites.

Sprites are graphics that can be assigned any valid color and placed anywhere on the screen. Sprites treat the screen as a grid 256 pixels high and 256 pixels wide. However, only the first 192 pixels are visible on the screen.

You can create up to 32 sprites in all graphics modes except GRAPHICS(2,1),(3,1), which do not allow sprites.

Sprites can be set in motion in any direction at a variety of speeds. A sprite continues its motion until it is specifically changed by the program or until program execution stops. Because sprites move from pixel to pixel, their motion can be smoother than that of characters, which can be moved only one character position (6 or 8 pixels) at a time.

Sprites "pass over" characters on the screen. When two or more sprites are coincident (occupying the same screen pixel position), the sprite with the lowest sprite-number covers the other sprite(s).

At any given time, only four sprites (in Graphics(1,1) and (1,2)) or eight sprites (in the other sprite enabled graphics modes) can be on the same horizontal pixel-row. Once this limit is exceeded the row of pixels in the sprite(s) with the highest sprite-number(s) disappears.

You can use the DELSPRITE command to delete one or more sprites. All sprites are deleted when your program ends (either normally or because of an error), stops at a break-point, or changes graphics mode.

**Sprite Specifications**

The sprite-number is a numeric-expression with a value from 1 to 32. If you specify the value of a previously defined sprite, the old sprite is replaced by the new sprite. If the old sprite had a vertical- or horizontal-velocity and you do not specify a new velocity, the new sprite retains the old velocity.

Character-code is a numeric-expression with a value from 0-255, specifying the character that defines the sprite pattern.

If you use the MAGNIFY command to change to double-sized sprites, the

sprite definition includes the character specified by the character-code and three additional characters (see MAGNIFY).

Once defined by the SPRITE command, the character-code of a sprite can be changed by the PATTERN command.

The foreground-color is a numeric-expression with a value from 1 to 16, specifying one of the 16 available colors. Once defined by the SPRITE command, the foreground-color of a sprite can be changed by the COLOR command.

The background-color of a sprite is always transparent.

The pixel-row and pixel-column are numeric-expressions whose values specify the screen pixel position of the pixel at the upper-left corner of the sprite. Note: Values can not exceed screen resolution.

Once defined by the SPRITE command, the pixel-row and pixel-column of a sprite can be changed by the LOCATE command, and the current pixel-row and pixel column of a sprite can be ascertained by the POSITION command. Also, the distance between sprites or between a sprite and a specified screen pixel can be ascertained by the DISTANCE command, and the COINC command can be used to ascertain whether sprites are coincident with each other or with a specified screen pixel.

### Sprite Motion

The optional vertical- and horizontal-velocity are numeric-expressions with values from -128 to 127. If both values are zero, the sprite is stationary. The speed of a sprite is in direct linear proportion to the absolute value of the specified velocity.

A positive vertical-velocity causes the sprite to move toward the top of the screen; a negative vertical-velocity causes the sprite to move toward the bottom of the screen.

A positive horizontal-velocity causes the sprite to move to the right; a negative horizontal-velocity causes the sprite to move to the left.

If neither the vertical- nor horizontal-velocity are zero, the sprite moves at an angle, in a direction and at a speed determined by the velocity values.

The velocity of a sprite can be changed by the MOTION command.

When a moving sprite reaches an edge of the screen, it disappears. The sprite reappears in the corresponding position at the opposite edge of the screen.

The motion of a sprite may be affected by the computer's internal processing and by input to, and output from, external devices.

## Program

The following three programs show some possible uses of sprites.

```

100 CALL CLEAR
110 CALL CHAR(244,"FFFFFFFFFFFFFFFF")
120 CALL CHAR(246,"183C7EFFFF7E3C18")
130 CALL CHAR(248,"FOOFFOOFFOOFFOOF")
140 CALL SPRITE(#1,244,5,92,124,#2,248,7,1,1)
150 CALL SPRITE(#28,33,16,12,48,1,1)
160 CALL SPRITE(#15,246,14,1,1,127,-128)
170 GOTO 170

```

(Press CLEAR to stop the program.)

Line 140 creates a dark blue sprite in the center of the screen and a red striped sprite in the upper-right corner of the screen. Line 150 creates a white sprite near the upper-left corner of the screen and starts it moving slowly at a 45-degree angle down and to the right. The sprite is an exclamation point.

Line 160 creates a dark red sprite at the upper-right corner of the screen and starts it moving very fast at a 45 degree angle down and to the left.

The following program makes a rather spectacular use of sprites.

```

100 CALL CLEAR
110 CALL CHAR(244,"0008081C7F1C0808")
120 RANDOMIZE
130 CALL SCREEN(2)
140 FOR A=1 TO 28
150 CALL SPRITE(#A,244,INT(A/3)+3,92,124,A*INT(RND*4.5)
-2.25+A/2*SGN(RND-.5),A*INT(RND*4.5)-2.25+A/2*SGN(RND-.5))
160 NEXT A
170 GOTO 140

```

(Press CLEAR to stop the program.)

Line 110 defines character 244.

Line 150 defines the sprites, 28 in all. The sprite-number is the current value of A. The character-value is 244. The sprite-color is  $\text{INT}(A/3)+3$ . The starting dot-row and dot-column are 92 and 124, the center of the screen. The row- and column-velocities are chosen randomly using the value of  $A*\text{INT}(\text{RND}*4.5)-2.25+A/2*\text{SGN}(\text{RND}-.5)$ .

Line 170 causes the sequence to repeat.

The following program uses all the commands that relate to sprites except for COLOR. They are CHAR, COINC, DELSPRITE, LOCATE, MAGNIFY, MOTION, PATTERN, POSITION, and SPRITE.

The program creates two double-sized magnified sprites in the shapes of two people walking along a floor. There is a barrier that one of them passes through and the other jumps through. The one that jumps through goes a

little faster after each jump, eventually catching the other one. When this happens, they each become double-sized, un-magnified sprites and continue walking. When they meet for the second time, the one that has been going faster disappears and the other continues walking.

Another example:

```

100 CALL CLEAR
110 S1$="010303010303030303030303030380C
0C08000C0C0C0C0C0C0C0C0C0C0E0"
120 S2$="0103030103070F1818030303060C0C0E80C
0C08000E0F008CCC0C00060303038"
130 COUNT=0
140 CALL CHAR(244,51$)
150 CALL CHAR(248,S2$)
160 CALL SCREEN(14)
170 CALL COLOR(14,13,13)
180 FOR A=19 TO 24
190 CALL HCHAR(A,1,136,32)
200 NEXT A
210 CALL COLOR(13,15,15)
220 CALL VCHAR(14,22,128,6)
230 CALL VCHAR(14,23,128,6)
240 CALL VCHAR(14,24,128,6)
250 CALL SPRITE(#1,244,5,113,129,#2,244,7,113,9)
260 CALL MAGNIFY(4)
270 XDIR=4
280 PAT=2
290 CALL MOTION(#1,0,XDIR,#2,0,4)
300 CALL PATTERN(#1,246+PAT,#2,246-PAT)
310 PAT=-PAT
320 CALL COINC(ALL,CO)
330 IF CO>0 THEN 370
340 CALL POSITION(#1,YPOS1,XPOS1)
350 IF XPOS1>136 AND XPOS1<192 THEN 470
360 GOTO 300
370 REM COINCIDENCE
380 CALL MOTION(#1,0,0#2,0,0)
390 CALL PATTERN(#1,244,#2,244)
400 IF COUNT>0 THEN 540
410 COUNT=COUNT+1
420 CALL POSITION(#1,YPOS1,XPOS1,#2,YPOS2,XPOS2)
430 CALL MAGNIFY(3)
440 CALL LOCATE(#1,YPOS1+16,XPOS1+8,#2,YPOS2+16,XPOS2)
450 CALL MOTION(#1,0,XDIR,#2,0,4)
460 GOTO 340
470 REM #1 HIT WALL
480 CALL MOTION(#1,0,0)
490 CALL POSITION(#1,YPOS1,XPOS1)
500 CALL LOCATE(#1,YPOS1,193)
510 XDIR=XDIR+1
520 CALL MOTION(#1,0,XDIR)
530 GOTO 300
540 REM SECOND COINCIDENCE
550 FOR DELAY=1 TO 1000 :: NEXT DELAY

```

```
560 CALL MOTION(#2,0,4)
570 CALL DELSPRITE(#1)
580 FOR STEP1=1 TO 20
590 CALL PATTERN(#2,248)
600 FOR DELAY=1 TO 40 :: NEXT DELAY
610 CALL PATTERN(#2,244)
620 FOR DELAY=1 TO 40 :: NEXT DELAY
630 NEXT STEP1
640 CALL CLEAR
```

**SPRITE2****SPRITE2**

## Format

CALL SPRITE2(#sprite-number,character-code,foreground-color line 1, foreground-color line 2,...foreground-color line 16, pixel-row,pixel-column[, vertical-velocity,horizontal-velocity][,...])

## Cross Reference

SPRITE, CHAR, COINC, COLOR, DELSPRITE, DISTANCE, GRAPHICS, LOCATE, MAGNIFY, MOTION, PATTERN, POSITION, SCREEN

## Description

The SPRITE2 command is much like the standard SPRITE command except it enables you to create multi-color sprites in GRAPHICS modes (1,3), (2,2), (2,3), (3,2) & (3,3). Each of the 16 (8 in MAGNIFY 1 & 2) lines of the sprite can have it's own separate foreground color. Any of the 16 colors are available per line of the sprite.

To specify the color of each of the 16 lines set all the foreground-colors 1..16 in the SPRITE2 command.

Note: Even though MAGNIFY 1 & 2 only shows 8 lines of foreground color all 16 lines of foreground colors must be set in the command used or not.

To change the color of the sprite you can use the COLOR command and specify all 16 lines of the sprite for the new colors.

## EXAMPLE:

```
10 CALL GRAPHICS(3,3)
20 CALL MAGNIFY(4)
30 CALL SPRITE2(#1,78,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,50,50,4,4)
40 REM specify all 16 of the new colors for SPRITE2

100 INPUT A$:IF A$="N" THEN 200
100 REM GET READY TO CHANGE THE COLOR
200 CALL COLOR(#1,16,15,14,13,12,11,10,9,8,7,6,5,4,3,2,1)
300 GOTO 300
```

**SPRITESET****SPRITESET**

## Format

CALL SPRITSET

## Cross Reference

SPRITE, SPRITE2, COINC, COLOR, DELSPRITE, DISTANCE, GRAPHICS, LOCATE, MAGNIFY, MOTION, PATTERN, POSITION, SCREEN

## Description

SPRITESET is similar to the CHARSET command as it also restores the default character definitions but for the SPRITE characters.

**SQR****SQR**

## Format

`SQR(numeric-expression)`

## Type

REAL

## Description

The SQR function returns the positive square root of the value of the numeric-expression.

The value of the numeric-expression cannot be negative. Examples

```
100 PRINT SQR(4)
```

Prints 2.

```
100 X=SQR(2.57E5)
```

Sets X equal to the square root of 257,000, which is 506.9516742255.

## STOP

## STOP

Format  
STOP

Cross  
Reference END

Description  
The STOP statement stops the execution of your program.

When your computer encounters a STOP statement, the computer performs the following operations:

- It closes all open files.

- It restores the default character definitions of all characters.

- Restores the default foreground-color (black) and background-color (transparent) to all characters.

- Restores the default screen color (cyan).

- Deletes all sprites.

- Resets the sprite magnification level to 1.

The graphics colors (see DCOLOR) and current position (see DRAWTO) are not affected. If the computer is in GRAPHICS(1,1),(2,1),(3,1) the graphics mode and margin settings remain unchanged.

A STOP statement is not necessary to stop your program; the program automatically stops after the highest-numbered line is executed.

STOP is frequently used before a command that follows the main portion of a program, to ensure that the command is not executed after the execution of the highest-numbered line in the main program.

STOP can be used interchangeably with the END statement, except that you cannot use STOP to end a command.

### Program

The following program illustrates a use of the STOP statement. The program adds the numbers from 1 to 100.

```
100 CALL CLEAR
110 TOT=0
120 NUMB=1
130 TOT=TOT+NUMB
140 NUMB=NUMB+1
150 IF NUMB>100 THEN PRINT TOT::STOP
160 GOTO 130
```

**STR\$****STR\$**

## Format

STR\$(numeric-expression)

## Type

String

## Cross Reference

VAL

## Description

The STR\$ function returns the string representation of the value of the numeric-expression.

STR\$ enables you to use the string representation of the numeric-expression with an instruction that requires a string-expression as a parameter.

STR\$ is the inverse of the VAL function.

STR\$ removes leading and trailing spaces.

## Examples

```
100 NUM$=STR$(78.6)
```

Sets NUM\$ equal to "78.6".

```
100 LL$=STR$(3E15)
```

Sets LL\$ equal to "3.E+15".

```
100 X$=STR$(A*4)
```

Sets X\$ equal to a string representation of whatever value is obtained when A is multiplied by 4. For instance, if A is equal to -8, X\$ is set equal to "-32".

**SUB****SUB**

## Format

SUB subprogram-name[(parameter[,...])]

## Cross Reference

CALL, SUBEND, SUBEXIT

## Description

The SUB statement is the first statement in a subprogram.

You can use a subprogram to separate a group of statements from the main program. Subprograms are generally used to perform a specific operation several times in the same program or in different programs, or to isolate variables that are specific to the subprogram.

Subprograms are accessed from your main program with a CALL statement. The subprogram-name in the SUB statement is the same name that you use in the CALL statement that transfers control to the subprogram.

The maximum length of a subprogram-name is 15 characters.

A user-written subprogram may NOT have the same subprogram-name as a built-in subprogram.

You can use parameters to pass values to a subprogram. Parameters must be valid names of variables or arrays.

SUBEND must be the last statement executed in a subprogram. When the computer encounters a SUBEND or a SUBEXIT statement in a subprogram, program control returns to the statement immediately following the CALL statement that called the subprogram.

It is recommended that you do not use any statement other than SUBEND or SUBEXIT to leave a subprogram. If you use another statement to leave a subprogram you may still be using variables local to the subprogram, which may cause unexpected results.

Note: Subprograms must have higher line numbers than any part of your main program. A SUB statement cannot be part of an IF THEN statement. If you have a subprogram HELP1 that calls HELP2, then HELP2 must precede HELP1 in the program.

## Subprogram Variables

The variables used in a subprogram (other than those used as parameters) are local to the subprogram; that is, even if a variable in your main program has the same name as a variable in a subprogram, the value of that variable outside the subprogram is not affected by changes to its value in the subprogram. If a subprogram is called more than once, any local variables used in the subprogram retain their values from one call to the next.

## Parameters

When your program executes a subprogram beginning with a SUB statement with parameters, the parameter values (constants or variables) are passed from the parameter-list of the CALL statement to the subprogram. The parameter-list in the CALL statement must contain the same number of parameters as the SUB statement. Values are passed in the order in which they are listed.

A numeric parameter must be passed a numeric value. A string parameter must be passed a string value.

An array parameter must be passed an array. A string-array parameter must be passed a string array.

To pass an entire array as one parameter, follow the array name with left and right parentheses. If the array has more than one dimension, place one comma between the parentheses for each additional dimension.

### Passing Parameters by Reference and Value

When a subprogram manipulates the value of a parameter passed to it, the new parameter value may or may not be passed back to the main program. When a parameter is passed to a subprogram "by reference", the new value is passed back to the main program after the subprogram has executed.

When a parameter is passed to a subprogram "by value", the new value is not passed back to the main program.

Variables, array elements, and arrays are normally passed by reference. However, if a numeric variable or array element is of a different data-type in the main program than it is in the subprogram, the parameter is passed by value.

To specify that a variable or array element is to be passed by value rather than by reference, enclose it in parentheses in the CALL statement's parameter-list. Note that this option is not available for arrays.

If you use an expression as a parameter, it is evaluated and passed by value.

### Examples

```
100 SUB MENU
```

Marks the beginning of a subprogram. No parameters are passed or returned.

```
100 SUB MENU(COUNT,CHOICE)
```

Marks the beginning of a subprogram. The variables COUNT and CHOICE may be used and/or have their values changed in the subprogram and returned to the variables in the same position in the calling statement.

```
100 SUB PAYCHECK(DATE,Q,SSN,PAYRATE,TABLE(,))
```

Marks the beginning of a subprogram. The variables DATE, Q, SSN, PAYRATE, and the array TABLE with two dimensions may be used and/or have their values changed in the subprogram and returned to the variables in the same position in the calling statement.

#### Program

The following program illustrates a use of SUB. The subprogram MENU had been previously saved with the MERGE option. It prints a menu and requests a choice. The main program tells the subprogram how many choices there are and

what the choices are. It then uses the choice made in the subprogram to determine what program to run.

```
100 CALL MENU(5,R)
110 ON R GOTO 120,130,140,150,160
120 RUN "DSK1.PAYABLES"
130 RUN "DSK1.RECEIVE"
140 RUN "DSK1.PAYROLL"
150 RUN "DSK1.INVENTORY"
160 RUN "DSK1.LEDGER"
170 DATA ACCOUNTS PAYABLE,ACCOUNTS
RECEIVABLE,PAYROLL,INVENTORY,GENERAL
LEDGER
```

Beginning of subprogram MENU.

Note that this R is not the same as the R used in lines 100 and 110 in the main program.

```
10000 SUB MENU(COUNT,CHOICE)
10010 CALL CLEAR
10020 IF COUNT>22 THEN PRINT "TOO MANY ITEMS" CHOICE=0 :: SUBEXIT
10030 RESTORE
10040 FOR R=1 TO COUNT
10050 READ TEMP$
10060 TEMP$=SEG$(TEMP$,1,25)
10070 DISPLAY AT(R,1):R;TEMP$
10080 NEXT R
10090 DISPLAY AT(R+1,1):"YOUR CHOICE: 1"
10100 ACCEPT AT(R+1,14)BEEP VALIDATE(DIGIT)SIZE(-2):CHOICE
10110 IF CHOICE>COUNT OR CHOICE<1 THEN 10100
10120 SUBEND
```

**SUBEND****SUBEND**

Format  
SUBEND

Cross Reference  
SUB, SUBEXIT

Description  
The SUBEND statement marks the end of a subprogram.

SUBEND must be the last statement executed in a subprogram. When the computer encounters a SUBEND statement in a subprogram, program control returns to the statement immediately following the CALL statement that called the subprogram.

It is recommended that you do not use any statement other than SUBEND or SUBEXIT to leave a subprogram. If you use another statement to leave a subprogram you may still be using variables local to the subprogram, which may cause unexpected results.

A SUBEND statement cannot be part of an IF THEN statement.

The only statements that can immediately-follow a SUBEND statement are REM, END, or the SUB statement for the next subprogram.

## SUBEXIT

## SUBEXIT

Format  
SUBEXIT

Cross Reference  
SUB, SUBEND

### Description

The SUBEXIT statement enables you to leave a subprogram before the computer executes the SUBEND statement that ends the subprogram.

SUBEXIT enables you to have more than one exit from a subprogram.

When the computer encounters a SUBEXIT statement in a subprogram, program control returns to the statement immediately following the CALL statement that called the subprogram.

It is recommended that you do not use any statement other than SUBEND or SUBEXIT to leave a subprogram. If you use another statement to leave a subprogram you may still be using variables local to the subprogram, which may cause unexpected results.

**SWAP****SWAP****Format**

CALL SWAP var1, var2

**Description**

The SWAP statement is used to exchange the values of two variables, provided they are of the same type and precision. If they are not of the type an error will occur.

The SWAP statement cannot be used to "SWAP" the contents of two arrays, except as individual elements.

There is a required space between SWAP and var1.

**Examples**

```
100 FOR I=1 TO 100
110 CALL SWAP A$(I),B$(I)
120 NEXT I
```

The SWAP statement can also be used to alphabetize two strings.

```
100 INPUT "STRING #1 >":A$
110 INPUT "STRING #2 >":B$
120 IF A$>B$ THEN CALL SWAP A$,B$
130 PRINT A$,B$
```

SWAP can also be used with a DEFvartype.

```
100 DEFSTR B
110 A$="TEST"
120 B$="TEST1"
130 SWAP A$,B
140 PRINT A$,B
```

**TAB****TAB**

## Format

TAB(numeric-expression)

## Cross Reference

DISPLAY, PRINT

## Description

The TAB function specifies the starting position of the next item to be printed by a PRINT or DISPLAY instruction.

The numeric-expression specifies the starting position of the next print item in a print-list of a PRINT or DISPLAY instruction.

If the value of the numeric-expression is not an integer, it is rounded to the nearest integer. If the value of the numeric-expression is less than 1, it is replaced by 1.

If the value of the numeric-expression is greater than the record length of the screen or device, it repeatedly reduced by the record length until it is less than or equal to the record length. The record length of the screen is the width of the screen window defined by the margins. For more information about the record length of a particular device, refer to the owner's manual that comes with that device.

Because the TAB function itself is treated as a separate print item, it must be preceded and /or followed by a print separator (usually a semicolon), unless it is the only item in the print-list.

If the number of characters already printed in the current record is greater than or equal to the position indicated by the value of the numeric-expression, the print item following the TAB is printed in the next record, beginning in the position specified by the value of the numeric-expression.

TAB can be used to print to a device or file only if the device or file has been opened in DISPLAY format.

TAB cannot be used with PRINT USING or DISPLAY USING.

## Examples

```
100 PRINT TAB(12);35
```

Prints the number 35 at the twelfth position from left margin.

```
100 PRINT 356;TAB(18);"NAME"
```

Prints 356 at the beginning of the line and NAME at the eighteenth position from the left margin.

```
100 PRINT "ABCDEFGHIJKLM";TAB(5);"NOP"
```

Prints ABCDEFGHIJKLM at the beginning of the line and NOP at the fifth position of the next line.

**TAN****TAN**

## Format

TAN(numeric-expression)

## Type

REAL

## Cross Reference

ATN, COS, SIN

## Description

The TAN function returns the tangent of the angle whose measurement in radians is the value of the numeric-expression.

The numeric-expression cannot be less than  $-1.5707963269514E10$  or greater than  $1.5707963266374E10$ .

To convert the measure to radians, multiply by  $\pi/180$ .

## Program

The following program gives the tangent for each of several angles.

```

100 A=.7853981633973
110 B=26.5650511177
120 C=45*PI/180
130 PRINT TAN(A);TAN(B)
140 PRINT TAN(B*PI/180)
150 PRINT TAN(C)
RUN
1.      7.17470553
.5
1

```

## TCOLOR

## TCOLOR

### Format

CALL TCOLOR(foreground-color,background color)

### Cross Reference

PALETTE, GRAPHICS

### Description

The TCOLOR command enables you to change the foreground-color and background-color of text characters in all GRAPHIC modes except(1,1).

In GRAPHICS(1,2),(1,3),(2,2),(2,3),(3,2),(3,3) text will take on the color of the last TCOLOR command issued. Therefore multi-colored text is able.

In TEXT modes GRAPHICS(2,1),(3,1), the command sets the full screen text to one fore and one background color.

### Example

```
100 CALL GRAPHICS(2,1)
200 CALL TCOLOR(16,2)
This sets the color to white on black for all text in the 40 column mode.
```

```
100 CALL GRAPHICS(2,2)
200 CALL TCOLOR(2,16)
300 PRINT "BLACK ON WHITE"
400 CALL TCOLOR(16,2)
500 PRINT "WHITE ON BLACK"
This will first make black on white text then white on black text.
```

**TERMCHAR--Function--Termination Character****TERMCHAR**

Format  
TERMCHAR

Type  
DEFINT

Cross Reference  
ACCEPT, INPUT, LINPUT

**Description**

The TERMCHAR function returns the character code of the key pressed to exit from the previously executed INPUT, ACCEPT, or LINPUT statement.

In a program, the value returned by TERMCHAR depends on the key pressed to exit from the last instruction that accepted input from the keyboard.

VALUE RETURNED	KEY
1	F7 AID
2	F4 CLEAR
10	FX or DOWN ARROW
11	FE or UP ARROW
12	F6 PROC'D
13	ENTER
14	F5 BEGIN
15	F9 BACK

If you use TERMCHAR as part of a command(unless it is preceded by ACCEPT, INPUT, or LINPUT), the value returned depends on the key to enter the command(ENTER, UP ARROW, or DOWN ARROW).

Note that pressing CLEAR during keyboard input normally causes a break in the program. However, if your program includes an ON BREAK NEXT statement, you can use CLEAR to exit from an input field.

**Program**

The following program illustrates a use of TERMCHAR. The program displays name, address, and city, state, and zip code information entered from the keyboard. Line 160 enables you to correct errors in previously entered lines by pressing UP ARROW. This returns the cursor to the beginning of the line that immediately precedes the one from which UP ARROW was entered.

```

100 CALL CLEAR
110 R=5:C=12
120 DISPLAY AT(R,C-10):"NAME :"
130 DISPLAY AT(R+1,C-10):"ADDRESS:"
140 DISPLAY AT(R+2,C-10):"C,S,Z:"
150 ACCEPT AT(R,C)SIZE(-20):A$(R)
160 IF TERMCHAR=11 THEN R=R-1 ELSE R=R+1
170 IF R=8 THEN 180 ELSE 150
180 DISPLAY AT(20,1):A$(5):A$(6):A$(7)

```

**TIME/TIME\$****TIME/TIME\$****Description**

The computer has an internal clock that can be accessed from BASIC.

TIME\$ can be used to read the clock and TIME to set the clock.

**TO SET CLOCK****Format**

```
CALL TIME("hh:mm:ss")
```

The string length is always 8 characters. Therefore an hour less than 10 must be preceded by a 0.

The clock works on 24 hour time so all times after 12 noon must have 12 hours added to them.

**Example**

```
CALL TIME("06:15:00")      6:15 A. M.
CALL TIME("18:15:00")      6:15 P. M.
```

**TO READ CLOCK****Format**

```
PRINT TIME$
OR
T$=TIME$
```

**Example**

```
10 CALL CLEAR
20 DISPLAY AT(24,1):TIME$
30 GOTO 20
```

```
10 CALL TIME("00:00:00")
20 FOR I=1 TO 10000
30 NEXT I
40 PRINT TIME$
```

This is an easy to see how long a program takes to execute.

**TRACE****TRACE**

## Format

TRACE ON

TRACE OFF

## Description

The TRACE ON instruction causes the computer to display the line number of each line in your program before it is executed.

TRACE ON enables you to see the order in which the computer performs statements as it runs your program. It is valuable as a debugging aid to help you find errors (such as unwanted infinite loops) in your program.

TRACE **OFF** removes the effect of the TRACE ON command.

You can use TRACE ON or TRACE OFF either as a program statement or a command.

## Programs

The following programs display a trace of the order of execution of the program lines.

```
100 FOR J=1 TO 3
110 PRINT "WORD"
120 NEXT J
130 TRACE ON
RUN
```

```
100 FOR J=1 TO 3
110 PRINT "WORD"
120 NEXT J
TRACE ON
RUN
```

**UNBREAK****UNBREAK**

## Format

UNBREAK [line-number-list]

## Cross Reference

BREAK

## Description

The UNBREAK instruction removes a break-point from each program statement you specify.

You can use UNBREAK as either a program statement or a command.

The line-number-list consists of one or more line numbers separated by commas. When an UNBREAK instruction is executed, break-points are removed from the specified program lines.

If you do not include a line-number-list, UNBREAK removes all break-points, except for a break-point that occurs when a BREAK statement with no line-number-list is encountered in a program.

If the line-number-list includes an invalid line number (0 or a value greater than 32767), the message Bad line number is displayed. If the line-number-list includes a fractional or negative line number, the message Syntax error is displayed. In both cases, the UNBREAK instruction is ignored; that is, break-points are not removed even at valid line numbers in the line-number-list. If you were entering UNBREAK as a program statement, it is not entered into your program.

If the line-number-list includes a line number that is valid (1-32767) but is not the number of a line in your program, or a fractional number greater than 1, the message

```
* WARNING
  LINE NOT FOUND
```

is displayed. (If you were entering UNBREAK as a program statement, the line-number is included in the warning message). A break-point is, however, removed from any valid line in the line-number-list that precedes the line number that caused the warning.

## Examples

UNBREAK

450 UNBREAK

Removes all break-points (except those resulting from a BREAK statement with no line-number-list).

UNBREAK 100,130

350 UNBREAK 100,130

Removes the break-points from lines 100 and 130.

**VAL****VAL**

## Format

`VAL(string-expression)`

## Type

REAL

## Cross Reference

STR\$

## Description

The VAL function returns the numeric value of the string-expression.

VAL enables you to use the numeric value of the string-expression with an instruction that requires a numeric-expression as a parameter.

VAL is the inverse of the STR\$ function.

The string-expression must be a valid representation of a number. The length of the string-expression must be greater than 0 and less than 255. If you use a string constant, it must be enclosed in quotation marks.

## Examples

```
100 NUMB=VAL("78.6")
```

```
110 PRINT NUMB
```

Prints 78.6.

```
100 LL=VAL("3E15")
```

Sets LL equal to 3E+15, or 315.

## VALHEX

## VALHEX

### Format

VALHEX(string-expression)

### Type

DEFINT

### Description

VALHEX returns the numeric value of the hexadecimal number represented by the string-expression.

The string-expression specifies the hexadecimal (base 16) number to be converted to a decimal (base 10) number. If you use a string constant, it must be enclosed in quotation marks.

The string-expression must contain only valid hexadecimal digits (0-9,A-F). Alphabetic hexadecimal digits must be upper-case letters. VALHEX can convert a hexadecimal number from one to four digits long. If the length of the string-expression is greater than four, VALHEX uses only the last four characters.

VALHEX returns an integer greater than or equal to -32768 (hexadecimal 8000) and less than or equal to 32767 (hexadecimal 7FFF).

### Examples

```
100 A=VALHEX("400A")  
Sets A equal to 16394.
```

```
100 PRINT VALHEX("8200")  
Prints -32256.
```

**VCHAR****VCHAR****Format**

CALL VCHAR(row,column,character-code[,number-of-repetitions])

**Cross Reference**

DCOLOR, GCHAR, GRAPHICS, HCHAR

**Description**

The VCHAR command enables you to place a character on the screen and repeat it horizontally.

Row and column are numeric-expressions whose values specify the position on the screen where the character is displayed.

The value of row must be greater than or equal to 1 and not exceed the total number of rows in the present graphics mode.

The value of column must be greater than or equal to 1 and must not exceed the total number of columns in the present graphics mode.

VCHAR is not affected by margin settings.

Character-code is a numeric-expression with a value from 0-255, specifying the number of the character. See Appendix B for a list of ASCII character codes.

The optional number-of-repetitions is a numeric-expression whose value specifies the number of times the character is repeated horizontally. If the repetitions extend past the end of a column, they continue from the first character of the next column. If the repetitions extend past the end of the last column, they continue from the first character of the first column.

If you use VCHAR to display a character on the screen, and then later use CHAR, COLOR, or DCOLOR to change the appearance of that character, the result depends on the graphics mode.

In GRAPHICS(1,1),(2,1),(3,1) , the displayed character changes to the newly specified pattern and/or color(s).

In High-Resolution Mode, the displayed character remains unchanged.

## Examples

```
100 CALL VCHAR(12,16,33)
```

Places character 33 (an exclamation point) in row 12, column 16.

```
100 CALL VCHAR(1,1,ASC("!"),768)
```

Places an exclamation point in row 1, column 1, and repeats it 768 times, which fills the screen in Pattern Mode GRAPHICS(1,1) .

```
100 CALL VCHAR(R,C,K,T)
```

Places the character with an ASCII code specified by the value of K in row R, column C, and repeats it T times.

**VERSION****VERSION**

## Format

CALL VERSION(numeric-variable)

## Description

The VERSION command returns a value indicating the version of BASIC being used.

In Geneve 9640 Advanced BASIC, VERSION returns a value of the current version of Advanced BASIC to the numeric-variable you specify.

## Example

100 CALL VERSION(V)

Sets V equal to current version.

**WEND****WEND**

The WEND statement terminates the loop that begins with WHILE.

Statements between WHILE and WEND are executed repeatedly until the condition stated in the WHILE statement is no longer true.

Unlike FOR-NEXT statements, WHILE-WEND loops may NOT be nested. WEND always continues the most recent while loop until the WHILE statement's condition becomes false.

See WHILE for detailed description of the WHILE-WEND loop.

**WHILE****WHILE**

## Format

```
WHILE condition :: .....program..... :: WEND
```

## Cross Reference

WEND, FOR-NEXT, IF-THEN-ELSE

## Description

The WHILE statement starts a loop which is executed repeatedly while the WHILE 'condition' is true. The loop is terminated with a WEND statement.

'Condition' is a logical expression, numeric or variable that WHILE evaluates. If the 'condition' is TRUE (or a non/zero value, i.e. condition<>0), the program then loops between the WHILE and the WEND statements. When the condition is no longer TRUE (false or condition=0) WHILE passes execution to the statement after WEND.

Unlike FOR-NEXT statements WHILE-WEND loops may NOT be nested.

## Example

```
100 WHILE S=0
110 CALL KEY(0,K,S)::REM will loop till S<>0 then next line past WEND
120 WEND
130 ..... program lines
140 END
```

This short routine checks the entries into the keyboard buffer until it is empty then proceeds to the rest of the program. The keyboard is said to be "Flushed".

```
100 REM WHILE TEST
110 WHILE NAME$<>"LAST"
120 READ NAME$,PHONE$
130 COUNT=COUNT+1
140 PRINT NAME$;TAB(20);PHONE$
150 WEND
160 PRINT "NUMBER OF NAMES=";COUNT
170 PRINT "WHILE HAS BEEN EVALUATED TO FALSE"
180 DATA GENEVE, 201-766-1700
190 DATA JIM UZZELL,201-000-0000
200 DATA LAST, LAST
```

## I/O DEFAULTS

Geneve 9640 Advanced BASIC includes several features to simplify the direction of input and output to certain devices. These devices are your main storage device (typically DSK1), your main printer (typically PIO). These defaults are set from the operating system defaults when BASIC is initially started.

The following names are used for reassigning a particular default device:

NAME	DEVICE
LPT	Default printing device
CHDIR	Default disk drive or directory

These commands can not be used in a program as a program statement.

The following can be used as a program statement for reassigning a particular device.

KEY(11)="string-expression"	Changes working directory or drive.
KEY(12)="string-expression"	Changes the printing device.

These are the only uses for these keys and should not be confused with the KEY command.

To change a default, type the command and follow it by the desired device name. For example, the LLIST command prints the program in memory to the main printer port. If your printer is connected to the RS232 port and not the PIO port you would need to redirect the output from LLIST. To do this type from the prompt

```
LPT      RS232[.BA=4800.....]
```

To change drives or directory, from the prompt type CHDIR "path.[directory]"

You may also check to see what a particular default is set for at any time. To do this, type any of the following commands and BASIC will list what that device is set for:

COMMAND	DEVICE
PPT	Lists the default printer
PWD	Lists the default working directory
KEY LIST	Lists both of the above and the default of FCTN keys 1-10.

## ADVANCED BASIC LOADING OPTIONS

When invoking ABASIC from the MDOS command line or a batch file you may also want to invoke several available options. One option is the amount of memory allocated to data space. The following depicts the memory allocation for ABASIC:

ABASIC INTERAL 56K ----- DATA BUFFERS 8K	PROGRAM MEMORY 64K	ASSEMBLY LANGUAGE SUBROUTINES 48K	DATA SPACE VARIABLES AND STRINGS 64K OR GREATER
--	--------------------------	--	---

Memory allocation is fixed except for data space. Data space can be as small as 64K(the default amount), or as large as the available memory in your 9640. with a standard GENEVE, this is limited to 192K minus any RAMDISK and/or SPOOLER rounded to the nearest 8K multiple. Note: This could change if the size of MDOS changes.

To request data space greater than 64K, simply type a space followed by the amount of memory desired (in 8K byte multiples i.e. 128,192) after typing ABASIC1 from the command line of MDOS or in a batch file.

Another optional parameter in the command line or batch file is the selection of the initial default directory and the initial program to be loaded and executed. In order to set a different default directory in ABASIC, type a space and the desired directory pathname ending with a period. ABASIC will set this as the default directory and initially try to load and execute a file named "LOAD" on this directory. If you would like to initially execute another program on the default directory, simply enter the filename. Lastly, if you want to load the ABASIC interpreter and inhibit the auto load of the initial program, enter an asterisk "\*". The following examples should help you understand these capabilities better:

ABASIC1 \*                Sets the default directory to that of MDOS(usually DSK1) and goes to the command mode of ABASIC

ABASIC1                Sets the default directory to that of MDOS(usually DSK1) and attempts to load and run the program LOAD.

ABASIC 128 DSK2.PROG1   Attempts to allocate 128K to DATA space, sets the default directory to DSK2 and attempts to load and run the program PROG1.

ABASIC1 128 DSK2.\*       Attempts to allocate 128K to DATA space, set the default directory to DSK2 and goes to the command mode of ABASIC.

NOTE: It is recommended that ABASIC be started from a batch file.

## APPENDICES

- Appendix A: List of Commands, Statements, and Functions
- Appendix B: ASCII Codes
- Appendix C: Musical Tone Frequencies
- Appendix D: Character Sets
- Appendix E: Pattern-Identifier Conversion Table
- Appendix F: Color Codes
- Appendix G: Mathematical Functions
- Appendix H: List of Speech words
- Appendix I: Adding Suffixes to Speech words
- Appendix J: Error Messages
- Appendix K: Graphics Modes - Summary
- Appendix L: Program - Illustrating MOUSE Commands
- Appendix M: Call Key ASCII Characters Chart
- Appendix N: ABASIC Assembly Support and other information
- Appendix O: Color Palette and hexadecimal charts
- Appendix P: RS232 Info and OUTP example



RETURN		STOP	C	CALL VCHAR	C
CALL SAY	C	SUB		CALL VERSION	C
CALL SCREEN	C	SUBEND		WEND	
CALL SOUND	C	SUBEXIT		WHILE	
CALL SPGET	C	CALL SWAP			
CALL SPRITE	C	CALL TIME	C		

## Geneve 9640 Advanced BASIC Functions

ABS	HEX\$	SEG\$
ASC	LEFT\$	SGN
ATN	LEN	SIN
CDBL	LOG	SIR
CHR\$	MAX	STR\$
CINT	MIN	TAB
COS	MOD	TAN
CREAL	PI	TERMCHAR
CSING	POS	TIME\$
DATE\$	REC	VAL
EOF	RND	VALHEX
EXP	RIGHT\$	
FREESPACE	RPT\$	
INT		

**APPENDIX B**

## ASCII CODES

The following predefined characters may be printed or displayed on the screen.

ASCII CODE	CHARACTER	ASCII CODE	
30	(cursor)	63	? (question mark)
31	(space)	64	@ (at sign)
32	(space)	65	A
33	! (exclamation point)	66	B
34	" (quote)	67	C
35	# (number or pound sign)	68	D
36	\$ (dollar)	69	E
37	% (percent)	70	F
38	& (ampersand)	71	G
39	' (apostrophe)	72	H
40	( (open parenthesis)	73	I
41	) (close parenthesis)	74	J
42	* (asterisk)	75	K
43	+ (plus)	76	L
44	, (comma)	77	M
45	- (minus)	78	N
46	. (period)	79	O
47	/ (slash)	80	P
48	0	81	Q
49	1	82	R
50	2	83	S
51	3	84	T
52	4	85	U
53	5	86	V
54	6	87	W
55	7	88	X
56	8	89	Y
57	9	90	Z
58	: (colon)	91	[ (open bracket)
59	; (semicolon)	92	\ (reverse slant)
60	< (less than)	93	] (close bracket)
61	= (equals)	94	(exponentiation)
62	> (greater than)	95	_ (underline)

## ASCII Codes (continued)

96	' (accent grave)	112	
97		113	
98		114	
99		115	
100		116	
101		117	
102		118	
103		119	
104		120	
105		121	
106		122	
107		123	{ (left Brace)
108		124	(vertical Bar)
109		125	} (right Brace)
110		126	~ (Tilde)
111		127	DEL (appears as blank)

When key unit = 3 or = 5, the following key presses may also be detected by CALL KEY.

1	Alt 7 (aid)	3	Alt 1 (del)
4	Alt 2 (insert)	6	Alt 8 (redo)
7	Alt 3 (erase)	8	Alt S (left)
9	Alt D (right)	10	Alt X (down)
11	Alt E (up)	12	Alt 6 (cmd)
13	ENTER	14	Alt 5 (begin)
15	Alt 9 (back)		

APPENDIX C

## MUSICAL TONE FREQUENCIES

The following table gives the frequencies (rounded to integers) of four octaves of the tempered scale (one half step between notes). while this list does not represent the entire range of notes that the computer can produce, it can be helpful for programming music.

FREQUENCY	NOTE	FREQUENCY	NOTE
110	A	440	A (above middle C)
117	A#,Bb	466	A#,Bb
123	B	494	B
131	C (low C)	523	C (high C)
139	C#,Db	554	C#,Db
147	D	587	D
156	D#,Eb	622	D#,Eb
165	E	659	E
175	F	698	F
185	F#,Gb	740	F#,Gb
196	G	784	G
208	G#,Ab	831	G#,Ab
220	A (below middle C)	880	A (above high C)
220	A (above middle C)	880	A (above high C)
223	A#,Bb	932	A#,Bb
247	B	988	B
262	C (middle C)	1047	C
277	C#,Db	1109	C#,Db
294	D	1175	D
311	D#,Eb	1245	D#,Eb
330	E	1319	E
349	F	1397	F
370	F#,Gb	1480	F#,Gb
392	G	1568	G
415	G#,Ab	1661	G#,Ab
440	A (above middle C)	1760	A



APPENDIX D

CHARACTER SETS

SET	ASCII CODES	SET	ASCII CODES
29	0-7	13	128-135
30	8-15	14	136-143
31	16-23	15	144-151
0	24-31	16	152-159
1	32-39	17	160-167
2	40-47	18	168-175
3	48-55	19	176-183
4	56-63	20	184-191
5	64-71	21	192-199
6	72-79	22	200-207
7	80-87	23	208-215
8	88-95	24	216-223
9	96-103	25	224-231
10	104-111	26	232-239
11	112-119	27	240-247
12	120-127	28	248-255

APPENDIX E


PATTERN-IDENTIFIER CONVERSION TABLE

BLOCK

BINARY  
CODE

HEXADECIMAL

(0=OFF; 1=ON)  
NOTATION



0000

	0	
0001	1	
	0010	2
0011	3	
0100	4	
0101	5	
0110	6	
0111	7	
	1000	8
1001	9	
1010	A	
1011	B	
1100	C	
1101	D	
1110	E	
1111	F	

**APPENDIX F****COLOR CODES**

COLOR	CODE	COLOR	CODE
Transparent	1	Medium Red	9
Black	2	Light Red	10
Medium Green	3	Dark Yellow	11
Light Green	4	Light Yellow	12
Dark Blue	5	Dark Green	13
Light Blue	6	Magenta	14
Dark Red	7	Gray	15
Cyan	8	White	16

**APPENDIX G****MATHEMATICAL FUNCTIONS**

The following mathematical functions may be defined with DEF as shown.

Function	Geneve 9640 Advanced BASIC statement
Secant	DEF SEC(X)=1/COS(X)
Cosecant	DEF CSC(X)=1/SIN(X)
Cotangent	DEF COT(X)=1/TAN(X)
Inverse Sine	DEF ARCSIN(X)=ATN(S/SQR(1/X*X))
Inverse Cosine	DEF ARCCOS(X)=ATN(X/SQR(1/X*X))+PI/2
Inverse Secant	DEF ARCSEC(X)=ATN(SQR(X*X/1))+(SGN(X)/1)*PI/2
Inverse Cosecant	DEF ARCCSC(X)=ATN(1/SQR(X*X/1))+(SGN(X)-1)*PI/2
Inverse Cotangent	DEF ARCCOT(X)=PI/2-ATN(X) or =PI/2+ATN(-X)
Hyberbolic Sine	DEF SINH(X)=(EXP(X)-EXP(-X))/2
Hyberbolic Cosine	DEF COSH(X)=(EXP(X)+EXP(-X))/2
Hyperbolic Tangent	DEF TANH(X)=2*EXP(-X)/(EXP(X)+EXP(-X))+1
Hyperbolic Secant	DEF SECH=2/(EXP(X)+EXP(-X))
Hyperbolic Cosecant	DEF CSCH=2/(EXP(X)-EXP(-X))
Hyperbolic Cotangent	DEF COTH(X)=2*EXP(-X)/(EXP(X)-EXP(-X))+1
Inverse Hyperbolic Sine	DEF ARCSINH(X)=LOG(X+SQR(X*X+1))
Inverse Hyperbolic Cosine	DEF ARCCOSH(X)=LOG(X+SQR(X*X-1))
Inverse Hyperbolic Tangent	DEF ARCTANH(X)=LOG((1+X)/(1-X))/2
Inverse Hyperbolic Secant	DEF ARCSECH(X)=LOG((1+SQR(1-X*X))/X)
Inverse Hyperbolic Cosecant	DEF ARCCSCH(X)=LOGUSGN(X)*SQR(X*X+1)+1)/X)
Inverse Hyperbolic Cotangent	DEF ARCCOTH(X)=LOG((X+1)/(X-1))/2

APPENDIX H

## LIST OF SPEECH WORDS

The following is a list of all the letters, numbers, words, and phrases that can be accessed with CALL SAY and CALL SPGET. See Appendix M for instructions on adding suffixes to anything in this list.

/ (NEGATIVE)	CENTER	F
+ (POSITIVE)	CHECK	FIFTEEN
0	CLEAR	FIGURE
1	COLOR	FIND
2	COME	FINE
3	COMES	FINISH
4	COMMA	FINISHED
5	COMMAND	FIRST
6	COMPLETE	FIT
7	COMPLETED	FIVE
8	COMPUTER	FOR
9	CONNECTED	FORTY
A (a)	CONSOLE	FOUR
Al ( )	CORRECT	FOURTEEN
ABOUT	COURSE	FOURTH
AFTER	CYAN	FROM
AGAIN	0	FRONT
ALL	DATA	G
AM	DECIDE	GAMES
AN	DEVICE	GET
AND	DID	GETTING
ANSWER	DIFFERENT	GIVE
ANY	DISKETTE	GIVES
ARE	DO	GO
AS	DOES	GOES
ASSUME	DOING	GOING
AT	DONE	GOOD
B	DOUBLE	GOOD WORK
BACK	DOWN	GOODBYE
BASE	DRAW	GOT
BE	DRAWING	GRAY
BETWEEN	E	GREEN
BLACK	EACH	GUESS
BLUE	EIGHT	H
BOTH	EIGHTY	HAD
BOTTOM	ELEVEN	HAND
BUT	ELSE	HANDHELD UNIT
BUY	END	HAS
BY	ENDS	HAVE
BYE	ENTER	HEAD
C	ERROR	HEAR
CAN	EXACTLY	HELLO
CASSETTE	EYE	HELP

## List of Speech words (continued)

HERE	MEMORY	PRINTER
HIGHER	MESSAGE	PROBLEM
HIT	MESSAGES	PROBLEMS
HOME	MIDDLE	PROGRAM
HOW	MIGHT	PUT
HUNDRED	MODULE	PUTTING
HURRY	MORE	Q
I	MOST	R
I WIN	MOVE	RANDOMLY
IF	MUST	READ (read)
IN	N	READ1 (red)
INCH	NAME	READY TO START
INCHES	NEAR	RECORDER
INSTRUCTION	NEED	RED
INSTRUCTIONS	NEGATIVE	REFER
IS	NEXT	REMEMBER
IT	NICE TRY	RETURN
J	NINE	REWIND
JOYSTICK	NINETY	RIGHT
JUST •	NO	ROUND
K	NOT	S
KEY	NOW	SAID
KEYBOARD	NUMBER	SAVE
KNOW	0	SAY
L	OF	SAYS
LARGE	OFF	SCREEN
LARGER	OH	SECOND
LARGEST	ON	SEE
LAST	ONE	SEES
LEARN	ONLY	SET
LEFT	OR	SEVEN
LESS	ORDER	SEVENTY
LET	OTHER	SHAPE
LIKE	OUT	SHAPES
LIKES	OVER	SHIFT
LINE	P	SHORT
LOAD	PART	SHORTER
LONG	PARTNER	SHOULD
LOOK	PARTS	SIDE
LOOKS	PERIOD	SIDES
LOWER	PLAY	SIX
M	PLAYS	SIXTY
MADE	PLEASE	SMALL
MAGENTA	POINT	SMALLER
MAKE	POSITION	SMALLEST
ME	POSITIVE	SO
MEAN	PRESS	SOME
	PRINT	
	SORRY	



List of speech words (continued)

SPACE	THIRTEEN	WANT
SPACES	THIRY	WANTS
SPELL	THIS	WAY
SQUARE	THREE	WE
START	THREW	WEIGH
STEP	THROUGH	WEIGHT
STOP	TIME	WELL
SUM	TO	WERE
SUPPOSED	TOGETHER	WHAT
SUPPOSED TO	TOKE	WHAT WAS THAT
SURE	TOO	WHEN
T	TOP	WHERE
TAKE	TRY	WHICH
TEEN	TRY AGAIN	WHITE
TELL	TURN	WHO
TEN	TWELVE	WHY
TEXAS INSTRUMENTS	TWENTY	WILL
THAN	TWO	WITH
THAT	TYPE	WON
THAT IS INCORRECT	U	WORD
THAT IS RIGHT	UHOH	WORDS
THE (the)	UNDER	WORK
THE1(th )	UNDERSTAND	WORKING
THEIR	UNTIL	WRITE
THEN	UP	X
THERE	UPPER	Y
THESE	USE	YELLOW
THEY	V	YES
THING	VARY	YET
THINGS	VERY	YOU
THINK	W	YOU WIN
THIRD	WAIT	YOUR
		Z ZERO

APPENDIX I:

## ADDING SUFFIXES TO SPEECH WORDS

This appendix describes how to add ING, S, and ED to any word available in the Solid State Speech(tm) resident vocabulary.

The code for a word is first read using SPGET. The code consists of a number of characters, one of which tells the speech unit the length of the word. Then, by means of the subprograms listed here, additional codes can be added to give the sound of a suffix.

words often have trailing-off data that make the word sound more natural but prevent the easy addition of suffixes. In order to add suffixes this trailing-off data must be removed.

The following program allows you to input a word and, by trying different truncation values, make the suffix sound like a natural part of the word. The subprograms DEFING (lines 1000 through 1130), DEFS1 (lines 2000 through 2100), DEFS2 (lines 3000 through 3090), DEFS3 (lines 4000 through 4120), DEFED1 (lines 5000 through 5070), DEFED2 (lines 6000 through 6110), DEFED3 (lines 7000 through 7130), and MENU (lines 10000 through 10120) should be input separately and saved with the MERGE option. (The subprogram MENU is the same one used in the illustrative program with SUB.) You may wish to use different line numbers. Each of these subprograms (except MENU) defines a suffix.

DEFING defines the ING sound. DEFS1 defines the S sound as it occurs at the end of "cats." DEFS2 defines the S sound as it occurs at the end of "cads." DEFS3 defines the S sound as it occurs at the end of "wishes." DEFED1 defines the ED sound as it occurs at the end of "passed." DEFED2 defines the ED sound as it occurs at the end of "caused." DEFED3 defines the ED sound as it occurs at the end of "heated."

In running the program, enter a 0 for the truncation value in order to leave the truncation sequence.

```

100 REM *****
110 REM REQUIRES MERGE OF:
120 REM MENU (LINES 10000 THROUGH 10120)
130 REM DEFING (LINES 1000 THROUGH 1130)
140 REM DEFS1 (LINES 2000 THROUGH 2100)
150 REM DEFS2 (LINES 3000 THROUGH 3090)
160 REM DEFS3 (LINES 4000 THROUGH 4120)
170 REM DEFED1 (LINES 5000 THROUGH 5070)
180 REM DEFED2 (LINES 6000 THROUGH 6110)
190 REM DEFED3 (LINES 7000 THROUGH 7130)

```

## Adding Suffixes to Speech Words (continued)

```

200 REM*****
210 CALL CLEAR
220 PRINT "THIS PROGRAM IS USED TO"
230 PRINT "FIND THE PROPER TRUNCATION"
240 PRINT "VALUE FOR ADDING SUFFIXES"
250 PRINT "TO SPEECH WORDS.": :
260 FOR DELAY=1 TO 300::NEXT DELAY
270 PRINT "CHOOSE WHICH SUFFIX YOU"
280 PRINT "WISH TO ADD.":
290 FOR DELAY=1 TO 800::NEXT DELAY
300 CALL MENU(8,CHOICE)
310 DATA 'ING','S' AS IN CATS,'S' AS IN CADS,'S' AS IN WISHES,
      'ED' AS IN PASSED,'ED' AS IN CAUSED,'ED' AS IN HEATED, END
320 IF CHOICE=0 OR CHOICE=8 THEN STOP
330 INPUT "WHAT IS THE WORD? ":WORD$
340 ON CHOICE GOTO 350,379,390,410,430,450,470
350 CALL DEFING(D$)
360 GOTO 480
370 CALL DEFS1(D$)::!CATS
380 GOTO 480
390 CALL DEFS2(D$)::!CADS
400 GOTO 480
410 CALL DEFS3(D$)::!WISHES
420 GOTO 480
430 CALL DEFED1(DWPASSED$)
440 GOTO 480
450 CALL DEFED2(0$)!CAUSED
460 GOTO 480
470 CALL DEFED3(D$)!HEATED
480 REM TRY VALUES
490 CALL CLEAR
500 INPUT "TRUNCATE HOW MANY BYTES?":L
510 IF L=0 THEN 300
520 CALL SPGET(WORDS$,B$)
530 L=LEN(B$)-L-3
540 C$=SEG$(B$,2)&CHR$(L)&SEG$(B$,4,L)
550 CALL SAY(,C$&D$)
560 GOTO 500

```

## Adding Suffixes to Speech words (continued)

```
1000 SUB DEFING(A$)
1010 DATA 96,0,52,174,30,65
1020 DATA 21,186,90,247,122,214
1030 DATA 179,95,77,13,202,50
1040 DATA 153,120,117,57,40,248
1050 DATA 133,173,209,25,39,85
1060 DATA 225,54,75,167,29,77
1070 DATA 105,91,44,157,118,180
1080 DATA 169,97,161,117,218,25
1090 DATA 119,184,227,222,249,238,1
1100 RESTORE 1010
1110 A$=""
1120 FOR I=1 TO 55::READ A::A$=A$&CHR$(A)::NEXT I
1130 SUBEND
```

```
2000 SUB DEFS1(A$)!CATS
2010 DATA 96,0,26
2020 DATA 14,56,130,204,0
2030 DATA 223,177,26,224,103
2040 DATA 85,3,252,106,106
2050 DATA 128,95,44,4,240
2060 DATA 35,11,2,126,16,121
2070 RESTORE 2010
2080 A$=""
2090 FOR I=1 TO 29::READ A::A$=A$&CHR$(A)::NEXT I
2100 SUBEND
```

```
3000 SUB DEFS2(AWCAD$)
3010 DATA 96,0,17
3020 DATA 161,253,158,217
3030 DATA 168,213,198,86,0
3040 DATA 223,153,75,128,0
3050 DATA 95,139,62
3060 RESTORE 3010
3070 A$=""
3080 FOR I=1 TO 20::READ A::A$=A$&CHR$(A)::NEXT I
3090 SUBEND
```

## Adding Suffixes to Speech Words (continued)

```
4000 SUB DEFS3(AWWISHE$)
4010 DATA 96,0,34
4020 DATA 173,233,33,84,12
4030 DATA 242,205,166,55,173
4040 DATA 93,222,68,197,188
4050 DATA 134,238,123,102
4060 DATA 163,86,27,59,1,124
4070 DATA 103,46,1,2,124,45
4080 DATA 138,129,7
4090 RESTORE 4010
4100 A$=""
4110 FOR I=1 TO 37::READ A::A$=A$&CHR$(A)::NEXT I
4120 SUBEND

5000 SUB DEFED1(A$)::!PASSED
5010 DATA 96,0,10
5020 DATA 0,224,128,37
5030 DATA 204,37,240,0,0
5040 RESTORE 5010
5050 A$=""
5060 FOR I=1 TO 13::READ A::A$=A$&CHR$(A)::NEXT I
5070 SUBEND

6000 SUB DEFED2(A$)::!CAUSED
6010 DATA 96,0,26
6020 DATA 172,163,214,59,35
6030 DATA 109,170,174,68,21
6040 DATA 22,201,220,250,24
6050 DATA 69,148,162,166,234
6060 DATA 75,84,97,145,204
6070 DATA 15
6080 RESTORE 6010
6090 A$=""
6100 FOR I=1 TO 29::READ A::A$=WCHR$(A)::NEXT I
6110 SUBEND
```

## Adding suffixes to speech words (continued)

```
7000 SUB DEFED3(A$)::!HEATED
7010 DATA 96,0,36
7020 DATA 173,233,33,84,12
7030 DATA 242,205,166,183
7040 DATA 172,163,214,59,35
7050 DATA 109,170,174,68,21
7060 DATA 22,201,92,250,24
7070 DATA 69,148,162,38,235
7080 DATA 75,84,97,145,204
7090 DATA 178,127
7100 DATA 7010
7110 A$=""
7120 FOR 1=1 TO 39::READ A::A$=A$&CHR$(A)::NEXT I
7130 SUBEND

10000 SUB MENU(COUNT,CHOICE)
10010 CALL CLEAR
10020 IF COUNT>22 THEN PRINT "TOO MANY ITEMS" :: CHOICE=0 :: SUBEXIT
10030 RESTORE
10040 FOR 1=1 TO COUNT
10050 READ TEMP$
10060 TEMP$=SEG$(TEMP$,1,25)
10070 DISPLAY AT (I,1):I;TEMP$
10080 NEXT I
10090 DISPLAY AT(I+1,1):"YOUR CHOICE: 1"
10100 ACCEPT AT(I+1,14)BEEP VALIDATE(DIGIT)SIZE(-2):CHOICE
10110 IF CHOICE<1 OR CHOICE>COUNT THEN 10100
10120 SUBEND
```

## Adding Suffixes to Speech words (continued)

You can use the subprograms in any program once you have determined the number of bytes to truncate. The following program uses the subprogram DEFING in lines 1000 through 1130 to have the computer say the word DRAWING using DRAW plus the suffix ING. Note that it was found that DRAW should be truncated by 41 characters to produce the most natural sounding DRAWING. The subprogram DEFING in lines 1000 through 1130 is the program you saved with the MERGE option.

```

100 CALL DEFING(ING$)
110 CALL SPGET("DRAW",DRAWS$)
120 L=LEN(DRAW$)-3-41::! 3 BYTES OF SPEECH OVERHEAD, 41 BYTES
    TRUNCATED
130 DRAW$=SEG$(DRAW$,1,2)&CHR$(L)&SEG$(DRAW$,4,L)
140 CALL SAY("WE ARE",DRAW$UNGWA1 SCREEN")
150 GOTO 140
1000 SUB DEFING(A$)
1010 DATA 96,0,52,174,30,65
1020 DATA 21,186,90,247,122,214
1030 DATA 179,95,77,13,202,50
1040 DATA 153,120,117,57,40,248
1050 DATA 133,173,209,25,39,85
1060 DATA 225,54,75,167,29,77
1070 DATA 105,91,44,157,118,180
1080 DATA 169,97,161,117,218,25
1090 DATA 119,184,227,222,249,238,1
1100 RESTORE 1010
1110 A$=""
1120 FOR I=1 TO 55::READ A::A$=A$&CHR$(A)::NEXT I
1130 SUBEND
(Press SHIFT C to stop the program.)

```

APPENDIX J:

## ERROR MESSAGES

The following lists all the error messages that Geneve 9640 Advanced BASIC gives. The first list is alphabetical by the message that is given, and the second list is numeric by the number of the error that is returned by CALL ERR. If the error occurs in the execution of a program, the error message is often followed by IN line-number.

## Sorted by Message

#	Message	Descriptions of Possible Errors
74	BAD ARGUMENT	<ul style="list-style-type: none"> <li>* Bad value given in ASC, ATN, COS, EXP, INT, LOG, SIN, SOUND, SQR, TAN, or VAL.</li> <li>* An array element specified in a SUB statement.</li> <li>* Bad first parameter or too many parameters in LINK.</li> </ul>
61	BAD LINE NUMBER	<ul style="list-style-type: none"> <li>* Line number less than 1 or greater than 32767.</li> <li>* Omitted line number.</li> <li>* Line number outside the range 1 through 32767 produced by RES.</li> </ul>
57	BAD SUBSCRIPT	<ul style="list-style-type: none"> <li>* Use of too large or small subscript in an array.</li> </ul>
79	BAD VALUE	<ul style="list-style-type: none"> <li>* Incorrect subscript in DIM.</li> <li>* Incorrect value given in AND, CHAR, CHR\$, CLOSE, EOF, FOR, GOSUB, GOTO, HCHAR, INPUT, MOTION, NOT, OR, POS, PRINT, PRINT USING, REC, RESTORE, RPT\$, SEG\$, SIZE, VCHAR, or XOR.</li> <li>* Array subscript value greater than 32767.</li> <li>* File number greater than 255 or less than zero.</li> <li>* More than three tones and one noise generator specified in SOUND.</li> <li>* A value passed to a subprogram is not acceptable in the subprogram. For example, a sprite velocity value less than -128 or a character value greater than 143.</li> <li>* Value in ON...GOTO or ON...GOSUB greater than the</li> </ul>
67	CAN'T CONTINUE	<ul style="list-style-type: none"> <li>* Program has been edited after being stopped by a break-point.</li> <li>* Program was not stopped by a break-point.</li> </ul>
69	COMMAND ILLEGAL IN PROGRAM	<ul style="list-style-type: none"> <li>* BYE, CON, LIST, MERGE, NEW, NUM, OLD, RES, or SAVE used in a program.</li> </ul>
84	DATA ERROR	<ul style="list-style-type: none"> <li>* READ or RESTORE with data not present or with a</li> </ul>

- string where a number value is expected.
- \* Line number after RESTORE is higher than the highest line number in the program.
  - \* Error in object file in LOAD.
    - 109 FILE ERROR
  - \* Wrong type of data read with a READ statement.
- \* Attempt to use CLOSE, EOF, INPUT, OPEN, PRINT, PRINT USING, REC, or RESTORE with a file that does not exist or does not have the proper attributes.
  - \* Not enough memory to use a file.
    - 44 FOR-NEXT NESTING
- \* The FOR and NEXT statements of loops do not align properly.
  - \* Missing NEXT statement.
    - 130 I/O ERROR
- \* An error was detected in trying to execute CLOSE, DELETE, LOAD, MERGE, OLD, OPEN, RUN, or SAVE.
- \* Not enough memory to list a program.
- 16 ILLEGAL AFTER SUBPROGRAM
  - \* Anything but END, REM, or SUB after a SUBEND.
- 36 IMAGE ERROR
  - \* An error was detected in the use of DISPLAY USING, IMAGE, or PRINT USING.
  - \* More than 10 (E-format) or 14 (numeric format) significant digits in the format string.
  - \* IMAGE string is longer than 254 characters.
- 28 IMPROPERLY USED NAME
  - \* An illegal variable name was used in CALL, DEF, or DIM.
    - \* Using a Geneve 9640 Advanced BASIC reserved word in LET.
  - \* Using a subscripted variable or a string variable in a FOR.
  - \* Using an array with the wrong number of dimensions.
  - \* Using a variable name differently than originally assigned.
    - A variable can be only an array, a numeric or string variable, or a user defined function name.
    - \* Dimensioning an array twice.
  - \* Putting a user defined function name on the left of the equals sign in an assignment statement.
    - \* Using the same variable twice in the parameter list of a SUB statement.
- 81 INCORRECT ARGUMENT LIST
  - \* CALL and SUB mismatch of arguments.
    - 83 INPUT ERROR
  - \* An error was detected in an INPUT.
    - 60 LINE NOT FOUND
  - \* Incorrect line number found in BREAK, GOSUB, GOTO, ON ERROR, RUN, or UNBREAK, or after THEN or ELSE.
    - \* Line to be edited not found.

- 62 LINE TOO LONG  
\* Line too long to be entered into a program.
- 39 MEMORY FULL  
\* Program too large to execute one of the following: DEF, DELETE, DIM, GOSUB, LET, LOAD, ON...GOSUB, OPEN, or SUB.  
\* Program too large to add a new line, insert a line, replace a line, or evaluate an expression.
- 49 MISSING SUBEND  
\* SUBEND missing in a subprogram.
- 47 MUST BE IN SUBPROGRAM  
\* SUBEND or SUBEXIT not in a subprogram.
- 19 NAME TOO LONG  
\* More than 15 characters in variable or subprogram name.
- 43 NEXT WITHOUT FOR  
\* FOR statement missing, NEXT before FOR, incorrect FOR-NEXT nesting, or branching into a FOR-NEXT loop.
- 78 NO PROGRAM PRESENT  
\* No program present when issuing a LIST, RESEQUENCE, RESTORE, RUN, or SAVE command.
- 10 NUMERIC OVERFLOW  
\* A number too large or too small resulting from a \*,+,-,/ operation or in ACCEPT, ATN, COS, EXP, INPUT, INT, LOG, SIN, SQR, TAN, or VAL.  
\* A number outside the range -32768 to 32767 in PEEK or LOAD.
- 70 ONLY LEGAL IN A PROGRAM  
\* One of the following statements was used as a command: DEF, GOSUB, GOTO, IF, IMAGE, INPUT, ON BREAK, ON ERROR, ON...GOSUB, ON...GOTO, ON WARNING, OPTION BASE, RETURN, SUB, SUBEND, or SUBEXIT.
- 25 OPTION BASE ERROR  
\* OPTION BASE executed more than once, or with a value other than 1 or zero.
- 97 PROTECTION VIOLATION  
\* Attempt to save, list, or edit a protected program.
- 48 RECURSIVE SUBPROGRAM CALL  
\* Subprogram calls itself, directly or indirectly.
- 51 RETURN WITHOUT GOSUB  
\* RETURN without GOSUB or an error handled by the previous execution of an ON ERROR statement.
- 56 SPEECH STRING TOO LONG  
\* Speech string returned by SPGET is longer than 255 characters.
- 40 STACK OVERFLOW  
\* Too many sets of parentheses.  
\* Not enough memory to evaluate an expression or assign a value.

## 54 STRING TRUNCATED

- \* A string created by RPT\$, concatenation ("&" operator), or a user defined function is longer than 255 characters.
- \* The length of a string expression in the VALIDATE clause is greater than 254 characters.

## 24 STRING-NUMBER MISMATCH

- \* A string was given where a number was expected or vice versa in a Geneve 9640 Advanced BASIC supplied function or subprogram.
- \* Assigning a string value to a numeric value or vice versa.
- \* Attempting to concatenate ("&" operator) a number.
- \* Using a string as a subscript.
- 135 SUBPROGRAM NOT FOUND
- \* A subprogram called does not exist or an assembly language subprogram named in LINK has not been loaded.

## 14 SYNTAX ERROR

- \* An error such as a missing or extra comma or parenthesis, parameters in the wrong order, missing parameters, missing keyword, misspelled keyword, keyword in the wrong order, or the like was detected in a Geneve 9640 Advanced BASIC command, statement, function, or subprogram.
- \* DATA or IMAGE not first and only statement on a line.
- \* Items after final ")".
- \* Missing "#" in SPRITE.
- \* Missing ENTER, tail comment symbol (!), or statement separator symbol (::).
- \* Missing THEN after IF.
- \* Missing TO after FOR.
- \* Nothing after CALL, SUB, FOR, THEN, or ELSE.
- \* Two E's in a numeric constant.
- \* Wrong parameter list in a Geneve 9640 Advanced BASIC supplied subprogram.
- \* Going into or out of a subprogram with GOTO, GOSUB, ON ERROR, etc.
- \* Calling INIT without the Memory Expansion peripheral attached.
- \* Calling LINK or LOAD without first calling INIT.
- \* Using a constant where a variable is required.
- \* More than seven dimensions in an

## array. 17 UNMATCHED QUOTES

- \* Odd number of quotes in an input

## line. 20 UNRECOGNIZED CHARACTER

- \* An unrecognized character such as ? or % is not in a quoted string.
- \* A bad field in an object file accessed by LOAD.

## Additional Error Messages

Sorted by #

#	Message
35	SYMBOL NOT FOUND
63	STRING FORMAT ERROR
64	ERROR BASIC OS
65	MOUSE MODE ERROR
99	INVALID ERROR NUMBER
101	INTEGER OVERFLOW
102	INVALID FILENAME
103	ARGUMENT NOT NUMERIC
104	MISSING ARGUMENT
105	TOO MANY ARGUMENTS
106	STRING TOO LONG
107	GRAPHICS MODE ERROR
108	WINDOW TOO SMALL
111	MEMORY OVERFLOW
112	CHECKSUM ERROR
113	DUPLICATE DEF
114	ILLEGAL TAG
115	UNRESOLVED REFERENCE
116	NAME NOT IN TABLE
117	INDEX OUT OF RANGE

These messages are added to syntax or bad value error messages if appropriate.

MISSING COMMA  
MISSING LEFT PAREN  
MISSING RIGHT PAREN  
LINETYPE(see Draw, Rect)  
PIXEL ROW or PIXEL COL

## GRAPHIC MODES Vs XOP6 VIDEO MODES Vs V9938 MODES

GRAPHICS MODE	XOP6 VIDEO MODE	V9938 MODE
1,1	2/3	Multicolor/Graphic 1
1,2	4	Graphic 2
1,3	5	Graphic 3
2,1	0	Text 1
2,2	6	Graphic 4
2,3	9	Graphic 7
3,1	A	Text 2-26 lines
3,2	7	Graphic 5
3,3	8	Graphic 6

**APPENDIX K****GRAPHICS MODES - Summary**

GRAPHICS MODE	SCREEN DIMEN.	SCREE N SIZE	DEFAULT MARGINS	MODE NAME	NO.OF PATNS .	COLORS PER SCREEN	PATTERN SIZE	SPRIT E MODE	MEMORY / SCREEN
1,1	256,19 2	32x24	3,30 1,24	Pattern Graphic1	256	16	8 x 8	1 4/line	4K/scr 32 pgs
1,2	256,19 2	32x24	3,30 1,24	Graphic 2	768	16	8 x 8	1 4/line	16K/sc r 8
1,3	256,19 2	32x24	3,30 1,24	Graphic 3	768	16	8 x 8	2 8/line	16K/sc r 8
2,1	256,19 2	40x24	1,40 1,24	Text- 1	256	2	6 x 8	None	4K/scr 3 pgs
2,2	256x21 2	40x26	1,40 1,24	Bitmap- 1	???	16	6 x 8	2 8/line	32K/scr 4 pgs
2,3	256,21 2	40x26	1,40 1,24	Bitmap- 4	???	256	6 x 8	2 8/line	64K/sc r 2
3,1	512,21 2	80x26	1,80 1,24	Text- 2	256	2+2	6 x 8	None	8K/scr 16 pgs
3,2	512x21 2	80x26	1,80 1,24	Bitmap- 2	???	4	6 x 8	2 8/line	32K/scr 4 pgs
3,3	512x21 2	80x26	1,80 1,24	Bitmap- 3	???	16	6 x 8	2 8/line	64K/sc r 2

APPENDIX L

## PROGRAM - ILLUSTRATING MOUSE COMMANDS

The following program illustrates the use of several MOUSE Commands to draw lines on the screen. Press MOUSE button 1 to start drawing a line and hold it down until you are done drawing.

```
100 CALL GRAPHICS(2,3) :: REM 256 COLOR BIT MAPPED MODE
110 CALL SPRITE(#1,33,16,1,1) :: REM DEFINE MOUSE AS !
120 CALL SEEMOUSE :: REM MAKE SURE MOUSE IS VISIBLE ON SCREEN
130 CALL MOUSE(Y,1) :: REM TEST FOR BUTTON PRESS
140 IF Y=0 THEN 130 :: REM WAIT FOR A BUTTON PRESS
150 CALL MOUSEDRAW(ON) :: REM BUTTON PRESSED SO START DRAWING
160 CALL MOUSE(Y,1) :: REM TEST BUTTON STATUS
170 IF Y=1 THEN 160 :: REM DRAW UNTIL RELEASED
180 CALL MOUSEDRAW(OFF) :: REM STOP DRAWING WHEN RELEASED
190 GO TO 130 :: REM GO TO WAIT FOR NEXT BUTTON PRESS
```

**APPENDIX M****Call Key ASCII Characters Chart**

The value you specify for the key-unit determines what portion of the keyboard is active and how the key pressed is interpreted.

**KEY-UNIT RESULT**

- 0 Console keyboard, in mode previously specified by CALL KEY.
- 1 only the left side of the keyboard is active.
- 2 only the right side of the keyboard is active.
- 3 Places keyboard in the same mode as mode 0.
- 4 Remaps the keyboard in the PASCAL mode. Both upper and lower-case alphabetical character codes are returned by the computer. May cause erroneous values.
- 5 Places the key board in 99/4A BASIC mode. Both upper- and lower-case alphabetical character codes are returned by the computer.

Geneve 9640 Advanced BASIC  
Call Key ASCII Character Sets for Modes 1-5

<MODE>							<MODE>						
KEY	0	1	2	3	4	5	KEY	0	1	2	3	4	5
vvvvvvKEYvvvvv	0	1	2	3	4	5	vvvvvvKEYvvvvv	0	1	2	3	4	5
--- ~ ---	96	-	-	96	96	96	SHIFT	58	-	-	58	58	58
SHIFT	126	-	-	126	126	126	--- ' ---	39	-	-	39	39	39
--- 1 ---	49	19	-	49	49	49	SHIFT	34	-	-	34	34	34
CTRL	177	-	-	177	177	177	--- , ---	44	-	14	44	44	44
FCTN	3	-	-	3	131	3	CTRL	128	-	-	128	0	128
SHIFT	33	-	-	33	33	33	FCTN	184	-	-	184	184	184
--- 2 ---	50	7	-	50	50	50	SHIFT	60	-	-	60	60	60
CTRL	178	-	-	178	178	178	--- . ---	46	-	13	46	46	46
FCTN	4	-	-	4	132	4	CTRL	155	-	-	155	27	155
SHIFT	64	-	-	64	64	64	FCTN	185	-	-	185	185	185
--- 3 ---	51	8	-	51	51	51	SHIFT	62	-	-	62	62	62
CTRL	179	-	-	179	179	179	--- / ---	47	-	16	47	47	47
FCTN	7	-	-	7	135	7	CTRL	187	-	-	187	187	187
SHIFT	35	-	-	35	35	35	SHIFT	63	-	-	63	63	63
--- 4 ---	52	9	-	52	52	52	--- A ---	65	1	-	65	65	65
CTRL	180	-	-	180	180	180	CTRL	129	-	-	129	1	129
FCTN	2	-	-	2	130	2	FCTN	124	-	-	124	124	124
SHIFT	36	-	-	36	36	36	--- B ---	66	16	-	66	66	66
--- 5 ---	53	10	-	53	53	53	CTRL	130	-	-	130	2	130
CTRL	181	-	-	181	181	181	FCTN	190	-	-	190	190	190
FCTN	14	-	-	14	142	14	--- C ---	67	14	-	67	67	67
SHIFT	37	-	-	37	37	37	CTRL	131	-	-	131	3	131
--- 6 ---	54	-	19	54	54	54	FCTN	96	-	-	96	96	96
CTRL	182	-	-	182	182	182	--- D ---	68	3	-	68	68	68
FCTN	12	-	-	12	140	12	CTRL	132	-	-	132	4	132
SHIFT	94	-	-	94	94	94	FCTN	9	-	-	9	137	9
--- 7 ---	55	-	7	55	55	55	--- E ---	69	5	-	69	69	69
CTRL	183	-	-	183	183	183	CTRL	133	-	-	133	5	133
FCTN	1	-	-	1	129	1	FCTN	11	-	-	11	139	11
SHIFT	38	-	-	38	38	38	--- F ---	70	12	-	70	70	70
--- 8 ---	56	-	8	56	56	56	CTRL	134	-	-	134	6	134
CTRL	158	-	-	158	30	158	FCTN	123	-	-	123	123	123
FCTN	6	-	-	6	134	6	--- G ---	71	17	-	71	71	71
SHIFT	42	-	-	42	42	42	CTRL	135	-	-	135	7	135
--- 9 ---	57	-	9	57	57	57	FCTN	125	-	-	125	125	125
CTRL	159	-	-	159	31	159	--- H ---	72	-	1	72	72	72
FCTN	15	-	-	15	143	15	CTRL	136	-	-	136	8	136
SHIFT	40	-	-	40	40	40	FCTN	191	-	-	191	191	191
--- 0 ---	48	-	10	48	48	48	--- I ---	73	-	5	73	73	73
CTRL	176	-	-	176	176	176	CTRL	137	-	-	137	9	137
FCTN	188	-	-	188	188	188	FCTN	63	-	-	63	63	63
SHIFT	41	-	-	41	41	41	--- J ---	74	-	2	74	74	74
--- - ---	45	-	-	45	45	45	CTRL	138	-	-	138	10	138
SHIFT	95	-	-	95	95	95	FCTN	192	-	-	192	192	192
--- = ---	61	-	-	61	61	61	--- K ---	75	-	3	75	75	75
CTRL	157	-	-	157	29	157	CTRL	139	-	-	139	11	139
FCTN	5	-	-	5	133	5	FCTN	193	-	-	193	193	193
SHIFT	43	-	-	43	43	43	--- L ---	76	-	12	76	76	76
--- [ ---	91	-	16	91	91	91	CTRL	140	-	-	140	12	140
SHIFT	123	-	-	123	123	123	FCTN	194	-	-	194	194	194
--- ] ---	93	-	-	93	93	93	--- M ---	77	-	0	77	77	77
SHIFT	125	-	-	125	125	125	CTRL	141	-	-	141	13	141
--- \ ---	92	-	-	92	92	92	FCTN	195	-	-	195	195	195
SHIFT	124	-	-	124	124	124	--- N ---	78	-	15	78	78	78
--- ; ---	59	-	17	59	59	59	CTRL	142	-	-	142	14	142
CTRL	156	-	-	156	28	156	FCTN	196	-	-	196	196	196
FCTN	189	-	-	189	189	189	--- O ---	79	-	6	79	79	79

## Appendix M (Cont.)

KEY	<MODE>						KEY	<MODE>					
	0	1	2	3	4	5		0	1	2	3	4	5
CTRL	143	-	-	143	15	143	m	109	A	A	77	109	109
FCTN	39	-	-	39	39	39	n	110	S	S	78	110	110
--- P ---	80	-	11	80	80	80	o	111	-	-	79	111	111
CTRL	144	-	-	144	16	144	p	112	C	C	80	112	112
FCTN	34	-	-	34	34	34	q	113	A	A	81	113	113
--- Q ---	81	18	-	81	81	81	r	114	P	P	82	114	114
CTRL	145	-	-	145	17	145	s	115	S	S	83	115	115
FCTN	197	-	-	197	197	197	t	116			84	116	116
--- R ---	82	6	-	82	82	82	u	117			85	117	117
CTRL	146	-	-	146	18	146	v	118			86	118	118
FCTN	91	-	-	91	91	91	w	119			87	119	119
--- S ---	83	2	-	83	83	83	x	120			88	120	120
CTRL	147	-	-	147	19	147	y	121			89	121	121
FCTN	8	-	-	8	136	8	z	122			90	122	122
--- T ---	84	11	-	84	84	84	BACKSPACE	8	-	-	8	136	8
CTRL	148	-	-	148	20	148	INSERT	4	-	-	4	132	4
FCTN	93	-	-	93	93	93	HOME	-	18	-	-	-	-
--- U ---	85	-	4	85	85	85	PAGE UP	12	-	-	12	140	12
CTRL	149	-	-	149	21	149	TAB	137	-	-	137	9	137
FCTN	95	-	-	95	95	95	DELETE	3	-	-	3	131	3
--- V ---	86	13	-	86	86	86	PAGE DOWN	2	-	-	2	130	2
CTRL	150	-	-	150	22	150	ESC	155	-	-	155	27	155
FCTN	127	-	-	-	127	127	UP ARROW	11	5	-	11	139	11
--- W ---	87	4	-	87	87	87	DOWN ARROW	10	0	-	10	138	10
CTRL	151	-	-	151	23	151	LEFT ARROW	8	2	-	8	136	8
FCTN	126	-	-	126	126	126	RIGHT ARROW	9	3	-	9	137	9
--- X ---	88	0	-	88	88	88	F1 SL ON	226	-	-	226	226	226
CTRL	152	-	-	152	24	152	F1 SL OFF	3	-	-	3	131	3
FCTN	10	-	-	10	138	10	F2 SL ON	227	-	-	227	227	227
--- Y ---	89	-	18	89	89	89	F2 SL OFF	4	-	-	4	132	4
CTRL	153	-	-	153	25	153	F3 SL ON	228	-	-	228	228	228
FCTN	198	-	-	198	198	198	F3 SL OFF	7	-	-	7	135	7
--- Z ---	90	15	-	90	90	90	F4 SL ON	229	-	-	229	229	229
CTRL	154	-	-	154	26	154	F4 SL OFF	2	-	-	2	130	2
FCTN	92	-	-	92	92	92	F5 SL ON	230	-	-	230	230	230
SPACE	32	-	-	32	32	32	F5 SL OFF	14	-	-	14	142	14
ENTER	13	-	-	13	13	13	F6 SL ON	231	-	-	231	231	231
a	97			65	97	97	F6 SL OFF	12	-	-	12	140	12
b	98			66	98	98	F7 SL ON	232	-	-	232	232	232
c	99			67	99	99	F7 SL OFF	1	-	-	1	129	1
d	100			68	100	100	F8 SL ON	233	-	-	233	233	233
e	101			69	101	101	F8 SL OFF	6	-	-	6	134	6
f	102			70	102	102	F9 SL ON	234	-	-	234	234	234
g	103			71	103	103	F9 SL OFF	15	-	-	15	143	15
h	104	S	S	72	104	104	F10 SL ON	235	-	-	235	235	235
i	105	A	A	73	105	105	F10 SL OFF	188	-	-	188	188	188
j	106	M	M	74	106	106	F11	224	-	-	224	224	224
k	107	E	E	75	107	107	F12	225	-	-	225	225	225
l	108	-	-	76	108	108							

CALL KEY ASCII CHARACTERS

## Appendix N

### ABASIC ASSEMBLY SUPPORT AND OTHER INFORMATION

UTILITIES INFO		XMLLNK DATA VALUES	
ADDRESS	CONTENTS		
>2002	>24F4 (DEFAULT-NO PGM)	6	CNS
>2004	>DF68 (DEFAULT-NO PGM)	>20	CIF
>DF60	1st LINK NAME	>26	SCROLL
>DF66	1st LINK ADDRESS	>0D3A	FCOMP
>DF68	SCAN >236C	>0D7C	FSUB
>DF70	PAD >8300	>0D80	FADD
>DF78	GPLWS >83E0	>0E88	FMUL
>DF80	SOUND >F120	>0FF4	FDIV
>DF88	VDPRD >F100	>11AE	CSN
>DF90	VDPSTA >F102	>12B8	CFI
>DF98	VDPWD >F100		
>DFA0	VDPWA >F102		
>DFA8	XMLLNK >2018	UTILITIES NOT SUPPORTED	
>DFB0	KSCAN >201C		
>DFB8	VSBW >2020		
>DFC0	VMBW >2024		
>DFC8	VSBW >2028		
>DFD0	VMBR >202C		
>DFD8	VMTR >2030		
>DFE0	NUMASG >2008		
>DFE8	NUMREF >200C		
>DFF0	STRASG >2010		
>DFF8	STRREF >2014		
		COMPCT	
		GETSTR	
		MEMCHK	
		VPUSH	
		VPOP	
		ASSGNV	
		VGWITE	
		GVWITE	

RORG programs start loading at address >24F4 thru >DF67(minus 8 bytes for each "LINK" name and address)

Utility workspace used by ABASIC for assembly programs >2038 to >2098

First free address pointer >2002

Last free address pointer >2004

ABASIC memory tables start at >FB00(The pages allocated)

Default I/O pab is at >FC00 (64 bytes)

ABASIC FAC and ARG are located at >F3C0 and F3D0

The TI FAC and ARG can be used also. Any program that loaded into those memory locations would corrupt those memory locations, unless your program provides memory space for these routines.

No portion of address >F140 to >FE30 can be used to store an assembly language program, although an assembly language program can use information from these addresses (i.e. I/O PAB)

The following are the meanings of values returned when a drive is cataloged(file type):

- 1 D/F
- 2 D/V
- 3 I/F
- 4 I/V
- 5 PGM
- 6 DIR
- 7 EMU

If these values have a minus sign in front of them it means that the file is protected.

## Appendix N (Cont.)

### ABASIC ASSEMBLY SUPPORT AND OTHER INFORMATION

DEFAULT I/O PAB DETAIL at >FC00 (64 bytes)

OPCODE	EQU 0	I/O OPCODE
MFLAG	EQU 1	MODE FLAG
ECODE	EQU 2	ERROR CODE
BAHIGH	EQU 3	BUF ADD HIGH
BALOW	EQU 4	BUF ADD LOW
LRN	EQU 6	LOGICAL RECORD NUMBER
RECNUM	EQU 6	RECORD NUMBER
LRC	EQU 8	LOGICAL RECORD LENGTH
MEMTYP	EQU 10	CPU or VDP
CCHIGH	EQU 11	CHARACTER COUNT HIGH
CHRCNT	EQU 12	CHAR COUNT
STATBY	EQU 14	STATUS BYTE(RECORD NUMBER)
NAMEL	EQU 15	NAME LENGTH
NAME	EQU 16	NAME(40 characters)
IOCONT	EQU 56	IO CONTINUE
FILENO	EQU 57	BASIC FILE NUMBER
INTOFF	EQU 58	POINTER INTO BUFFER
PABBUF	EQU 60	32 BIT ADDRESS POINTER TO DATA BUFFER

### Keyboard Grouping

The keyboard treats the following keys as a group, rather than individually; CTRL, SHIFT, NUM- LOCK, CAPS-LOCK and INS. The service routine for the keyboard I/O routine returns a "shift status" byte that tells you when one of these keys are pressed.

### PRE-SCAN

The following symbols are used by ABASIC for pre-scan:

!@P+ Turn pre-scan on  
!@P- Turn pre-scan off  
!@P\* Terminate pre-scan

If your program uses a large quantity of variables(any kind) it is recommended that pre-scan be used.

String variables(any kind) should precede numeric variables(any). Memory space allocated for strings is less than that of numeric variables and allows for the most efficient use of Data space(Freespace(2)).

## Appendix N (Cont.)

### ABASIC ASSEMBLY SUPPORT AND OTHER INFORMATION

ABASIC Memory block >F000->FFFF

>F000->F01F	User and ABASIC WS Register
>F020->F03F	ABASIC WS Register
>F040->F047	Fast move byte routine
>F048->F04F	Fast move word routine
>F050->F061	Fast move to/from stack routine
>F062->F07D	Fast move memory table page 3 to active page 3
>F080->F0FF	ABASIC WS Registers (Many ABASIC routines use these registers i.e.XOP)
>F100->F107	Port read/write (0,1,2,3)
>F108->F10F	Port read/write (0,1,2,3)
>F110->F117	Page Map(active pages)
>F120->F12F	Sound
>F130->F13F	Clock
>F140->FE2F	ABASIC support data(i.e. i/o pab, buffers, program storage info). Corruption of this memory block will cause lockup.
>FE30->FF2F	Reserved for ABASIC
>FF30->FFDF	Unused block of memory(Debug may use part of this)
>FFE0->FFFF	Used by MDOS and DEBUG

Call Peek can be used to get the values from >0000->FFFF memory addresses. Information at these memory addresses are values based on the visible memory(active pages).

Call Load can be used to put values in >2000->DFFF memory addresses, but memory addresses >2000->24F3 contain the ABASIC Assembly support routines and other ABASIC routines. (See Utilities info table)

The following are four new assembly instructions available to the TMS9995:  
DIVS (DIVide Signed)      MPYS (MultiPLY Signed)

```
[<label>] DIVS <gas> [<comment>]  
[<label>] MPYS <gas> [<comment>]
```

A destination-operand is not used, because it must always be R0 and R1 of the user workspace.

#### Examples

DIVS R2	DIVS *R4+	DIVS @ADDR	DIVS @VALUE(R10)
MPYS R3	MPYS *R7+	MPYS @LABEL	MPYS @INDEX(R8)

opcodes:	DIVS	=	>0180	Format VI
	MPYS	=	>01C0	Format VI

LWP (Load workspace-Pointer from a register)  
LST (Load SStatus-register)

```
[<label>] LWP <wa> [<comment>]  
[<label>] LST <wa> [<comment>]
```

opcodes:	LWP	=	>0090	Format VIII
	LST	=	>0080	Format VIII
Examples	LWP R5		LWP R12	LST R13      LST R0

## APPENDIX O

### COLOR CHART DEFAULT PALETTE

COLOR	MDOS		MYBASIC	
	CODE	G, R, B	CODE	R, G, B
TRANSPARENT	0	0,0,0	1	0,0,0
BLACK	1	0,0,0	2	1,1,1
GREEN	2	6,1,1	3	1,7,1
LT GREEN	3	7,3,3	4	3,8,3
DK BLUE	4	1,1,7	5	1,1,8
LT BLUE	5	3,2,7	6	3,4,8
DK RED	6	1,5,1	7	6,1,1
CYAN	7	6,2,7	8	2,7,8
MED RED	8	1,7,1	9	8,1,1
LT RED	9	3,7,3	10	8,3,3
DK YELLOW	A	6,6,1	11	7,7,1
LT YELLOW	B	6,6,4	12	7,7,4
DK GREEN	C	4,1,1	13	1,5,1
MAGENTA	D	2,6,5	14	7,2,6
GRAY	E	5,5,5	15	6,6,6
WHITE	F	7,7,7	16	8,8,8

### HEXDECIMAL TO DECIMAL CHART

5th DIGIT		4th DIGIT		3rd DIGIT		2nd DIGIT		1st DIGIT		
HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	
0	0	0	0	0	0	0	0	0	0	
1	65536	1	4096	1	256	1	16	1	1	1
2	131072	2	8192	2	512	2	32	2	2	2
3	96608	3	12288	3	768	3	48	3	3	3
4	262144	4	16384	4	1024	4	64	4	4	4
5	327680	5	20480	5	1280	5	80	5	5	5
6	393216	6	24576	6	1536	6	96	6	6	6
7	458752	7	28672	7	1792	7	112	7	7	7
8	524288	8	32768	8	2048	8	128	8	8	8
9	589824	9	36864	9	2304	9	144	9	9	9
A	655360	A	40960	A	2560	A	160	A	10	10
B	720896	B	45056	B	2816	B	176	B	11	11
C	786432	C	49152	C	3072	C	192	C	12	12
D	851968	D	53248	D	3328	D	208	D	13	13
E	917504	E	57344	E	3584	E	224	E	14	14
F	983040	F	61440	F	3840	F	240	F	15	15

## APPENDIX P

### RS232 INFO AND OUTP EXAMPLE

#### RS232 MEMORY MAP FOR MYBASIC ONLY

C000 - CFFE      DSR ROM  
D000 - DFFE      PARALLEL I/O

#### RS232 CARD OUTPUT/INPUT BIT DEFINITION

MYBASIC ONLY SUPPORTS CRU ADDRESS >1300(PORT/1) AND >1500(PORT/2) FOR INP AND OUTP.

#### ADDRESS BUS BIT LAYOUT (Only A3 thru A14 are used)

A0	A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13	A14	A15
NOT USED			BASE ADDRESS					CRU ADDRESS							

#### RS232 CARD CRU OUTPUT BIT DEFINITION

ADDR	BIT	DEFINITION
1300	0	DSR ROM page enable, 1=enable
1302	1	Parallel Port mode set, 1=input mode
1304	2	Parallel Port Strobe bit
1306	3	Spare Parallel Port bit
1308	4	Flag 0
130A	5	Clear To Send, RS232 Port 0, 0=active
130C	6	Clear To Send, RS232 Port 1, 0=active
130E	7	Indicator LED control, 1=LED on

#### RS232 CARD CRU INPUT DEFINITION

ADDR	BIT	DEFINITION
1300	0	Spare
1302	1	Parallel Port configuration sense
1304	2	Parallel Port Acknowledge sense bit
1306	3	Spare Parallel Port Sense bit
1308	4	Flag 0
130A	5	Clear To Send, RS232 Port 0 sense
130C	6	Clear To Send, RS232 Port 1 sense
130E	7	LED state sense

#### 9902 UART BASE ADDRESSES

UART 0=1340      UART 1=1380

#### TI RS232 CARD DEFINITIONS FOR ADDRESS C000 - C00E

ADDR	CONTENTS	EXPLANATION
C000	BYTE >AA	Identification
C001	BYTE 1	Version number
C002	BYTE 0	Number of programs
C003	BYTE 0	Reserved
C004	DATA >C010	Power up routine
C006	DATA 0	User program header
C008	DATA >C016	DSR header
C00A	DATA 0	Subroutine link header
C00C	DATA >C06C	Address of interrupt link
C00E	DATA 0	Address of subroutine libraries

## APPENDIX P (Cont.)

### RS232 INFO AND OUTP EXAMPLE CON'T

ASCII CODE	FUNCTION ACRONYM	FUNCTION	ASCII CODE	FUNCTION ACRONYM	FUNCTION
0	NUL	Null	17	DC1	Device Control 1
1	SOH	Start heading	18	DC2	Device Control 2
2	STX	Start text	19	DC3	Device Control 3
3	ETX	End text	20	DC4	Device Control 4
4	EOT	End transmission	21	NAK	Negative ACK
5	ENQ	Enquiry	22	SYN	Synchronous idle
6	ACK	Acknowledge	23	ETB	End transmission block
7	BEL	Bell	24	CAN	Cancel
8	BS	Backspace	25	EM	End medium
9	HT	Horizontal tab	26	SUB	Substitute
10	LF	Line feed	27	ESC	Escape
11	VT	Vertical tab	28	FS	File separator
12	FF	Form feed	29	GS	Group separator
13	CR	Carriage return	30	RS	Record separator
14	SO	Shift out	31	US	Unit separator
15	SI	Shift in			
16	DLE	Data link escape			

### SOFTWARE OPTIONS

OPTION                      Enter As

BAUD RATE=110, 300,600, 1200, 2400, 4800, 9600    .BA=(desired rate)  
 DATA BITS= 7 or 8                                      .DA= 7 (or 8)  
 PARITY=ODD,EVEN,ONE.PA= 0 (or E or N)  
 TWO STOP BITS                      .TW  
 NULLS                                      .NU  
 CHECK PARITY                      .CH  
 ECHO OFF                                      .EC  
 CRLF OFF                                      .CR  
 LF OFF                                      .LF

Only Baud rate and stop bits are allowed in an OLD/SAVE to RS232  
 Only Nulls, Echo off, Crlf off and Lf off can be used with PIO

### Example program using OUTP

```

100 A$="THIS IS A TEST"
110 CALL OUTP(1,7)          :!! Ring printer bell
120 CALL OUTP(1,15)         :!! Set printer to condensed
130 FOR X=1 TO 14           :!! \
140 A=ASC(SEG$(A$,X,1))     :!! Send ASCII value to printer
150 CALL OUTP(1,A)          :!! /
160 NEXT X                  :!! /
170 CALL OUTP(1,18)         :!! Cancel condensed
180 CALL OUTP(1,10)         :!! Send linefeed
190 !CALL OUTP(1,13)        :!! Carriage return(uni-directional printers)
The 1 in OUTP is RS232 port at CRU >1300    2 would be >1500

```

## APPENDIX Q

### Some differences between TI99 XB and Geneve Advance BASIC

SPRITE & LOCATE pixel Row & Column can not exceed maximum screen size.

Exiting ON ERROR before it's RETURN will give unexpected results.

If you have a subprogram HELP1 that calls HELP2, then HELP2 must precede HELP1 in the program.

Speed of Advanced BASIC is roughly three to five times that of XB.

To use the standard XB graphics the command CALL GRAPHICS(1,1) must first be in the program.

Advanced BASIC pre-scan is significantly faster than XB.

There are many more graphics modes in Advanced BASIC than XB as well as extended SPRITE capabilities.

The MOUSE can be read directly in Advanced BASIC with its own set of commands.

Many of the PEEK and POKE commands in XB won't work in Advanced BASIC.

Embedded Assembly Language files probably won't run in Advanced BASIC.

You can access the drives in Advanced BASIC with MDOS drive letters such as A:, B:, E:... as well as DSK1, DSK2, HDS1...

Ctrl-C must be used to exit the running program in Advanced BASIC instead of Ftn-4 (berak) as in XB.

Some commands not in TI99 Extended BASIC but in Advanced BASIC:

CINT  
CLS  
CREAL  
DATE,DATE\$  
DEFINT,DEFREAL,DEFSTR  
CHDIR  
HEX\$  
KILL  
LPT  
MOD  
MOUSE  
TERMCHAR  
VALHEX  
WHILE,WEND

## **APPENDIX R** **Commands by category**

<b>Command</b>	<b>page #</b>
<b>File control</b>	
CHDIR.....	26
CLOSE.....	31
DELETE.....	48
EOF.....	63
FILES.....	67
KILL.....	100
LOAD.....	112
MERGE.....	125
MYART.....	132
OLD.....	137
OPEN.....	148
REC.....	172
SAVE.....	187
 <b>Program control</b>	
BREAK.....	16
BTIME.....	18
BYE.....	18
CALL.....	19
CONTINUE.....	37
DEF.....	44
DEFvartype.....	46
DIM.....	50
END.....	62
ERR.....	64
FOR TO.....	70
FREESPACE.....	73
GOSUB.....	76
GOTO.....	78
HEX\$.....	83
IF THEN ELSE.....	84
LET.....	103
LIST.....	108
LLIST.....	110
LTRACE.....	117
NEW.....	132
NEXT.....	133
NUMBER.....	134
ON BREAK.....	138
ON ERROR.....	140
ON GOSUB.....	142
ON GOTO.....	144
ON WARNING.....	146
OPTION BASE.....	151
READ.....	171
REM.....	176
RESEQUENCE.....	177
RESTORE.....	178
RETURN.....	180
RUN.....	185
STOP.....	206
SUB.....	208
SUBEND.....	211
SUBEXIT.....	212
SWAP.....	213
TRACE.....	219
UNBREAK.....	220

VLHEX.....	222
VERSION.....	225
WEND.....	225
WHILE.....	226

## Sound, graphics & sprites control

BCOLOR.....	14
CIRCLE.....	29
CLEAR.....	30
CLS.....	32
COINC.....	33
COLOR.....	35
DCOLOR.....	43
DELSPRITE.....	49
DISTANCE.....	56
DRAW.....	58
DRAWTO.....	60
ECOLOR.....	61
FILL.....	68
GCHAR & GPOINT.....	74
GRAPHICS.....	79
HCHAR.....	82
LOCATE.....	114
LPR.....	116
MAGNIFY.....	118
MOTION.....	129
PALETTE.....	152
PATTERN.....	153
POINT.....	158
POSITION.....	163
PSET.....	160
RECTANGLE.....	174
RESETPLT.....	176
SCHAR.....	190
SCREEN.....	190
SOUND.....	195
SPRITE.....	199
TCOLOR.....	216
VCHAR.....	223

## String control

ACCEPT.....	10
ASC.....	13
BEEP.....	15
CHAR.....	21
CHARPAT.....	25
CHARSET.....	26
CHR\$.....	27
DISPLAY.....	52
DISPLAY USING.....	55
IMAGE.....	86
INPUT.....	90
LEFT\$.....	101
LEN.....	102
LINPUT.....	106
MARGINS.....	121
POS.....	161
PRINT.....	164
PRINT USING.....	169
RIGHT\$.....	182
RPT\$.....	184
SEG\$.....	192
STR\$.....	207

TAB.....	214
TERMCHAR.....	217
VAL.....	221

#### **Numeric control**

ABS.....	09
ATN.....	14
CINT.....	28
COS.....	38
CREAL.....	39
EXP.....	66
INT.....	94
LOG.....	115
MAX.....	123
MIN.....	127
MOD.....	128
PI.....	157
RANDOMIZE.....	170
RND.....	183
SGN.....	193
SIN.....	194
SQR.....	205
TAN.....	215

#### **Memory & peripheral control**

DATE/DATE\$.....	42
INIT.....	89
INP.....	89
JOYST.....	95
CALL KEY.....	96
KEY.....	98
LINK.....	105
LPT.....	116
MEMSET.....	124
MOUSE.....	130
OUTP.....	152
PEEK.....	154
PEEKV.....	156
POKEV.....	159
PPT.....	164
SAY.....	189
SPGET.....	198
TIME/TIME\$.....	218

**NOTES:**

**Geneve 9640 Advanced BASIC User's Manual  
update v409C  
Copyright 2023**